	Pictorial index	Search by illustration	
1	For safety and security	Make sure to read through them	
2	Instrument cluster	How to read the gauges and meters, the variety of warning lights and indicators, etc.	
3	Operation of each component	Opening and closing the doors and windows, adjustment before driving, etc.	
4	Driving	Operations and advice which are necessary for driving	
5	Interior features	Usage of the interior features, etc.	
6	Maintenance + Y \ _ and care	Caring for your vehicle and maintenance procedures	
7	When trouble Far	What to do in case of malfunction or emergency	
8	Vehicle specifications	Vehicle specifications, customizable features, etc.	
	Index	Search by symptom	
	ilidex	Search alphabetically	

г	. (
For your information8 Reading this manual14		2	Instrument cluster	
How	to search15			
	orial index16	2.	Instrument cluster	
1 1011	The mack manner of the second		Warning lights and	
1	For safety and security		indicators	120
			Gauges and meters	125
1-1.	For safe use		Multi-information display	129
	Before driving42		Fuel consumption	
	For safety drive44		information	138
	Seat belts46	3	Operation of	
	SRS airbags51		each component	
	Front passenger occupant			
	classification system64	3-1.	Key information	
	Airbag manual on-off	ולו	Keys	144
	system69	3-2.	Opening, closing and	
	Safety information for		locking the doors	
	children		Smart entry & start system	
	Child restraint systems72	*/\ω :	Wireless remote control	177
	Installing child restraints89		Doors	186
	Exhaust gas precautions 103	200	Trunk	191
1-2.	Theft deterrent system	3-3	. Adjusting the seats	
	Engine immobilizer system104		Front seats	198
	Double locking system111		Power rear seat	205
	Alarm112		Driving position memory	218
	Anti-theft device118		Rear seat position memory.	223
	7 THE CHERCAGO COMMISSION TO		Head restraints	225
		3-4.	Adjusting the steering wheel and mirrors	
			Steering wheel	228
			Inside rear view mirror	229
			Outside rear view mirrors	232

2

3-5.	Opening, closing the windows and moon roof		4-4.	Refueling
		224		Opening the fuel tank cap 305
	Power windows		4-5.	Using the driving support systems
,	D			Cruise control309
4	Driving			Dynamic radar cruise control313
4-1.	Before driving Driving the vehicle Cargo and luggage			Dynamic radar cruise control with full-speed range328
	Trailer towing	. 258		LKA
4-2 .	Driving procedures Engine (ignition) switch Automatic transmission (vehicles without paddle shift switches) Automatic transmission (vehicles with paddle shift switches) Turn signal lever Parking brake Brake Hold	259 264 269 278 279 282	۰ ۸۵ : OS	(Lane-Keeping Assist)344 Driving mode select switch354 Electronically modulated air suspension358 Driving assist systems360 PCS (Pre-Crash Safety system)368 BSM (Blind Spot Monitor)381 The Blind Spot Monitor function387 The RCTA function390
4-3.	Operating the lights and			Lexus night view393
	wipers Headlight switch AHS (Adaptive High-beam System) Fog light switch Windshield wipers and	291	4-6.	Driving tips Winter driving tips399 Eco-friendly driving tips403
	vviilustileiu wipers and			

washer......300 Headlight cleaner switch......304

5	nterior features	5-6.	Other interior features		
		Sun visors and vanity		147	
5-1.	Remote Touch screen		mirrors		
J -1.	Remote Touch406				
	12.3-inch display		Ashtrays		
5 2	Lexus Climate Concierge		Cigarette lighters		
J-Z.	-		Power outlets		
- 2	Lexus Climate Concierge 417		Heated steering wheel	4/0	
5-3.	Using the air conditioning system and defogger		Climate control seats/ seat heaters	478	
	Front automatic air		Armrest	483	
	conditioning system418		Retractable table	484	
	Rear air conditioning		Rear sunshade	486	
	system438	10	Rear door sunshades	490	
	Rear window and outside rear view mirror		Trunk storage extension	494	
	defoggers445		Coat hooks	496	
	Windshield wiper de-icer446		Assist grips	497	
5-4	Using the interior lights	* \ \\ \alpha :	Garage door opener	498	
•	Interior lights list447		ERA-GLONASS	504	
	• Interior lights448				
	• Personal lights449	005	.com		
5-5.	Using the storage features				
	List of storage features 451				
	• Glove box453				
	• Coin holder454				
	• Door pockets454				
	• Cup holders455				
	• Console box457				
	 Cool box/auxiliary 				
	box459				
	• Auxiliary boxes462				
	Trunk features465				

Maintenance and care	7 W	hen trouble arises
Maintenance and care Cleaning and protecting the vehicle exterior	E If	ssential information mergency flashers594 your vehicle has to be stopped in an emergency595
Maintenance Maintenance		teps to take in an emergency
requirements517 Scheduled maintenance520		your vehicle needs to be towed596
Do-it-yourself maintenance Do-it-yourself service precautions	9 F	you think something is wrong
Engine compartment539 Tires556	<u>ال</u> : ۵۸ -	a warning message is displayed614
Tire inflation pressure	OS 1 1 1 1 1 1 1 1 1	you have a flat tire
	Maintenance and care Cleaning and protecting the vehicle exterior	Maintenance and care 7-1. E Cleaning and protecting the vehicle exterior

8 Vehicle specifications

8-1. Specifications

Maintenance data
(fuel, oil level, etc.).....648
Fuel information.......665

8-2. Customization

Customizable features667

Index

What to do if...
(Troubleshooting)......682
Alphabetical index......688

تلفن شبانه روزی: ۱۳۵۰ ۱۳۹۸ - ۲۱ م

FarmaSOS.com

For information regarding the equipment listed below, refer to "Navigation and Multimedia System Owner's Manual" or "Navigation System Owner's Manual".

- Navigation system
- · Audio/visual system
- Rear seat entertainment system
- Lexus parking assist-sensor
- · Lexus parking assist monitor



تلفن شبانه روزی: ۱۳۰۵ مراکب ۲۱-۸۸۸۶۲ ۲۲

FarmaSOS.com

For your information

Main Owner's Manual

Please note that this manual applies to all models and explains all equipment, including options. Therefore, you may find some explanations for equipment not installed on your vehicle.

All specifications provided in this manual are current at the time of printing. However, because of the Lexus policy of continual product improvement, we reserve the right to make changes at any time without notice.

Depending on specifications, the vehicle shown in the illustrations may differ from your vehicle in terms of color and equipment.

Noise from under vehicle after turning off the engine (for Korea)

Approximately five hours after the engine is turned off, you may hear sound coming from under the vehicle for several minutes. This is the sound of a fuel evaporation leakage check and, it does not indicate a malfunction.

Accessories, spare parts and modification of your Lexus

A wide variety of non-genuine spare parts and accessories for Lexus vehicles are currently available in the market. Using these spare parts and accessories which are not genuine Lexus products may adversely affect the safety of your vehicle, even though these parts may be approved by certain authorities in your country. Toyota Motor Corporation therefore cannot accept any liability or guarantee spare parts and accessories which are not genuine Lexus products, nor for replacement or installation involving such parts.

This vehicle should not be modified with non-genuine Lexus products. Modification with non-genuine Lexus products could affect its performance, safety or durability, and may even violate governmental regulations. In addition, damage or performance problems resulting from the modification may not be covered under warranty.

Installation of an RF-transmitter system

The installation of an RF-transmitter system in your vehicle could affect electronic systems such as:

- Multiport fuel injection system/sequential multiport fuel injection system
- Dynamic radar cruise control with full-speed range
- Dynamic radar cruise control system
- Cruise control system
- Anti-lock brake system
- Vehicle dynamics integrated management
- SRS airbag system
- Seat belt pretensioner system

Be sure to check with your Lexus dealer for precautionary measures or special instructions regarding installation of an RF-transmitter system.

Further information regarding frequency bands, power levels, antenna positions and installation provisions for the installation of RF-transmitters, is available on request at your Lexus dealer.



FarmaSOS.com

Vehicle data recordings

Your Lexus is equipped with several sophisticated computers that will record certain data, such as:

- · Engine speed
- Accelerator status
- Brake status
- Vehicle speed
- Shift position

The recorded data varies according to the vehicle grade level and options with which it is equipped. Furthermore, these computers do not record conversations, sounds or pictures.

Data usage

Lexus may use the data recorded in these computers to diagnose malfunctions, conduct research and development, and improve quality.

Lexus will not disclose the recorded data to a third party except:

- With the consent of the vehicle owner or with the consent of the lessee if the vehicle is leased
- In response to an official request by the police, a court of law or a government agency
- For use by Lexus in a law suit
- For research purposes where the data is not tied to a specific vehicle or vehicle owner

FarmaSOS.com

Event data recorder (except for Korea)

This vehicle is equipped with an event data recorder (EDR). The main purpose of an EDR is to record, in certain crash or near crash-like situations, such as an airbag deployment or hitting a road obstacle, data that will assist in understanding how a vehicle's systems performed. The EDR is designed to record data related to vehicle dynamics and safety systems for a short period of time, typically 30 seconds or less. However, data may not be recorded depending on the severity and type of a crash.

The EDR in this vehicle is designed to record such data as:

- How various systems in your vehicle were operating;
- How far (if at all) the driver was depressing the accelerator and/or brake pedal; and.
- How fast the vehicle was traveling.

These data can help provide a better understanding of the circumstances in which crashes and injuries occur.

NOTE: EDR data are recorded by your vehicle only if a non-trivial crash situation occurs; no data are recorded by the EDR under normal driving conditions and no personal data (e.g., name, gender, age, and crash location) are recorded. However, other parties, such as law enforcement, could combine the EDR data with the type of personally identifying data routinely acquired during a crash investigation.

To read data recorded by an EDR, special equipment is required, and access to the vehicle or the EDR is needed. In addition to the vehicle manufacturer, other parties, such as law enforcement, that have the special equipment, can read the information if they have access to the vehicle or the EDR.

Disclosure of the FDR data

Lexus will not disclose the data recorded in an EDR to a third party except when:

- An agreement from the vehicle's owner (or the lessee for a leased vehicle) is obtained
- In response to an official request by the police, a court of law or a government agency
- For use by Lexus in a law suit

However, if necessary, Lexus may:

- Use the data for research on vehicle safety performance
- Disclose the data to a third party for research purposes without disclosing information about the specific vehicle or vehicle owner

Event data recorder (for Korea)

This vehicle is equipped with an event data recorder (EDR). The main purpose of an EDR is to record, in certain crash or near crash-like situations, such as an airbag deployment or hitting a road obstacle, data that will assist in understanding how a vehicle's systems performed. The EDR is designed to record data related to vehicle dynamics and safety systems for a short period of time, typically 30 seconds or less. However, data may not be recorded depending on the severity and type of a crash.

The EDR in this vehicle is designed to record such data as:

- How various safety systems in your vehicle (e.g., the airbags, seat belts and ABS)
 were operating;
- How far (if at all) the driver was depressing the accelerator and/or brake pedal; and.
- · How fast the vehicle was traveling.

The EDR can help provide a better understanding of the circumstances in which crashes and injuries occur.

NOTE: EDR data are recorded by your vehicle only if a nontrivial crash situation occurs; no data are recorded by the EDR under normal driving conditions and no personal data (e.g., name, gender, age, and crash location) are recorded. However, personal data acquired during a defect investigation could be used to manage crash records. A person provided by the Minister of Land Infrastructure and Transport could extract and analyze EDR data for official purpose.

To read data recorded by an EDR, special equipment is required, and access to the vehicle or the EDR is needed. In addition to the vehicle manufacturer, other parties, such as law enforcement, that have the special equipment, can read the information if they have access to the vehicle or the EDR.

Scrapping of your Lexus

The SRS airbag and seat belt pretensioner devices in your Lexus contain explosive chemicals. If the vehicle is scrapped with the airbags and seat belt pretensioners left as they are, this may cause an accident such as fire. Be sure to have the systems of the SRS airbag and seat belt pretensioner removed and disposed of by a qualified service shop or by your Lexus dealer before you scrap your vehicle.

A CAUTION

■General precautions while driving

Driving under the influence: Never drive your vehicle when under the influence of alcohol or drugs that have impaired your ability to operate your vehicle. Alcohol and certain drugs delay reaction time, impair judgment and reduce coordination, which could lead to an accident that could result in death or serious injury.

Defensive driving: Always drive defensively. Anticipate mistakes that other drivers or pedestrians might make and be ready to avoid accidents.

Driver distraction: Always give your full attention to driving. Anything that distracts the driver, such as adjusting controls, talking on a cellular phone or reading can result in a collision with resulting death or serious injury to you, your occupants or others.

■ General precaution regarding children's safety

Never leave children unattended in the vehicle, and never allow children to have or use the key.

Children may be able to start the vehicle or shift the vehicle into neutral. There is also a danger that children may injure themselves by playing with the windows, the moon roof, or other features of the vehicle. In addition, heat build-up or extremely cold temperatures inside the vehicle can be fatal to children.

Reading this manual

A CAUTION:


Explains something that, if not obeyed, could cause death or serious injury to people.

NOTICE:


Explains something that, if not obeyed, could cause damage to or a malfunction in the vehicle or its equipment.

123 ··· Indicates operating or working procedures. Follow the steps in numerical order.

- Indicates the action (pushing, turning, etc.) used to operate switches and other devices.
- □ Indicates the outcome of an operation (e.g. a lid opens).




- Indicates the component or position being explained.
- Means "Do not", "Do not do this", or "Do not let this happen".



How to search

- Searching by name
 - Alphabetical index......P. 688



- Searching by installation position
 - Pictorial indexP. 16






- Searching by symptom or sound
 - What to do if... (Troubleshooting)..........P. 682

FarmaS0




- Searching by title
 - Table of contentsP. 2



Pictorial index

Exterior




The shape of the headlights may differ depending on the grade, etc. $(\rightarrow P.371)$

1 Doors Locking/unlocking Opening/closing the door glasses Locking/unlocking by using the mechanical key Warning lights/warning messages	P. 155, 177 1P. 236 P. 631
2 Trunk Opening from inside the cabin Opening from outside Opening by using the mechanical key Warning lights/warning messages	P. 191 P. 155, 177 P. 633
3 Outside rear view mirrors Adjusting the mirror angle. Folding the mirrors. Driving position memory. Defogging the mirrors.	P. 232 P. 233 P. 218

Precautions again To prevent freezi Precautions again 5 Fuel filler door Refueling method Fuel type/fuel tan 6 Tires Tire size/inflation Winter tires/tire of Checking/rotation Coping with flat to 7 Hood Opening Engine compartn Engine oil Coping with over	nst winter season ing (windshield wiper de-icer)* inst car wash d. ink capacity in pressure chain on/tire pressure warning system* ires. inent cover.	P. 399 P. 446 P. 512 P. 305 P. 305 P. 652 P. 652 P. 556 P. 660, 662 P. 399 P. 556 P. 618 P. 536 P. 536 P. 536 P. 541 P. 653 P. 641
Light bulbs of the ext (Replacing method: P. 5	terior lights for driving لفن شبانه روزی 584, Watts: P. 664)	;
 9 Front fog lights/r 10 Turn signal lights 11 Tail lights 12 Stop lights Hill-start assist co 	t position lights/daytime running lights rear fog lights*	P. 298 P. 278 P. 285 P. 360
	ever to R	P. 264, 269

^{*:} If equipped

Instrument panel (Left-hand drive vehicles)





4	Multi-information display	
	When the warning messages are displayed	
5	Parking brake switches Applying/releasing Precautions against winter season Warning buzzer/message.	P. 279 P. 400
6	Turn signal leverHeadlight switchHeadlights/front position lights/tail lights/daytime	P. 285
	running lights	P. 285 P. 298
7	Windshield wiper and washer switch Usage Adding washer fluid Warning messages	P. 300 P. 300 P. 553
8	Emergency flasher switch	P. 594
9 (10)	Trunk opener	P.19 ²
	Hood lock release lever	
~	Tilt and telescopic steering control switch. Adjustment Driving position memory	P. 228 P. 228
13)	Air conditioning system Usage Rear window defogger	P. 418
14)	Audio system*2 Audio system*2 Hands-free system*2	
(15)	Trunk opener main switch	P. 192

*1: If equipped

^{*2:} Refer to "Navigation and Multimedia System Owner's Manual" or "Navigation System Owner's Manual".


Instrument panel switches (Left-hand drive vehicles)






*1: If equipped

^{*2:} Refer to "Navigation and Multimedia System Owner's Manual" or "Navigation System Owner's Manual".




(1)	Audio remote control switches	
2	Paddle shift switches *2	P. 271
\sim	Back switch*1	
4	Talk switch*1	
5	Phone switches * 1 / / / ۶۲ + / ۵ : تلفن شبانه روزی: "DISP" button.	
7	Vehicle-to-vehicle distance button*2	P. 316, 331
	Cruise control switch masos.com Cruise control *2	P. 309
	Cruise control switch masos.com Cruise control *2	P. 309
		P. 309 P. 313
8	Cruise control switch Cruise control*2 Dynamic radar cruise control*2	P. 309 P. 313 P. 328




^{*1:} Refer to "Navigation and Multimedia System Owner's Manual" or "Navigation System Owner's Manual". *2: If equipped

^{*3:} Location of the switches varies according to the vehicle grade level.

Front interior (Left-hand drive vehicles)





(1)	Interior light	P. 448
	Personal lights	
	Moon roof switches*1	
3	"SOS" button*1	P. 504
4	Intrusion sensor and tilt sensor cancel switch*1	P. 115
5	Vanity mirrors	P. 467
6	Sun visors*3	P. 467
	Inside rear view mirror	
8	Garage door opener switches *1	P. 498
9	Auxiliary box	P. 462

*1: If equipped FarmaSOS.com


- *2: Refer to "Navigation and Multimedia System Owner's Manual" or "Navigation System Owner's Manual".
- *3: Except for Taiwan: NEVER use a rearward facing child restraint on a seat protected by an ACTIVE AIRBAG in front of it, DEATH or SERIOUS INJURY to the CHILD can occur. (→P.98)

For Taiwan: DO NOT carry baby, infant and children on the front passenger seat. Except for the front passenger seat, NEVER use a rearward facing child restraint on a seat protected by an ACTIVE AIRBAG in front of it, DEATH or SERIOUS INJURY to the CHILD can occur. (\rightarrow P. 101)





■ Instrument panel (Right-hand drive vehicles)





() Engine switch	
Starting the engine/changing the modes	P. 259
Emergency stop of the engine	P. 595
When the engine will not start	P. 627
When the engine will not start	P. 614
(2) Shift lever	P. 264, 269
Changing the shift position	
Precautions against towing	P. 596
When the shift lever does not move	
③ Meters	P. 125
Reading the meters/adjusting the instrument panel light	
Warning lights/indicator lights	
When the warning lights come on	

4	Multi-information display	P.129
5	Parking brake switches Applying/releasing Precautions against winter season Warning buzzer/message.	P. 279 P. 279 P. 400
6	Turn signal lever	P. 285
7	Windshield wiper and washer switch Usage Adding washer fluid Warning messages	P. 300
8	Emergency flasher switch	P. 594
9 10	Trunk opener	P.19 ²
11)	Hood lock release lever	P. 536
12	Tilt and telescopic steering control switch	P. 228
13)	Air conditioning system Usage Rear window defogger	P. 418
14)	Audio system* Audio system* Hands-free system*	
(15)	Trunk opener main switch	P. 192

^{*:} Refer to "Navigation and Multimedia System Owner's Manual" or "Navigation System Owner's Manual".

■ Instrument panel switches (Right-hand drive vehicles)






*1: If equipped

^{*2:} Refer to "Navigation and Multimedia System Owner's Manual" or "Navigation System Owner's Manual".


6 "DISP" button......



7 Vehicle-to-vehicle distance button*2 P. 316

Dynamic radar cruise control*2 P. 313 9 Brake hold switch......P. 282


8 Cruise control switch SOS. Com
Cruise control *2




^{*1:} Refer to "Navigation and Multimedia System Owner's Manual" or "Navigation System Owner's Manual". *2: If equipped

^{*3:} Location of the switches varies according to the vehicle grade level.

Front Interior (Right-hand drive vehicles)





FarmaSOS.com

- *1: If equipped
- *2: Refer to "Navigation and Multimedia System Owner's Manual" or "Navigation System Owner's Manual".
- *3: NEVER use a rearward facing child restraint on a seat protected by an ACTIVE AIRBAG in front of it, DEATH or SERIOUS INJURY to the CHILD can occur. (→P. 98)



Rear interior (5-seat models)



8)	Auxiliary boxes*1Ashtrays*1	P. 462
	Power window switches	
10	Seat belts	P. 46
11)	Cup holders	P. 455
12)	Pelvic support seat switches*1	P. 210
	Rear seat relaxation system/	
	pelvic support seat switches *1	P. 210, 212
13)	Auxiliary box	P. 462
•	Rear seat entertainment system controller*1,2 Headphone jacks*1,2	
14)	Cool box/auxiliary box*1	P. 459
•	Cool box/auxiliary box*1	P. 494
	6/19 9/19 11/41	



FarmaSOS.com

*1: If equipped

^{*2:} Refer to "Navigation and Multimedia System Owner's Manual" or "Navigation System Owner's Manual".

Rear interior (4-seat models)




8	Auxiliary boxes*1Ashtrays*1	P. 462 P. 470
	Power window switches	
10	Retractable table	P. 484
(11)	Seat belts	P. 46
(12)	Cup holders	P. 455
(13)	Rear seat console Rear seat relaxation system/pelvic support seat controller Rear seat entertainment system controller*2 Cigarette lighter*1	P. 471 P. 473
(14) (15)	Auxiliary box	
	Headphone jacks ** ** ** ** ** ** ** ***	


FarmaSOS.com

*1: If equipped

^{*2:} Refer to "Navigation and Multimedia System Owner's Manual" or "Navigation System Owner's Manual".

Rear interior switches





- 1 Rear seat entertainment system display*3
- 2 Rear seat entertainment system player *1,3 تلفن شبانه روزگرهٔ* Disc slot*3
- 3 Auxiliary box FarmaSOS.com P. 462
- (5) A/V input port (VTR and HDMI port)*1,3

*1: If equipped

 $^{^{\}star 2}$: Location of the switches varies according to the vehicle grade level.

^{*3:} Refer to "Navigation and Multimedia System Owner's Manual" or "Navigation System Owner's Manual".



تلفن شبانه روزى: ۱۵۸۰۲۹۸۸۸–۲۲


For sate use
Before driving42
For safety drive44
Seat belts46
SRS airbags51
Front passenger occupant classification system
Airbag manual on-off system69
Safety information for children71
Child restraint systems72
Installing child restraints89
Exhaust gas precautions103
Theft deterrent system
Engine immobilizer system 104
Double locking system 111
Alarm112
Anti-theft device118

Before driving

Floor mat


Use only floor mats designed specifically for vehicles of the same model and model year as your vehicle. Fix them securely in place onto the carpet.

1 Insert the retaining hooks (clips) into the floor mat eyelets.



- 2 Turn the upper knob of each retaining hook (clip) to secure the floor mats in place.
 - *: Always align the \(\triangle \text{ marks}

tion.



The shape of the retaining hooks (clips) may differ from that shown in the illustra-



Observe the following precautions.

Failure to do so may cause the driver's floor mat to slip, possibly interfering with the pedals while driving. An unexpectedly high speed may result or it may become difficult to stop the vehicle. This could lead to an accident, resulting in death or serious injury.

■ When installing the driver's floor mat

- Do not use floor mats designed for other models or different model year vehicles. even if they are Lexus Genuine floor mats.
- Only use floor mats designed for the driver's seat.
- Always install the floor mat securely using the retaining hooks (clips) provided.
- Do not use two or more floor mats on top of each other.
- Do not place the floor mat bottom-side up or upside-down.

■ Before driving

- Check that the floor mat is securely fixed in the correct place with all the provided retaining hooks (clips). Be especially careful to perform this check after cleaning the floor.
- With the engine stopped and the shift lever in P, fully depress each pedal to the floor to make sure it does not interfere with the floor mat.



For safety drive

For safe driving, adjust the seat and mirror to an appropriate position before driving.

Correct driving posture

- 1 Adjust the angle of the seatback so that you are sitting straight up and so that you do not have to lean forward to steer. (→P. 198)
- ② Adjust the seat so that you can depress the pedals fully and so that your arms bend slightly at the elbow when gripping the steering wheel. (→P. 198)



- 3 Lock the head restraint in place with the center of the head \(\lambda\) : "
 restraint closest to the top of your ears. (→P. 225)
- (4) Wear the seat belt correctly. OS. COM (→P. 46)

Correct use of the seat belts

Make sure that all occupants are wearing their seat belts before driving the vehicle. $(\rightarrow P. 46)$

Use a child restraint system appropriate for the child until the child becomes large enough to properly wear the vehicle's seat belt. $(\rightarrow P. 72)$

Adjusting the mirrors

Make sure that you can see backward clearly by adjusting the inside and outside rear view mirrors properly. $(\rightarrow P. 229, 232)$

A CAUTION

Observe the following precautions.

Failure to do so may result in death or serious injury.

- Do not adjust the position of the driver's seat while driving.
 Doing so could cause the driver to lose control of the vehicle.
- Do not place a cushion between the driver or passenger and the seatback.
 A cushion may prevent correct posture from being achieved, and reduce the effectiveness of the seat belt and head restraint.
- Do not place anything under the front seats.
 Objects placed under the front seats may become jammed in the seat tracks and stop the seat from locking in place. This may lead to an accident and the adjustment mechanism may also be damaged.
- Always observe the legal speed limit when driving on public roads.
- When driving over long distances, take regular breaks before you start to feel tired.

Also, if you feel tired or sleepy while driving, do not force yourself to continue driving and take a break immediately.

Seat belts

Make sure that all occupants are wearing their seat belts before driving the vehicle

Correct use of the seat belts

- Extend the shoulder belt so that it comes fully over the shoulder, but does not come into contact with the neck or slide off the shoulder.
- Position the lap belt as low as possible over the hips.
- Adjust the position of the seatback. Sit up straight and well back in the seat.




● Do not twist the seat belt.

* ۱ー۸۸۶۲ + ۸۵ :روزی: تلفن شبانه روزی:

Fastening and releasing the seat belt

- 1) To fasten the seat belt, push the plate into the buckle until a click sound is heard.
- 2 To release the seat belt, press the release button.

If the seat belt cannot be pulled out of the retractor, firmly pull the belt and release it.




Adjusting the seat belt shoulder anchor height (front seats)

- 1) Moves the seat belt shoulder anchor up
- 2) Moves the seat belt shoulder anchor down



Seat belt comfort guide (outer rear seats)

For children or smaller-than-average people, slide the seat belt comfort guide forward so that the shoulder belt does not sit close to the person's neck.




Seat belt pretensioners (front and outer rear seats)

The pretensioners help the seat belts to quickly restrain the occupants by retracting the seat belts when the vehicle is subjected to certain types of severe frontal collision.

The front seat belt pretensioners also activate when the vehicle is subjected to certain types of severe side collision.

The pretensioners do not activate in the event of a minor frontal impact, a minor side impact, a rear impact or a vehicle rollover.



Pre-crash seat belts (front seats of vehicles with pre-crash safety system)

If the system determines that a collision is unavoidable, the front seat belts will retract before the collision. $(\rightarrow P. 368)$

■ Child seat belt usage

The seat belts of your vehicle were principally designed for persons of adult size.

- Use a child restraint system appropriate for the child, until the child becomes large enough to properly wear the vehicle's seat belt. $(\rightarrow P.72)$
- When the child becomes large enough to properly wear the vehicle's seat belt, follow the instructions regarding seat belt usage. (→P. 46)

■ Automatic adjustment of the seat belt shoulder anchor height (front seats)

A desired seat belt shoulder anchor height can be entered to memory and recalled automatically by the driving position memory and seat position memory. $(\rightarrow P. 218)$

■ Emergency locking retractor (ELR)

The retractor will lock the belt during a sudden stop or on impact. It may also lock if you lean forward too quickly. A slow, easy motion will allow the belt to extend so that you can move around fully.

■ Replacing the belt after the pretensioner has been activated

If the vehicle is involved in multiple collisions, the pretensioner will activate for the first collision, but will not activate for the second or subsequent collisions.

■ Seat belt regulations

If seat belt regulations exist in the country where you reside, please contact your Lexus dealer for seat belt replacement or installation.

Observe the following precautions to reduce the risk of injury in the event of sudden braking, sudden swerving or an accident.

Failure to do so may cause death or serious injury.

■ Wearing a seat belt

- Ensure that all passengers wear a seat belt.
- Always wear a seat belt properly.
- Each seat belt should be used by one person only. Do not use a seat belt for more than one person at once, including children.
- Lexus recommends that children be seated in the rear seat and always use a seat belt and/or an appropriate child restraint system.
- To achieve a proper seating position, do not recline the seat more than necessary. The seat belt is most effective when the occupants are sitting up straight and well back in the seats.
- Do not wear the shoulder belt under your arm.
- Always wear your seat belt low and snug across your hips

■Pregnant women

Obtain medical advice and wear the seat belt in the proper way. $(\rightarrow P.46)$

Women who are pregnant should position the lap belt as low as possible over the hips in the same manner as other occupants, extending the shoulder belt completely over the shoulder and avoiding belt contact with the rounding of the abdominal area.

If the seat belt is not worn properly, not only the pregnant woman, but also the fetus could suffer death or serious injury as a result of sudden braking or a collision.



■ People suffering illness

Obtain medical advice and wear the seat belt in the proper way. $(\rightarrow P. 46)$

■ When children are in the vehicle

Do not allow children to play with the seat belt. If the seat belt becomes twisted around a child's neck, it may lead to choking or other serious injuries that could result in death.

If this occurs and the buckle cannot be unfastened, scissors should be used to cut the belt.

■ Seat belt pretensioners

- Vehicles with front passenger occupant classification system: Do not place anything, such as a cushion, on the front passenger's seat. Doing so will disperse the passenger's weight, which prevents the sensor from detecting the passenger's weight properly. As a result, the seat belt pretensioner for the front passenger's seat may not activate in the event of a collision.
- If the pretensioner has activated, the SRS warning light will come on. In that case, the seat belt cannot be used again and must be replaced at your Lexus dealer.

Adjustable shoulder anchor


Always make sure the shoulder belt is positioned across the center of your shoulder. The belt should be kept away from your neck, but not falling off your shoulder. Failure to do so could reduce the amount of protection in an accident and cause death or serious injuries in the event of a sudden stop, sudden swerve or accident. $(\rightarrow P.47)$

■ Seat belt damage and wear

- Do not damage the seat belts by allowing the belt, plate, or buckle to be jammed in the door.
- Inspect the seat belt system periodically. Check for cuts, fraying, and loose parts.
 Do not use a damaged seat belt until it is replaced. Damaged seat belts cannot protect an occupant from death or serious injury.
- Ensure that the belt and plate are locked and the belt is not twisted.
 If the seat belt does not function correctly, immediately contact your Lexus dealer.
- Replace the seat assembly, including the belts, if your vehicle has been involved in a serious accident, even if there is no obvious damage.
- Do not attempt to install, remove, modify, disassemble or dispose of the seat belts.
 Have any necessary repairs carried out by your Lexus dealer. Inappropriate handling may lead to incorrect operation.

SRS airbags

The SRS airbags inflate when the vehicle is subjected to certain types of severe impacts that may cause significant injury to the occupants. They work together with the seat belts to help reduce the risk of death or serious injury.




SRS front airbags

- 1 SRS driver airbag/front passenger airbag
 Can help protect the head and chest of the driver and front passenger from impact with interior components
- ② SRS knee airbags Can help provide driver and front passenger protection

SRS side and curtain shield airbags

- 3 SRS front side airbags
 Can help protect the torso of the front seat occupants
- 4 SRS rear side airbags (if equipped)


 Can help protect the torso of occupants in the rear outer seats
- (5) SRS curtain shield airbags Can help protect primarily the head of occupants in the outer seats



6 SRS seat cushion airbag (relaxation seat)
Can help restrain the relaxation seat occupant

تلفن شبانه روزی: ۱۵۸۰۲۹۸۸ - ۲۱

SRS airbag system components



- 1) Front passenger's seat belt buckle switch
- 2 Front passenger occupant classification system (ECU and sensors) (if equipped)
- (3) Side impact sensors (front)
- (4) "PASSENGER AIR BAG" indicator light (if equipped)/"AIR BAG ON" and "AIR BAG OFF" indicator light (if equipped)
- (5) Airbag manual on-off switch (if equipped)
- (6) Front passenger airbag
- (7) Curtain shield airbags
- (8) Knee airbags
- (9) Front side airbags
- Active head restraints (if equipped)

- 11 SRS warning light
- (12) Rear side airbags (if equipped)
- (3) Seat belt pretensioners and force limiters
- (14) Driver airbag
- (if equipped)
- (16) Side impact sensors (rear)
- Side impact sensors (front door) (if equipped)
- (18) Driver's seat belt buckle switch
- (19) Driver's seat position sensor
- ② Airbag sensor assembly
- (21) Front impact sensors

The main SRS airbag system components are shown above. The SRS airbag system is controlled by the airbag sensor assembly. As the airbags deploy, a chemical reaction in the inflators quickly fills the airbags with non-toxic gas to help restrain the motion of the occupants.

A CAUTION

SRS airbag precautions

Observe the following precautions regarding the SRS airbags. Failure to do so may cause death or serious injury.

- The driver and all passengers in the vehicle must wear their seat belts properly. The SRS airbags are supplemental devices to be used with the seat belts.
- The SRS driver airbag deploys with considerable force, and can cause death or serious injury especially if the driver is very close to the airbag.

Since the risk zone for the driver's airbag is the first 50 - 75 mm (2 - 3 in.) of inflation, placing yourself 250 mm (10 in.) from your driver airbag provides you with a clear margin of safety. This distance is measured from the center of the steering wheel to your breastbone. If you sit less than 250 mm (10 in.) away now, you can change your driving position in several ways:

- · Move your seat to the rear as far as you can while still reaching the pedals تلفن شبانه روزی: ۱۰۸۸ comfortably.
- · Slightly recline the back of the seat. Although vehicle designs vary, many drivers can achieve the 250 mm (10 in.) distance, even with the driver seat all the way forward, simply by reclining the back of the seat somewhat. If reclining the back of your seat makes it hard to see the road, raise yourself by using a firm, non-slippery cushion, or raise the seat if your vehicle has that feature.
- If your steering wheel is adjustable, tilt it downward. This points the airbag toward your chest instead of your head and neck.

The seat should be adjusted as recommended above, while still maintaining control of the foot pedals, steering wheel, and your view of the instrument panel controls.

■SRS airbag precautions

- The SRS front passenger airbag also deploys with considerable force, and can cause death or serious injury especially if the front passenger is very close to the airbag. The front passenger seat should be as far from the airbag as possible with the seatback adjusted, so the front passenger sits upright.
- Improperly seated and/or restrained infants and children can be killed or seriously injured by a deploying airbag. An infant or child who is too small to use a seat belt should be properly secured using a child restraint system. Lexus strongly recommends that all infants and children be placed in the rear seats of the vehicle and properly restrained. The rear seats are safer for infants and children than the front passenger seat. (→P. 72)
- Do not sit on the edge of the seat or lean against the dashboard.



- Do not allow a child to stand in front of the SRS front passenger airbag unit or sit on the knees of a front passenger.
- Do not allow the front seat occupants to hold items on their knees.



 Do not lean against the door, the roof side rail or the front, side and rear pillars.



■SRS airbag precautions

 Do not allow anyone to kneel on the passenger seats toward the door or put their head or hands outside the vehicle.



 Do not attach anything to or lean anything against areas such as the dashboard, steering wheel pad and lower portion of the instrument panel.

These items can become projectiles when the SRS driver, front passenger and knee airbags deploy.



· ۲1-1115





- Do not hang coat hangers or hard objects on the coat hooks. All of these items could become projectiles and may cause death or serious injury, should the SRS curtain shield airbags deploy.
- If a vinyl cover is put on the area where the SRS knee airbag will deploy, be sure to remove it.

■SRS airbag precautions

- Do not use seat accessories which cover the parts where the SRS side airbags and SRS seat cushion airbag inflate as they may interfere with inflation of the SRS airbags. Such accessories may prevent the side airbags and SRS seat cushion airbag from activating correctly, disable the system or cause the side airbags and SRS seat cushion airbag to inflate accidentally, resulting in death or serious injury.
- Do not strike or apply significant levels of force to the area of the SRS airbag components. Doing so can cause the SRS airbags to malfunction.
- Do not touch any of the component parts immediately after the SRS airbags have deployed (inflated) as they may be hot.
- If breathing becomes difficult after the SRS airbags have deployed, open a door or window to allow fresh air in, or leave the vehicle if it is safe to do so. Wash off any residue as soon as possible to prevent skin irritation.
- If the areas where the SRS airbags are stored, such as the steering wheel pad and front and rear pillar garnishes are damaged or cracked, have them replaced by your Lexus dealer.
- Vehicles with front passenger occupant classification system: Do not place anything, such as a cushion, on the front passenger's seat. Doing so will disperse the passenger's weight, which prevents the sensor from detecting the passenger's weight properly. As a result, the SRS front passenger airbag may not deploy in the event of a collision.

■ Modification and disposal of SRS airbag system components

Do not dispose of your vehicle or perform any of the following modifications without consulting your Lexus dealer. The SRS airbags may malfunction or deploy (inflate) accidentally, causing death or serious injury.

- Installation, removal, disassembly and repair of the SRS airbags
- Repairs, modifications, removal or replacement of the steering wheel, instrument panel, dashboard, seats or seat upholstery, front, side and rear pillars or roof side rails
- Repairs or modifications of the front fender, front bumper, or side of the occupant compartment
- Installation of a grille guard (bull bars, kangaroo bar, etc.), snow plows, winches
- Modifications to the vehicle's suspension system
- Installation of electronic devices such as mobile two-way radios (RF-transmitter) and CD players

تلفن شبانه روزی: ۱-۸۸۸۶۲ ۲۸ ا

■ If the SRS airbags deploy (inflate)

- Slight abrasions, burns, bruising etc., may be sustained from SRS airbags, due to the extremely high speed deployment (inflation) by hot gases.
- A loud noise and white powder will be emitted.
- Parts of the airbag module (steering wheel hub, airbag cover and inflator) as well as
 the seats, parts of the front and rear pillars, and roof side rails, may be hot for several minutes. The airbag itself may also be hot.
- The windshield may crack.
- Vehicles with ERA-GLONASS: If the SRS airbags deploy, the system is designed to send an emergency call* to the Public Safety Answering Point (PSAP), notifying them of the vehicle's location (without needing to push the "SOS" button) and an agent will attempt to speak with the occupants to ascertain the level of emergency and assistance required. If the occupants are unable to communicate, the agent automatically treats the call as an emergency and helps to dispatch the necessary emergency services. (→P. 504)
 - *: In some cases, the call cannot be made. $(\rightarrow P.506)$

■ SRS airbag deployment conditions (SRS front airbags and SRS seat cushion airbag)

• The SRS front airbags and SRS seat cushion airbag will deploy in the event of an impact that exceeds the set threshold level (the level of force corresponding to an approximately 20 - 30 km/h [12 - 18 mph] frontal collision with a fixed wall that does not move or deform).

However, this threshold velocity will be considerably higher in the following situations:


- If the vehicle strikes an object, such as a parked vehicle or sign pole, which can move or deform on impact
- If the vehicle is involved in an underride collision, such as a collision in which the front of the vehicle "underrides", or goes under, the bed of a truck
- Depending on the type of collision, it is possible that only the seat belt pretensioners will activate.
- Front passenger occupant classification system: The SRS front passenger airbag will not activate, if there is no passenger sitting in the front passenger seat. However, the SRS front passenger airbag may deploy, if luggage is put in the seat, or the seat belt is fastened, even if the seat is unoccupied.

SRS airbag deployment conditions (SRS side and curtain shield airbags)

- The SRS side and curtain shield airbags will deploy in the event of an impact that exceeds the set threshold level (the level of force corresponding to the impact force produced by an approximately 1500 kg [3300 lb.] vehicle colliding with the vehicle cabin from a direction perpendicular to the vehicle orientation at an approximate speed of 20-30 km/h[12-18 mph]).
- The SRS side and curtain shield airbags will deploy in the event of a severe frontal collision.
- Conditions under which the SRS airbags may deploy (inflate), other than a collision (SRS front airbags, SRS curtain shield airbag and SRS seat cushion airbag)

The SRS front airbags, SRS curtain shield airbag and SRS seat cushion airbag may also deploy if a serious impact occurs to the underside of your vehicle. Some examples are shown in the illustration.


- Hitting a curb, edge of pavement or hard surface
- Falling into or jumping over a deep hole
- Landing hard or falling



Types of collisions that may not deploy the SRS airbags (SRS front airbags and SRS seat cushion airbag)

The SRS front airbags and SRS seat cushion airbag do not generally inflate if the vehicle is involved in a side or rear collision, if it rolls over, or if it is involved in a low-speed frontal collision. But, whenever a collision of any type causes sufficient forward deceleration of the vehicle, deployment of the SRS front airbags and SRS seat cushion airbag may occur.


- Collision from the side
- Collision from the rear
- Vehicle rollover



■ Types of collisions that may not deploy the SRS airbags (SRS side and curtain shield airbags)


The SRS side and curtain shield airbags may not activate if the vehicle is subjected to a collision from the side at certain angles, or a collision to the side of the vehicle body other than the passenger compartment.

- Collision from the side to the vehicle body other than the passenger compartment
- Collision from the side at an angle




The SRS side airbags do not generally inflate if the vehicle is involved in a frontal or rear collision, if it rolls over, or if it is involved in a low-speed side collision.

- Collision from the front
- Collision from the rear
- Vehicle rollover



The SRS curtain shield airbags do not generally inflate if the vehicle is involved in a rear collision, if it rolls over, or if it is involved in a low-speed side or low-speed frontal collision.


- Collision from the rear
- Vehicle rollover




■ When to contact your Lexus dealer

In the following cases, the vehicle will require inspection and/or repair. Contact your Lexus dealer as soon as possible.


- Any of the SRS airbags have been inflated.
- The front of the vehicle is damaged or deformed, or was involved in an accident that was not severe enough to cause the SRS airbags to inflate.



 A portion of a door is damaged or deformed, or the vehicle was involved in an accident that was not severe enough to cause the SRS side and curtain shield airbags to inflate.




 The pad section of the steering wheel, dashboard near the front passenger airbag or lower portion of the instrument panel is scratched, cracked, or otherwise damaged.




 Relaxation seat: The seat cushion surface is scratched, cracked, or otherwise damaged.



 The surface of the seats with the side airbag is scratched, cracked, or otherwise damaged.



 The portion of the front pillars, rear pillars or roof side rail garnishes (padding) containing the curtain shield airbags inside is scratched, cracked, or otherwise damaged.






تلفن شبانه روزی: ۱۳۵۰ ۱۳۹۸ - ۲۱ م

Front passenger occupant classification system^{*}

Your vehicle is equipped with a front passenger occupant classification system. This system detects the conditions of the front passenger seat and activates or deactivates the devices for the front passenger.



- (2) SRS warning light
- (3) "AIR BAG OFF" indicator light
- (4) "AIR BAG ON" indicator light

Condition and operation in the front passenger occupant classification system

■ Adult*1

Indicator/	"AIR BAG ON" and "AIR BAG OFF" indicator lights	"AIR BAG ON"
warning light	SRS warning light	Off
	Front passenger's seat belt reminder light	Flashing*2
	Front passenger airbag	
	Side airbag on the right side passenger seats	Activated
Devices	Curtain shield airbag in the front passenger side	
	Front passenger knee airbag Front passenger's seat belt pretensioner	
	Active head restraints	

■ Child*3 or child restraint system*4

Indicator/	"AIR BAG ON" and "AIR BAG OFF" indicator lights	"AIR BAG OFF"* ⁵
warning light	SRS warning light. COM	Off
	Front passenger's seat belt reminder light	Flashing*2
	Front passenger airbag	Deactivated
	Side airbag on the right side passenger seats	Activated
Devices	Curtain shield airbag in the front passenger side	Activated
	Front passenger knee airbag	Deactivated
	Front passenger's seat belt pretensioner	Activated
	Active head restraints	/ totivated

■ Unoccupied

Indicator/	"AIR BAG ON" and "AIR BAG OFF" indicator lights	Not illuminated
warning light	SRS warning light	Off
	Front passenger's seat belt reminder light	Oπ
	Front passenger airbag	Deactivated
	Side airbag on the right side passenger seats	Activated
Devices	Curtain shield airbag in the front passenger side	Activated
	Front passenger knee airbag	Deactivated
	Front passenger's seat belt pretensioner	Deactivated or activated*6
	Active head restraints	Deactivated

■ There is a malfunction in the system

Indicator/	"AIR BAG ON" and "AIR BAG OFF" hindicator lights روزی "تلفن شبانه روزی"	"AIR BAG OFF"
warning light	SRS warning light	On
	Front passenger's seat belt reminder light	Off
	Front passenger airbag	Deactivated
	Side airbag on the right side passenger seats	Activated
Devices	Curtain shield airbag in the front passenger side	Activated
	Front passenger knee airbag	Deactivated
	Front passenger's seat belt pretensioner	Activated
	Active head restraints	Activated

- *1: The system judges a person of adult size as an adult. When a smaller adult sits in the front passenger seat, the system may recognize him/her as a child depending on his/her physique and posture.
- *2: In the event the front passenger does not wear a seat belt
- *3: When a larger child who has outgrown a child restraint system sits in the front passenger seat, the system may recognize him/her as an adult depending on his/her physique or posture.
- *4: Never install a rear-facing child restraint system on the front passenger seat. A forward-facing child restraint system should only be installed on the front passenger seat when it is unavoidable. (→P. 72)
- *5: In case the indicator light is not illuminated, consult this manual on how to install the child restraint system properly. $(\rightarrow P. 89)$
- *6: Activated only in cases of side impact

■ Front passenger occupant classification system precautions

Observe the following precautions regarding the front passenger occupant classification system.

Failure to do so may cause death or serious injury.

- Wear the seat belt properly.
- Make sure the front passenger's seat belt plate has not been left inserted into the buckle before someone sits in the front passenger seat.
- Do not put weight on the front passenger seat by putting your hands or feet on the front passenger seat seatback from the rear passenger seat.
- Do not let a rear passenger lift the front passenger seat with their feet or press on the seatback with their legs.
- Do not put objects under the front passenger seat.

Front passenger occupant classification system precautions

- Do not recline the front passenger seatback so far that it touches a rear seat. This may cause the "AIR BAG OFF" indicator light to be illuminated, which indicates that the passenger's airbags will not deploy in the event of a severe accident. If the seatback touches the rear seat, return the seatback to a position where it does not touch the rear seat. Keep the front passenger seatback as upright as possible when the vehicle is moving. Reclining the seatback excessively may lessen the effectiveness of the seat belt system.
- If an adult sits in the front passenger seat, the "AIR BAG ON" indicator light is illuminated. If the "AIR BAG OFF" indicator is illuminated, ask the passenger to sit up straight, well back in the seat, feet on the floor, and with the seat belt worn correctly. If the "AIR BAG OFF" indicator still remains illuminated, either ask the passenger to move to the rear seat, or if that is not possible, move the front passenger seat fully rearward.
- When it is unavoidable to install a forward-facing child restraint system on the front passenger seat, install the child restraint system on the front passenger seat in the proper order. (→P. 89)
- Do not modify or remove the front seats.
- Do not kick the front passenger seat or subject it to severe impact. Otherwise, the SRS warning light may come on to indicate a malfunction of the detection system. In this case, contact your Lexus dealer immediately.
- Child restraint systems installed on the rear seat should not contact the front seat-backs.
- Do not use a seat accessory, such as a cushion or seat cover, that covers the seat cushion surface.
- Do not modify or replace the upholstery of the front seat.

Airbag manual on-off system*


This system deactivates the front passenger airbag, front passenger knee airbag.

Only deactivate the airbags when using a child restraint system on the front passenger seat.

1 "PASSENGER AIR BAG" indicator

This indicator light turns on when the airbag system is on (only when the engine switch is in IGNITION ON mode).

2 Airbag manual on-off switch



Deactivating the front seat passenger airbag and front passenger knee airbag

Insert the mechanical key into the cylinder and rotate to the "OFF" position.

The "OFF" indicator light turns on (only when the engine switch is in IGNITION ON mode).



■ "PASSENGER AIR BAG" indicator information

If any of the following problems occur, it is possible that there is a malfunction in the system. Have the vehicle inspected by Lexus dealer.

- Neither "ON" nor "OFF" comes on.
- The indicator light does not change when the airbag manual on-off switch is switched to "ON" or "OFF".

A CAUTION

■ When installing a child restraint system

For safety reasons, always install a child restraint system in a rear seat. In the event that the rear seat cannot be used, the front seat can be used as long as the airbag manual on-off system is set to off.

If the airbag manual on-off system is left on, the strong impact of the airbag deployment (inflation) may cause serious injury or even death.

■ When a child restraint system is not installed on the front passenger seat

Ensure that the airbag manual on-off system is set to on.

If it is left off, the airbag may not deploy in the event of an accident, which may result in serious injury or even death.

Safety information for children

Observe the following precautions when children are in the vehicle.

Use a child restraint system appropriate for the child, until the child becomes large enough to properly wear the vehicle's seat belt.

- It is recommended that children sit in the rear seats to avoid accidental contact with the shift lever, wiper switch etc.
- Use the rear door child-protector lock or the window lock switch to avoid children opening the door while driving or operating the power window accidentally.
- Do not let small children operate equipment which may catch or pinch body parts, such as the power window, hood, trunk, seats etc.

A CAUTION

Never leave children unattended in the vehicle, and never allow children to have or use the key.

Children may be able to start the vehicle or shift the vehicle into neutral. There is also a danger that children may injure themselves by playing with the cigarette lighter, the windows, the moon roof, or other features of the vehicle. In addition, heat build-up or extremely cold temperatures inside the vehicle can be fatal to children.

Child restraint systems

Lexus strongly urges the use of child restraint systems.

Points to remember

Studies have shown that installing a child restraint on a rear seat is much safer than installing one on the front passenger seat.

- Choose a child restraint system that suits your vehicle and is appropriate to the age and size of the child.
- For installation details, follow the instructions provided with the child restraint system.

General installation instructions are provided in this manual. $(\rightarrow P. 89)$

- If child restraint system regulations exist in the country where you reside, please contact your Lexus dealer for the child restraint system installation.
- Lexus recommends that you use a child restraint system which conforms to the regulation ECE No.44.

Types of child restraints

Child restraint systems are classified into the following 5 groups according to the regulation ECE No.44:

Group 0: Up to 10 kg (22 lb.) (0 - 9 months)

Group 0⁺: Up to 13 kg (28 lb.) (0 - 2 years)

9 to 18 kg (20 to 39 lb.) (9 months - 4 years) Group I:

Group II: 15 to 25 kg (34 to 55 lb.) (4 years - 7 years)

Group III: 22 to 36 kg (49 to 79 lb.) (6 years - 12 years)


In this owner's manual, the following 3 types of popular child restraint systems that can be secured with the seat belts are explained:

► Baby seat (infant seat) ◆

► Child seat (convertible seat)

Equal to Group O and O+ of ECE Equal to Group O+ and I of ECE No.44

No.44





▶ Junior seat (booster seat)

Equal to Group II and III of ECE No.44



Child restraint system suitability for various seating positions (for Russia and South Africa)

Information provided in the table shows your child restraint system suitability for various seating positions.

Seating	Front passenger seat		Rear seat		
position	Airbag manual on-off switch		Right- hand	Left- hand	Center
Mass groups	ON	OFF	nanu	nanu	
0 Up to 10 kg (22 lb.) (0 - 9 months)	X Never put	U*1,L*1	U*2,L*2	U* ² ,L* ²	Х
0 ⁺ Up to 13 kg (28 lb.) (0 - 2 years)	X Never put	U*1,L*1	U*2,L*2	U* ² ,L* ²	Х
1 9 to 18 kg (20 to 39 lb.) (9 months - 4 years)	Rear- facing — X Never put Forward- facing — UF*1	۰ ۸ù*!	تلفن ب <mark>ُل</mark> ِانه	U* ²	Х
II, III 15 to 36 kg (34 to 79 lb.) (4 - 12 years)	UF* ¹	U* ¹	U* ²	U* ²	Х

Key of letters inserted in the above table:

- U: Suitable for "universal" category child restraint systems approved for use in this mass group.
- UF: Suitable for forward-facing "universal" category child restraint systems approved for use in this mass group.
- L: Suitable for child restraint systems shown in the child restraint system list.
- X: Not suitable seat position for children in this mass group.
- *1: Adjust the front seatback to the most upright position. Move the front seat to the rearmost position.

If the head restraint interferes with your child restraint system, and the head restraint can be removed, remove the head restraint.

If the passenger seat is equipped with a vertical height adjuster, it must be placed in the upper most position.

Follow these procedures:

- For installing a baby seat with support base
 If the baby seat interferes with the seatback when latching the baby seat into the support base, adjust the seatback rearward until there is no interference.
- For installing a forward-facing child seat
 If there is gap between the child seat and the seatback, tilt the seatback rearward until good contact is achieved.
 If the seat belt shoulder anchor is ahead of the child seat belt guide, move the seat cushion forward.
- For installing a junior seat
 If the child in your child restraint system is in a very upright position, adjust the seatback to the most comfortable position.

 If the seat belt shoulder anchor is ahead of the child seat belt guide, move the seat cushion forward.
- *2: If the ottoman interferes with your child restraint system and the child restraint system cannot be installed correctly, move the rear seat to the rearmost position and stow the ottoman.

If the head restraint interferes with your child restraint system, and the head restraint can be removed, remove the head restraint.

The child restraint system mentioned in the table may not be available outside of the EU area.

Other child restraint system which is different from the system mentioned in the table can be used, but the suitability of the systems must be carefully checked with the child restraint system manufacturer concerned and the seller of those seats.

Child restraint system list

Mass groups	Child restraint systems	Category
0 Up to 10 kg (22 lb.) (0 - 9 months)	LEXUS G 0+, BABYSAFE PLUS with SEAT BELT FIXATION, BASE PLATFORM	Semi-universal
0 ⁺ Up to 13 kg (28 lb.) (0 - 2 years)	LEXUS G 0+, BABYSAFE PLUS with SEAT BELT FIXATION, BASE PLATFORM	Semi-universal



Child restraint system suitability for various seating positions (for Taiwan and Malaysia)

Information provided in the table shows your child restraint system suitability for various seating positions.

► For Taiwan

Seating		Rear seat		
position Mass groups	Front passenger seat	Right- hand	Left- hand	Center
0 Up to 10 kg (22 lb.) (0 - 9 months)	X Never put	U*2,L*2	U*2,L*2	Х
0 ⁺ Up to 13 kg (28 lb.) (0 - 2 years)	X Never put	U*2,L*2	U* ² ,L* ²	Х
1 9 to 18 kg (20 to 39 lb.) (9 months - 4 years)	X Never put -۸۸۸۶۲ + ۸۵	U*2 فن شبانه ر	U* ²	Х
II, III 15 to 36 kg (34 to 79 lb.) (4 - 12 years)	X	U*2	U* ²	Х

▶ For Malaysia

Seating		Rear seat			
position Mass groups	Front passenger seat	Right- hand	Left- hand	Center	
0 Up to 10 kg (22 lb.) (0 - 9 months)	X Never put	U*2,L*2	U*2,L*2	Х	
0+ Up to 13 kg (28 lb.) (0 - 2 years)	X Never put	U*2,L*2	U*2,L*2	Х	
I 9 to 18 kg (20 to 39 lb.) (9 months - 4 years)	Rear-facing— X Never put Forward-facing— UF*1	U*2	U* ²	Х	
II, III 15 to 36 kg (34 to 79 lb.) (4 - 12 years)	UF*1	U*2	U*2	Х	

Key of letters inserted in the above table:

- U: Suitable for "universal" category child restraint systems approved for use in this mass group.
- UF: Suitable for forward-facing "universal" category child restraint systems approved for use in this mass group.
- L: Suitable for child restraint systems shown in the child restraint system list.
- X: Not suitable seat position for children in this mass group.
- *1: Adjust the front seatback to the most upright position. Move the front seat to the rearmost position.

If the head restraint interferes with your child restraint system, and the head restraint can be removed, remove the head restraint.

If the passenger seat is equipped with a vertical height adjuster, it must be placed in the upper most position.

Follow these procedures:

- For installing a baby seat with support base
 If the baby seat interferes with the seatback when latching the baby seat into the support base, adjust the seatback rearward until there is no interference.
- For installing a forward-facing child seat
 If there is gap between the child seat and the seatback, tilt the seatback rearward until good contact is achieved.
 If the seat belt shoulder anchor is ahead of the child seat belt guide, move the seat cushion forward.
- For installing a junior seat
 If the child in your child restraint system is in a very upright position, adjust the seatback to the most comfortable position.

 If the seat belt shoulder anchor is ahead of the child seat belt guide, move the seat cushion forward.
- *2: If the ottoman interferes with your child restraint system and the child restraint system cannot be installed correctly, move the rear seat to the rearmost position and stow the ottoman.

If the head restraint interferes with your child restraint system, and the head restraint can be removed, remove the head restraint.

The child restraint system mentioned in the table may not be available outside of the EU area.

Other child restraint system which is different from the system mentioned in the table can be used, but the suitability of the systems must be carefully checked with the child restraint system manufacturer concerned and the seller of those seats.

Child restraint system list

Mass groups	Child restraint systems	Category
0 Up to 10 kg (22 lb.) (0 - 9 months)	LEXUS G 0+, BABYSAFE PLUS with SEAT BELT FIXATION, BASE PLATFORM	Semi-universal
0 ⁺ Up to 13 kg (28 lb.) (0 - 2 years)	LEXUS G 0+, BABYSAFE PLUS with SEAT BELT FIXATION, BASE PLATFORM	Semi-universal



Child restraint system suitability for various seating positions (with ISOFIX rigid anchors) (for Russia, South Africa, Taiwan and Malaysia)

Information provided in the table shows your child restraint system suitability for various seating positions.

		-	Vehicle ISOFIX positions		
Mass groups	Size class	Fixture	Outboard rear seat		
			Right-hand	Left-hand	
Carrycot	F	ISO/L1	Х	Х	
Carrycot	G	ISO/L2	Х	Х	
0 Up to 10 kg (22 lb.) (0 - 9 months)	6 5)	ISO/R1	1 L*	IL*	
0 ⁺ Up to 13 kg (28 lb.) (0 - 2 years)	Е	ISO/R1	IL*	IL*	
	D	ISO/R2	IL*	IL*	
	-///6/ +	الله ISO/R3	*_آلفن ش	IL*	
Fall 9 to 18 kg (20 to 39 lb.) (9 months - 4 years)	D	ISO/R2	Х	Х	
	rmaS	ISO/R3	mX	Х	
	В	ISO/F2	IUF*, IL*	IUF*, IL*	
	B1	ISO/F2X	IUF*, IL*	IUF*, IL*	
	Α	ISO/F3	IUF*, IL*	IUF*, IL*	

Key of letters inserted in the above table:

IUF: Suitable for ISOFIX forward-facing child restraint systems of universal category approved for use in this mass group.

IL: Suitable for child restraint systems shown in the ISOFIX child restraint system list.

When using a "LEXUS MINI" or "LEXUS MIDI", adjust the support leg and ISOFIX connectors as follows:

- 1 Lock the ISOFIX connectors where numbers 3 and 4 and 5 can be seen.
- 2 Lock the support leg where 4th hole can be seen.



- X: ISOFIX position not suitable for ISOFIX child restraint systems in this mass group and/or this size class.
- *: If the ottoman interferes with your child restraint system and the child restraint system cannot be installed correctly, move the rear seat to the rearmost position and stow the ottoman.

If the head restraint interferes with your child restraint system, and the head restraint can be removed, remove the head restraint.

The child restraint system mentioned in the table may not be available outside of the EU area.

Other child restraint systems different from the systems mentioned in the table can be used, but the suitability of the systems must be carefully checked with the child restraint system manufacturer and retailer.

ISOFIX child restraint system list

Mass groups	Size class	Fixture	ISOFIX child restraint systems	Category
0 Up to 10 kg (22 lb.)	Е	ISO/R1	LEXUS MINI	Semi-universal
(0 - 9 months)	Е	ISO/R1	LEXUS MIDI	Semi-universal
	∮ E	ISO/R1	LEXUS MINI	Semi-universal
6	(GE 9)	ISO/R1	LEXUS MIDI	Semi-universal
0 ⁺ Up to 13 kg (28 lb.) (0 - 2 years)	D	ISO/R2	LEXUS MINI	Semi-universal
	D	روزی: SO/R2	LEXUS MIDI	Semi-universal
	ırınas	ISO/R3	LEXUS OMINI	Semi-universal
	С	ISO/R3	LEXUS MIDI	Semi-universal
 9 to 18 kg (20 to 39 lb.) (9 months - 4 years)	В	ISO/F2	LEXUS MIDI	Semi-universal
	B1	ISO/F2X	LEXUS MIDI	Semi-universal
	А	ISO/F3	LEXUS MIDI	Semi-universal

■ When installing a child restraint system on the front passenger seat (except for Taiwan)

When you have to use a child restraint system on the front passenger seat, adjust the following:

- The seatback to the most upright position
- The seat cushion to the highest position
- The seat to the rearmost position



■ Selecting an appropriate child restraint system

- Use a child restraint system appropriate for the child until the child becomes large enough to properly wear the vehicle's seat belt.
- If the child is too large for a child restraint system, sit the child on a rear seat and use the vehicle's seat belt. $(\rightarrow P.46)$

A CAUTION

■ Using a child restraint system

The use of a child restraint system not suitable for the vehicle may not properly secure the infant or child. It may result in death or serious injury (in the event of sudden braking or an accident).



■ Child restraint precautions (except for Taiwan)

- For effective protection in automobile accidents and sudden stops, a child must be properly restrained, using a seat belt or child restraint system depending on the age and size of the child. Holding a child in your arms is not a substitute for a child restraint system. In an accident, the child can be crushed against the windshield, or between you and the vehicle's interior.
- Lexus strongly urges the use of a proper child restraint system that conforms to the size of the child, installed on the rear seat. According to accident statistics, the child is safer when properly restrained in the rear seat than in the front seat.
- Vehicles without airbag manual on-off switch (except for Korea): Never install a rear-facing child restraint system on the front passenger seat. In the event of an accident, the force of the rapid inflation of the front passenger airbag can cause death or serious injury to the child if the rear-facing child restraint system is installed on the front passenger seat.

Vehicles with airbag manual on-off switch (except for Korea):

Never use a rear-facing child restraint system on the front passenger seat when the airbag manual on-off switch is on. $(\rightarrow P. 69)$

In the event of an accident, the force of the rapid inflation of the front passenger airbag can cause death or serious injury to the child.

Vehicles with front passenger occupant classification system (for Korea):

Never install a rear-facing child restraint system on the front passenger seat even if the "AIR BAG OFF" indicator light is illuminated.

In the event of an accident, the force of the rapid inflation of the front passenger airbag can cause death or serious injury to the child if the rear-facing child restraint system is installed on the front passenger seat.

• Vehicles without front passenger occupant classification system: A forward-facing child restraint system may be installed on the front passenger seat only when it is unavoidable. A child restraint system that requires a top strap should not be used in the front passenger seat since there is no top strap anchor for the front passenger seat. Adjust the seatback as upright as possible and always move the seat as far back as possible because the front passenger airbag could inflate with considerable speed and force. Otherwise, the child may be killed or seriously injured.

- Child restraint precautions (except for Taiwan)
 - Do not allow the child to lean his/her head or any part of his/her body against the door or the area of the seat, front and rear pillars or roof side rails from which the SRS side airbags or SRS curtain shield airbags deploy even if the child is seated in the child restraint system. It is dangerous if the SRS side airbags and curtain shield airbags inflate, and the impact could cause death or serious injury to the child.
 - Make sure you have complied with all installation instructions provided by the child restraint manufacturer and that the system is properly secured. If it is not secured properly, it may cause death or serious injury to the child in the event of a sudden stop or accident.



تلفن شبانه روزی: ۱۵۸۰۲۹۸۸ - ۲۱

■ Child restraint precautions (for Taiwan)

- For effective protection in automobile accidents and sudden stops, a child must be properly restrained, using a seat belt or child restraint system depending on the age and size of the child. Holding a child in your arms is not a substitute for a child restraint system. In an accident, the child can be crushed against the windshield, or between you and the vehicle's interior. This may cause death or serious injury to the child in the event of a sudden stop, sudden swerve or accident.
- Never install a child restraint system on the front passenger seat. In the event of an accident, the force of the rapid inflation of the front passenger airbag can cause death or serious injury to the child if the child restraint system is installed on the front passenger seat.
- Do not allow the child to lean his/her head or any part of his/her body against the door or the area of the seat, front, center and rear pillars or roof side rails from which the SRS side airbags or SRS curtain shield airbags deploy even if the child is seated in the child restraint system. It is dangerous if the SRS side airbags and curtain shield airbags inflate, and the impact could cause death or serious injury to the child.
- Make sure you have complied with all installation instructions provided by the child restraint manufacturer and that the system is properly secured. If it is not secured properly, it may cause death or serious injury to the child in the event of a sudden stop, sudden swerve or accident.

■ When children are in the vehicle

Do not allow children to play with the seat belt. If the seat belt becomes twisted around a child's neck, it may lead to choking or other serious injuries that could result in death.

If this occurs and the buckle cannot be unfastened, scissors should be used to cut the belt.

■ When the child restraint system is not in use

- Keep the child restraint system properly secured on the seat even if it is not in use.
 Do not store the child restraint system unsecured in the passenger compartment.
- If it is necessary to detach the child restraint system, remove it from the vehicle or store it securely in the trunk. This will prevent it from injuring passengers in the event of a sudden stop or accident.

امداد خودرو فارما

تلفن شبانه روزی: ۱۵۸۰۲۹۸۸ - ۲۱

Installing child restraints

Follow the child restraint system manufacturer's instructions. Firmly secure child restraints to the outer rear seats using a seat belt or ISOFIX rigid anchors. Attach the top strap when installing a child restraint.

Installation with a seat belt



ISOFIX rigid anchors (ISOFIX child restraint system)


Lower anchors are provided for the outer rear seats. (Buttons displaying the location of the anchors are attached to the seats.)



▶ 5-seat models

Anchor brackets (for top strap)


An anchor bracket is provided for each rear seat.



▶ 4-seat models

Anchor brackets (for top strap)

An anchor bracket is provided for each rear seat.



Before installing the child restraint system on an outer rear seat (power rear seat)


When using a child restraint system in an outer rear seat, adjust the following:

- The seat cushion to the fully rearward position
- The upper seatback to the rearmost position
- The head restraint to the lowest and rearmost position
- Relaxation seat: The seatback to the most upright position and ottoman (footrest) to the stowed position



Installing child restraints using a seat belt

- Rear-facing Baby seat (infant seat)/child seat (convertible seat)
 - 1 Place the child restraint system on the rear seat facing the rear of the vehicle.





Run the seat belt through the child restraint system and insert the plate into the buckle.

Make sure that the belt is not twisted.

Follow the directions given in the child restraint system installation manual and fix the child restraint system securely in place.

If your child restraint system is not equipped with a lock-off (a seat belt locking feature), secure the child restraint system using a locking clip.





After installing the child restraint system, rock it back and forth to ensure that it is installed securely.

■ Forward-facing—Child seat (convertible seat)

1 Place the child restraint system on the seat facing the front of the vehicle.




Run the seat belt through the child restraint system and insert the plate into the buckle.

Make sure that the belt is not twisted.

Follow the directions given in the child restraint system installation manual and fix the child restraint system securely in place.

If your child restraint system is not equipped with a lock-off (a seat belt locking feature), secure the child restraint system using a locking clip.





After installing the child restraint system, rock it back and forth to ensure that it is installed securely.

■ Junior seat (booster seat)

1 Place the child restraint system on the seat facing the front of the vehicle.




2 Sit the child in the child restraint system. Fit the seat belt to the child restraint system according to the manufacturer's instructions and insert the plate into the buckle. Make sure that the belt is not twisted.



Check that the shoulder belt is correctly positioned over the child's shoulder and that the lap belt is as △ دوزی: الفن شبانه روزی: المعنان المعنان


Removing a child restraint installed with a seat belt

Push the buckle release button and fully retract the seat belt.



Installation with ISOFIX rigid anchors (ISOFIX child restraint system)

1 Widen the gap between the seat cushion and seatback slightly.




Child restraint systems with a top strap

1 Secure the child restraint using a seat belt or ISOFIX rigid anchors and move the head restraint to the lowest position (outer rear seats) or fold the head restraint (rear center seat). (→P. 225)



2 Open the anchor bracket cover, latch the hook onto the anchor bracket and tighten the top strap.

Make sure the top strap is securely latched.



You need a locking clip to install the child restraint system. Follow the instructions provided by the manufacturer of the system. If your child restraint system does not provide a locking clip, you can purchase the following item from your Lexus dealer:

Locking clip for child restraint system (Part No. 73119-22010)

■ When installing a child restraint system (except for Taiwan)

Follow the directions given in the child restraint system installation manual and fix the child restraint system securely in place.

If the child restraint system is not correctly fixed in place, the child or other passengers may be seriously injured or even killed in the event of sudden braking or an accident.

• If the driver's seat interferes with the child restraint system and prevents it from being attached correctly, attach the child restraint system to the right-hand rear seat (lefthand drive vehicles) or the left-hand rear seat (right-hand drive vehicles).



 Adjust the front passenger seat or rear seats so that it does not interfere with the child restraint system.

تلفن شبانه روزی: ۱-۸۸۸۶۲ ۲۸ ا

■ When installing a child restraint system (except for Taiwan)

 Vehicles without airbag manual on-off switch (except for Korea):

Only put a forward-facing child restraint system on the front seat when unavoidable. When installing a forward-facing child restraint on the front passenger seat, move the seat as far back as possible. Failure to do so may result in death or serious injury if the airbags deploy (inflate).

Vehicles with airbag manual on-off switch (except for Korea):

When installing a forward-facing child restraint on the front passenger seat, move the seat as far back as possible. Failure to do so may result in death or serious injury if the airbags deploy (inflate).

Vehicles with front passenger occupant classification system (for Korea): Only put a forward-facing child seat on the

front seat when unavoidable. When installing a forward-facing child restraint on the front passenger seat, move the seat as far back as possible even if the "AIR BAG OFF" indicator light is illuminated. Failure to do so may result in death or serious injury if the airbags deploy (inflate).










■ When installing a child restraint system (except for Taiwan)


 Vehicles without airbag manual on-off switch (except for Korea): Never use a rear-facing child restraint system on the front passenger seat. The force of the rapid inflation of the front passenger airbag can cause death or serious injury to children in the event of an accident.



 Vehicles with airbag manual on-off switch (except for Korea): Never use a rear-facing child restraint system on the front passenger seat when the airbag manual on-off switch is on. The force of the rapid inflation of the front passenger

airbag can cause death or serious injury to children in the event of an accident. $(\rightarrow P. 69)$








• There is a label(s) on the passenger side sun visor, indicating it is forbidden to attach a rear-facing child restraint system to the front passenger seat.

Details of the label(s) are shown in the illustration below.



■ When installing a child restraint system (except for Taiwan)



CIVIIBA160

- If child restraint system regulations exist in the country where you reside, please contact your Lexus dealer for the child restraint system installation.
- When a junior (booster) seat is installed, always ensure that the shoulder belt is positioned across the center of the child's shoulder. The belt should be kept away from the child's neck, but not so that it could fall off the child's shoulder. Failing to do so may result in death or serious injury in the event of an accident or sudden braking.
- Ensure that the belt and plate are securely locked and the seat belt is not twisted.
- Shake the child restraint system left and right, and forward and backward to ensure that it has been securely installed.
- After securing a child restraint system, never adjust the seat.
- Follow all installation instructions provided by the child restraint system manufacturer.
- For Korea: When securing some types of child restraint systems in rear seats, it may not be possible to properly use the seat belts in positions next to the child restraint without interfering with it or affecting seat belt effectiveness. Be sure your seat belt fits snugly across your shoulder and low on your hips. If it does not, or if it interferes with the child restraint, move to a different position. Failure to do so may result in death or serious injury.

■ When installing a child restraint system (for Taiwan)

Follow the directions given in the child restraint system installation manual and fix the child restraint system securely in place.

If the child restraint system is not correctly fixed in place, the child or other passengers may be seriously injured or even killed in the event of a sudden braking, sudden swerving or an accident.

- If the driver's seat interferes with the child restraint system and prevents it from being attached correctly, attach the child restraint system to the right-hand rear seat.
- Adjust the front passenger seat so that it does not interfere with the child restraint system.



 Never use a child restraint system on the front passenger seat. The force of the rapid inflation of the front

passenger airbag can cause death or serious injury to children in the event of an accident.










- When installing a child restraint system (for Taiwan)
 - There is a label(s) on the passenger side sun visor, indicating it is forbidden to attach a child restraint system to the front passenger seat. Details of the label(s) are shown in the illustration below.





- "9L" in the illustration is not related to the contents of the warning label.
- If child restraint system regulations exist in the country where you reside, please contact your Lexus dealer for the child restraint system installation.
- When a junior (booster) seat is installed, always ensure that the shoulder belt is positioned across the center of the child's shoulder. The belt should be kept away from the child's neck, but not so that it could fall off the child's shoulder. Failing to do so may result in death or serious injury in the event of sudden braking, sudden swerving or an accident.
- Ensure that the belt and plate are securely locked and the seat belt is not twisted.
- Shake the child restraint system left and right, and forward and backward to ensure that it has been securely installed.
- After securing a child restraint system, never adjust the seat.
- Follow all installation instructions provided by the child restraint system manufacturer.

■ To correctly attach a child restraint system to the anchors

When using the lower anchors, be sure that there are no foreign objects around the anchors and that the seat belt is not caught behind the child restraint system. Make sure the child restraint system is securely attached, or it may cause death or serious injury to the child or other passengers in the event of sudden braking or an accident.



تلفن شبانه روزى: ۵۸+۲۹۸۸۸-۲۲

Exhaust gas precautions

Substances in the exhaust gases are harmful to the human body if inhaled.



A CAUTION

Exhaust gases include harmful carbon monoxide (CO), which is colorless and odorless. Observe the following precautions.

Failure to do so may cause exhaust gases enter the vehicle and may lead to an accident caused by light-headedness, or may lead to death or a serious health hazard.

Important points while driving

Keep the trunk lid closed.

If you smell exhaust gases in the vehicle even when the trunk lid is closed, open the windows and have the vehicle inspected at your Lexus dealer as soon as possible.

■ When parking

- If the vehicle is in a poorly ventilated area or a closed area, such as a garage, stop the engine.
- Do not leave the vehicle with the engine on for a long time. If such a situation cannot be avoided, park the vehicle in an open space and ensure that exhaust fumes do not enter the vehicle interior.
- Do not leave the engine running in an area with snow build-up, or where it is snowing. If snowbanks build up around the vehicle while the engine is running, exhaust gases may collect and enter the vehicle.

Exhaust pipe

The exhaust system needs to be checked periodically. If there is a hole or crack caused by corrosion, damage to a joint or abnormal exhaust noise, be sure to have the vehicle inspected and repaired by your Lexus dealer.

Engine immobilizer system

The vehicle's keys have built-in transponder chips that prevent the engine from starting if a key has not been previously registered in the vehicle's on-board computer.

Never leave the keys inside the vehicle when you leave the vehicle.

This system is designed to help prevent vehicle theft but does not guarantee absolute security against all vehicle thefts.

The indicator light flashes after the engine switch has been turned off to indicate that the system is operating.

The indicator light stops flashing after the engine switch has been turned to ACCESSORY or IGNI-TION ON mode to indicate that the system has been canceled.



■ System maintenance

The vehicle has a maintenance-free type engine immobilizer system.

- Conditions that may cause the system to malfunction
 - If the grip portion of the key is in contact with a metallic object
 - If the key is in close proximity to or touching a key to the security system (key with a built-in transponder chip) of another vehicle

■ Certifications for the engine immobilizer system

► For vehicles sold in Taiwan

經型式認證合格之低功率射頻電機,非經許可,公司、商號或使用者均不得擅 自變更頻率、加大功率或變更原設計之特性及功能。

低功率射頻電機之使用不得影響飛航安全及干擾合法通信;經發現有干擾現象 時, 應立即停用, 並改善至無干擾時方得繼續使用。

前項合法通信,指依電信法規定作業之無線電通信。

低功率射頻電機須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之 干擾。

► For vehicles sold in Brazil

Este equipamento está homologado pela ANATEL de acordo com os procedimentos regulamentados pela Resolução 242/2000 e atende aos requisitos técnicos aplicados.

Este equipamento opera em caráter secundário, isto é, não tem direito a proteção contra interferência prejudicial, mesmo de estações do mesmo tipo, e não pode causar interferência a sistemas operando em caráter primário.



► For vehicles sold in Korea



상호명/제조자 기자재의 명칭(모델명)

식별부호

: R-LPD1-04-0191

: Toyota Motor Corporation

: Shown on product./Japan

: 미약전파를 사용하는 무선설비의 기기(TMIMB-1)

► For vehicles sold in Singapore

Complies with IDA Standards DA101418

▶ For vehicles sold in Republic of Serbia

TOYOTA

TOYOTA MOTOR CORPORATION

	TA-CHO, TOYOTA, AICHI,	,471-8571, JAPAN TEL:+81-565-28-2121	
R&T	TE Declara	tion of Conformity	
We,			
Manufacturer's Name:	ГОҮОТА МОТОР	R CORPORATION	
Manufacturer's Address:	I, Toyota -cho, ∃	Toyota, Aichi, 471-8572, Japan	
hereby declare under our so	ole responsibility	that the product:	
Product Name: Immobiliz Product Model: TMIMB-1	er g	امداد حودر	
to which this declaration rel	ates is in confor	mity with the essential requirements and	
other relevant requirements	of the R&TTE D	Directive (1999/5/EC). The product is	
compliant with the following	standards and/	or other normative documents:	
+ 7	\-\\\\	تلفن شبانه روزی : ۸۵ + ۲	
-Health & safety require	ements:	EN 60950-1	
-EMC requirements		EN 301 489-01 & EN 301 489-03	
-Effective uses of radio	arma	EN 300 330-2	
Supplementary information:		1	
* CE mark		CE	
* Member states intended for use		EU and EFTA	
<u>Date:</u>	February 25, 2013		
Signature: Tetry Inotino		ing Irotuw	
	Tetsuya Matsı	uo	
	,		

Hereby, TOYOTA MOTOR CORPORATION, declares that this TMIMB-1 is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

TOYOTA MOTOR CORPORATION vakuuttaa täten että TMIMB-1 tyyppinen laite on direktiivin 1999/5/EY oleellisten vaatimusten ja sitä koskevien direktiivin muiden ehtojen mukainen.

Hierbij verklaart TOYOTA MOTOR CORPORATION dat het toestel TMIMB-1 in overeenstemming is met de essentiële eisen en de andere relevante bepalingen van richtlijn 1999/5/EG.

Par la présente TOYOTA MOTOR CORPORATION déclare que l'appareil TMIMB-1 est conforme aux exigences essentielles et aux autres dispositions pertinentes de la directive 1999/5/CE.

Härmed intygar TOYOTA MOTOR CORPORATION att denna TMIMB-1 står I överensstämmelse med de väsentliga egenskapskrav och övriga relevanta bestämmelser som framgår av direktiv 1999/5/EG.

Undertegnede TOYOTA MOTOR CORPORATION erklærer herved, at følgende udstyr TMIMB-1 overholder de væsentlige krav og øvrige relevante krav i direktiv 1999/5/EF.

Hiermit erklärt TOYOTA MOTOR CORPORATION, dass sich das Gerät TMIMB-1 in Übereinstimmung mit den grundlegenden Anforderungen und den übrigen einschlägigen Bestimmungen der Richtlinie 1999/5/EG befindet.

نلفن شبانه روز*ی:* **۱۸**

ΜΕ ΤΗΝ ΠΑΡΟΥΣΑ ΤΟΥΌΤΑ MOTOR CORPORATION ΔΗΛΩΝΕΙ ΟΤΙ ΤΜΙΜΒ-1 ΣΥΜΜΟΡΦΩΝΕΤΑΙ ΠΡΟΣ ΤΙΣ ΟΥΣΙΩΔΕΙΣ ΑΠΑΙΤΗΣΕΙΣ ΚΑΙ ΤΙΣ ΛΟΙΠΕΣ ΣΧΕΤΙΚΕΣ ΔΙΑΤΑΞΕΙΣ ΤΗΣ ΟΔΗΓΙΑΣ 1999/5/ΕΚ.

Con la presente TOYOTA MOTOR CORPORATION dichiara che questo TMIMB-1 è conforme ai requisiti essenziali ed alle altre disposizioni pertinenti stabilite dalla direttiva 1999/5/CF

Por medio de la presente TOYOTA MOTOR CORPORATION declara que el TMIMB-1 cumple con los requisitos esenciales y cualesquiera otras disposiciones aplicables o exigibles de la Directiva 1999/5/CE.

TOYOTA MOTOR CORPORATION declara que este TMIMB-1 está conforme com os requisitos essenciais e outras disposições da Directiva 1999/5/CE.

Hawnhekk, TOYOTA MOTOR CORPORATION, jiddikjara li dan TMIMB-1 jikkonforma mal-ħtiġijiet essenzjali u ma provvedimenti oħrajn relevanti li hemm fid-Dirrettiva 1999/5/EC.

Käesolevaga kinnitab TOYOTA MOTOR CORPORATION seadme TMIMB-1 vastavust direktiivi 1999/5/EÜ põhinõuetele ja nimetatud direktiivist tulenevatele teistele asjakohastele sätetele.

Alulírott, TOYOTA MOTOR CORPORATION nyilatkozom, hogy a TMIMB-1 megfelel a vonatkozó alapvető követelményeknek és az 1999/5/EC irányelv egyéb előírásainak.

TOYOTA MOTOR CORPORATION týmto vyhlasuje, že TMIMB-1 spĺňa základné požiadavky a všetky príslušné ustanovenia Smernice 1999/5/ES.

TOYOTA MOTOR CORPORATION tímto prohlašuje, že tento TMIMB-1 je ve shodě se základními požadavky a dalšími příslušnými ustanoveními směrnice 1999/5/ES.

TOYOTA MOTOR CORPORATION izjavlja, da je ta TMIMB-1 v skladu z bistvenimi zahtevami in ostalimi relevantnimi določili direktive 1999/5/ES.

Šiuo TOYOTA MOTOR CORPORATION deklaruoja, kad šis TMIMB-1 atitinka esminius reikalavimus ir kitas 1999/5/EB Direktyvos nuostatas.

Ar šo TOYOTA MOTOR CORPORATION deklarē, ka TMIMB-1 atbilst Direktīvas 1999/5/EK būtiskajām prasībām un citiem ar to saistītajiem noteikumiem.

Niniejszym TOYOTA MOTOR CORPORATION oświadcza, że TMIMB-1 jest zgodny z zasadniczymi wymogami oraz pozostałymi stosownymi postanowieniami Dyrektywy 1999/5/EC.

Hér með lýsir TOYOTA MOTOR CORPORATION yfir því að TMIMB-1 er í samræmi við grunnkröfur og aðrar kröfur, sem gerðar eru í tilskipun 1999/5/EC.

TOYOTA MOTOR CORPORATION erklærer herved at utstyret TMIMB-1 er i samsvar med de grunnleggende krav og øvrige relevante krav i direktiv 1999/5/EF.

С настоящето, TOYOTA MOTOR CORPORATION, декларира, че TMIMB-1 е в съответствие със съществените изисквания и другите приложими разпоредби на Директива 1999/5/EC.

Prin prezenta, TOYOTA MOTOR CORPORATION, declară că aparatul TMIMB-1 este in conformitate cu cerințele esențiale și cu alte prevederi pertinente ale Directivei 1999/5/CE.

Ovim, TOYOTA MOTOR CORPORATION, izjavljuje da ovaj TMIMB-1 je usklađen sa bitnim zahtjevima i drugim relevantnim odredbama Direktive 1999/5/EC.

Nepermjet kesaj, TOYOTA MOTOR CORPORATION, deklaroj qe ky TMIMB-1 eshte ne pajtim me kerkesat thelbesore dhe dispozitat e tjera perkatese te Direktives 1999/5/EC.

Ovim TOYOTA MOTOR CORPORATION, izjavljuje da je TMIMB-1 u sklau s bitnim zahtjevima i drugim relevantnim odredbama Direktive 1999/5/EC i Pravilnika o RiTT opremi (NN 25/2012).

Ovim, TOYOTA MOTOR CORPORATION, deklariše da je TMIMB-1 u skladu sa osnovnim zahtevima i ostalim relevantnim odredbama Direktive 1999/5/EC.

İşbu belge ile TOYOTA MOTOR CORPORATION, bu TMIMB-1 ürününün 1999/5/EC Yönetmeliği'nin temel gerekliliklerine ve diğer ilgili hükümlerine uygun olduğunu beyan eder.

امداد حودرو فارما

تلفن شبانه روزی: ۱۵۸۰۲۹۸۸ - ۲۱

► For vehicles sold in Dominican Republic

FCC ID: NI4TMIMB-1

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference; and (2) This device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

↑ NOTICE

■ To ensure the system operates correctly

Do not modify or remove the system. If modified or removed, the proper operation of the system cannot be guaranteed.

تلفن شیانه روزی: ۲۱-۸۸۸۶۲ + ۲۸ د

امداد ودرو فارما

Double locking system*

Unauthorized access to the vehicle is prevented by disabling the door unlocking function from both the interior and exterior of the vehicle.

Vehicles employing this system have labels on the window glass of both front doors.



Setting the double locking system

Turn the engine switch off, have all the passengers exit the vehicle and ensure that all the doors are closed.

Using the entry function:

Press the lock button on the outside door handle twice within 5 seconds.

Using the wireless remote control:

Press twice within 5 seconds.

Canceling the double locking system

Using the entry function: Hold the outside door handle.

Using the wireless remote control: Press 3



A CAUTION

■ Double locking system precaution

Never activate the double locking system when there are people in the vehicle because all the doors cannot be opened from inside the vehicle.

Alarm

The alarm

The alarm uses light and sound to give an alert when an intrusion is detected

The alarm is triggered in the following situations when the alarm is set:

- Vehicles without airbag manual on-off system: A locked door or trunk is unlocked or opened in any way other than using the entry function, wireless remote control or mechanical key. (The doors will lock again automatically.)
- Vehicles with airbag manual on-off system: A locked door or trunk is unlocked or opened in any way other than using the entry function or wireless remote control. (The doors will lock again automatically.)
- The hood is opened.
- The intrusion sensor detects something moving inside the vehicle. (An intruder gets in the vehicle.) (if equipped)
- The tilt sensor detects a change of vehicle inclination. (if equipped)

Setting the alarm system

Close the doors, trunk and hood, and lock all the doors using the entry function or wireless remote control. The system will be set automatically after 30 seconds.

Vehicles without airbag manual onoff system: The alarm can also be set using the mechanical key.

The indicator light changes from being on to flashing when the system is set.



Deactivating or stopping the alarm

Do one of the following to deactivate or stop the alarm:

- ▶ Vehicles without airbag manual on-off system
- Unlock the doors or open the trunk.
- Turn the engine switch to ACCESSORY or IGNITION ON mode, or start the engine. (The alarm will be deactivated or stopped after a few seconds.)
- ▶ Vehicles with airbag manual on-off system
- Unlock the doors or open the trunk using the entry function or wireless remote control.
- Start the engine. (The alarm will be deactivated or stopped after a few seconds.)

■ System maintenance

The vehicle has a maintenance-free type alarm system.

تلفن شبانه روزی: ﴿\ltems to check before locking the vehicle ...


To prevent unexpected triggering of the alarm and vehicle theft, make sure of the following:

- Nobody is in the vehicle.
- The windows and moon roof (if equipped) are closed before the alarm is set.
- No valuables or other personal items are left in the vehicle.

■ Triggering of the alarm

The alarm may be triggered in the following situations: (Stopping the alarm deactivates the alarm system.)

Vehicles with airbag manual on-off system: The doors or trunk are unlocked using the mechanical key.



 A person inside the vehicle opens a door, the trunk or hood.



• The battery is recharged or replaced when the vehicle is locked. (→P. 639)





■Alarm-operated door lock maSOS.com

- When the alarm is operating, the doors are locked automatically to prevent intruders.
- Do not leave the key inside the vehicle when the alarm is operating, and make sure
 the key is not inside the vehicle when recharging or replacing the battery.



■ To ensure the system operates correctly

Do not modify or remove the system. If modified or removed, the proper operation of the system cannot be guaranteed.

Intrusion sensor and tilt sensor (if equipped)

- The intrusion sensor detects intruders or movement in the vehicle.
- The tilt sensor detects changes in vehicle inclination, such as when the vehicle is towed away.

This system is designed to deter and prevent vehicle theft but does not guarantee absolute security against all intrusions.

■ Setting the intrusion sensor and tilt sensor

The intrusion sensor and tilt sensor will be set automatically when the alarm is set. $(\rightarrow P. 112)$


■ Canceling the intrusion sensor and tilt sensor

If you are leaving pets or other moving things inside the vehicle, make sure to stop the intrusion sensor and tilt sensor before setting the alarm, as they will respond to movement inside the vehicle.

- 1 Turn the engine switch off.
- 2 Press the intrusion sensor and tilt sensor cancel switch.

A message will be shown on the multi-information display in the instrument cluster.

Press the switch again to re-enable the intrusion sensor and tilt sensor.



■ Canceling and automatic re-enabling of the intrusion sensor and tilt sensor

- The alarm will still be set even when the intrusion sensor and tilt sensor are canceled.
- After the intrusion sensor and tilt sensor are canceled, pressing the engine switch
 or unlocking the doors using the entry function or wireless remote control will reenable the intrusion sensor and tilt sensor.
- The intrusion sensor and tilt sensor will automatically be re-enabled when the alarm system is deactivated.

■ Intrusion sensor detection considerations

The sensor may trigger the alarm in the following situations:

- A window or the moon roof is open. In this case, the sensor may detect the following:
 - Wind or the movement of objects such as leaves and insects inside the vehicle
 - Ultrasonic waves emitted from devices such as the intrusion sensors of other vehicles
 - The movement of people outside the vehicle
- Unstable items, such as dangling accessories or clothes hanging on the coat hooks, are in the vehicle.





- Places with extreme vibrations or noises, or situations in which the vehicle is subject to repeated impacts or vibrations:
 - When parked in a parking garage
 - · When the vehicle is transported by a ferry, trailer, train, etc.
 - · When ice adhering to the vehicle is removed
 - · When the vehicle is in an automatic or high-pressure car wash
 - When in a hail or lightning storm

■ Tilt sensor detection considerations

The sensor may trigger the alarm in the following situations:

- The vehicle is transported by a ferry, trailer, train, etc.
- The vehicle is parked in a parking garage.
- The vehicle is inside a car wash that moves the vehicle.
- Any of the tires loses air pressure.
- The vehicle is jacked up.
- An earthquake occurs or the road caves in.

№ NOTICE

■ To ensure the intrusion sensor functions correctly

 To ensure that the sensors operate properly, do not touch or cover them.



 Do not spray air fresheners or other products directly into the sensor holes.





 Installing accessories other than genuine Lexus parts or leaving objects between the driver's seat and front passenger's seat may reduce the detection performance.

Anti-theft device*

An agreement (activation) with a service provider is necessary for usage of the anti-theft device.

After making an agreement (activation), various services will be provided by the service provider, including receiving position data from your vehicle and preventing engine ignition.

The type of services provided may differ by service provider. For details, please contact a service provider.

■ Auxiliary battery

- The anti-theft device has a built-in auxiliary battery, which is used when the vehicle's battery is discharged or has been removed. Make sure that you replace the auxiliary battery in good time so that the anti-theft device can function properly in emergency situations.
- The replacement interval of the auxiliary battery will differ according to the environment in which it is used. The auxiliary battery has a minimum lifetime of 12 months in normal use conditions. Comply with the replacement interval outlined by your service provider.

■ Certifications for the anti-theft device

Este produto está homologado pela ANATEL, de acordo com os procedimentos regulamentados pela Resolução 242/2000, e atende aos requisitos técnicos aplicados.



Para maiores infomações, consulte o site da ANATEL - www.anatel.gov.br

2. Instrument cluster

Warning lights and	
indicators	.120
Gauges and meters	. 125
Multi-information display	129
Fuel consumption	
information	.138



تلفن شبانه روزی: ۱-۸۸۸۶۲ ۲۸ ا

Warning lights and indicators

The warning lights and indicators on the instrument cluster, center panel and outside rear view mirrors inform the driver of the status of the vehicle's various systems.

For the purpose of explanation, the following illustration displays all warning lights and indicators illuminated.

Instrument cluster



The units used on the speedometer may differ depending on the target region.


Center panel

- ► Vehicles with airbag manual on-off system
- ► Vehicles with front passenger occupant classification system





Outside rear view mirrors (vehicles with BSM)





تلفن شبانه روزی: ۱۵۸۰۲۹۸۸۸ - ۲۱

Warning lights

Warning lights inform the driver of malfunctions in the indicated vehicle's systems.



^{*1:} These lights come on when the engine switch is turned to IGNITION ON mode to indicate that a system check is being performed. They will go off after the engine is on, or after a few seconds. There may be a malfunction in a system if the lights do not come on, or go off. Have the vehicle inspected by your Lexus dealer.

^{*2:} The light flashes to indicate a malfunction.

Indicators

The indicators inform the driver of the operating state of the vehicle's various systems.



Turn signal indicator $(\to P.278)$



Brake hold operated indicator $(\rightarrow P. 282)$



Tail light indicator $(\to P.285)$



Cruise control "SFT" indicator $(\rightarrow P. 309, 313, 328)$



Headlight high beam indicator (\rightarrow P. 287)



Cruise control indicator $(\rightarrow P. 309, 313, 328)$



Adaptive High-beam System indicator $(\rightarrow P. 291)$



Radar cruise control indicator $(\rightarrow P. 313. 328)$



Front foa light indicator $(\to P.298)$



LKA (Lane-Keeping Assist) indicator $(\rightarrow P.344)$



Rear fog light indicator $(\to P.298)$



"HEIGHT HIGH" indicator $(\rightarrow P.358)$



Gear Shift Indicator $(\to P.273)$



Slip indicator (\rightarrow P. 362)



Snow mode indicator $(\rightarrow P. 266, 274)$



VSC (Vehicle Stability Control) OFF indicator $(\to P.363)$



Parking brake indicator $(\to P. 279)$



Pre-crash safety system warning light (\rightarrow P. 370)



Brake hold standby indicator $(\rightarrow P. 282)$



BSM (Blind Spot Monitor) outside rear view mirror indicators (\rightarrow P. 381)





"AIR BAG ON/ OFF" indicator $(\rightarrow P 64)$



"PASSENGER AIR BAG" indica $tor(\rightarrow P.69)$

(if equipped)

- *1: These lights come on when the engine switch is turned to IGNITION ON mode to indicate that a system check is being performed. They will go off after the engine is on, or after a few seconds. There may be a malfunction in a system if the lights do not come on, or go off. Have the vehicle inspected by your Lexus dealer.
- *2: The light flashes to indicate that the system is operating.
- *3: The light comes on when the system is turned off. The light flashes faster than usual to indicate that the system is operating.
- *4: In order to confirm operation, the BSM outside rear view mirror indicators illuminate in the following situations:
 - When the engine switch is turned to IGNITION ON mode while the BSM main switch is set to ON.
 - · When the BSM main switch is set to ON while the engine switch is in IGNI-TION ON mode.

If the system is functioning correctly, the BSM outside rear view mirror indicators will turn off after a few seconds.

If the BSM outside rear view mirror indicators do not illuminate or do not turn off, there may be a malfunction with the system.

If this occurs, have the vehicle inspected by your Lexus dealer.




A CAUTION

If a safety system warning light does not come on

Should a safety system light such as the ABS and SRS warning light not come on when you start the engine, this could mean that these systems are not available to help protect you in an accident, which could result in death or serious injury. Have the vehicle inspected by your Lexus dealer immediately if this occurs.

Gauges and meters



The units used on the speedometer may differ depending on the target region.

1 Engine coolant temperature gauge

Displays the engine coolant temperature

(2) Tachometer

الفن شان Displays the engine speed in revolutions per minute

(3) ECO lamp and SPORT lamp

Changes colors or brightness according to driving mode or way of driving $(\rightarrow P. 127)$

(4) Speedometer

Displays the vehicle speed

5 Fuel gauge

Displays the quantity of fuel remaining in the tank

- (6) Odometer/trip meter and trip meter reset switches
- 7 Multi-information display

Presents the driver with a variety of driving-related data (\rightarrow P. 129)

(8) Outside temperature

Displays the outside temperature within the range of -40°C (-40°F) to 50°C (122°F)

Odometer and trip meter display

Odometer:

Displays the total distance the vehicle has been driven

Trip meter:

Displays the distance the vehicle has been driven since the meter was last reset.

Trip meters "A" and "B" can be used to record and display different distances independently.


10 Shift position and shift range

Displays the selected shift position or selected shift range (\rightarrow P. 264, 269)

(11) Instrument panel light control switches

Changing the odometer and trip meter display


- 1) Switches the display
- 2 Resets the trip meter currently displayed to "0"



Instrument panel light control

The brightness of the instrument panel lights can be adjusted.

- (1) Darker
- 2 Brighter



■ The meters and display illuminate when

The engine switch is in IGNITION ON mode.

■ Instrument panel brightness adjustment

Meters:

The brightness level of the meters when the surroundings are bright (day mode) and dark (night mode) can be adjusted individually. However, when in day mode, adjusting the brightness level will also change the brightness level of night mode.

Clock, air conditioning temperature display and switch lights:

The brightness level of the clock, air conditioning temperature display and switch lights are linked with the brightness level of meter night mode.

■ Light dimmer control (Changing to night mode)

The brightness level of the meter, clock and air conditioning temperature display lights will change to night mode only when the surroundings are dark and the tail lights are on.

■ Automatic adjustment of the brightness level of the meters

The brightness level of the meters will be adjusted automatically according to the brightness of the surroundings detected by the light sensor. However, the brightness level of the meters will not be adjusted automatically in the following conditions.

- Day mode: When the brightness of the meter is adjusted to the brightest manually
- Night mode: When the brightness of the meter is adjusted to the brightest or darkest manually

■ ECO lamp and SPORT lamp

- When all of the following conditions are satisfied and Eco-friendly driving is being performed, ECO lamp (blue) will illuminate. (ECO lamp will become brighter the more Eco-friendly your driving is. Also, while the vehicle is stopped or the acceleration exceeds Zone of Eco driving, ECO lamp turns off. (→P.132) However, when Eco drive mode is selected, while the vehicle is stopped or the acceleration exceeds Zone of Eco driving, ECO lamp does not turn off.):
 - Driving with the shift lever in D.
 - Vehicles with paddle shift switches: Paddle shift switch is not operated.
 - Normal mode, comfort mode (if equipped) or Eco drive mode is selected, and snow mode is not in use.
 - The vehicle speed is approximately 130 km/h (80 mph) or below.
- When sport mode is selected, SPORT lamp (red) will illuminate.

Outside temperature display

In the following situations, the correct outside temperature may not be displayed, or the display may take longer than normal to change.

- When stopped, or driving at low speeds (less than 20 km/h [12 mph])
- When the outside temperature has changed suddenly (at the entrance/exit of a garage, tunnel, etc.)

■ Customization

Settings (e.g. on/off operation of ECO lamp) can be changed. (Customizable features →P. 668)



■ To prevent damage to the engine and its components

- Do not let the indicator needle of the tachometer enter the red zone, which indicates the maximum engine speed.
- The engine may be overheating if the engine coolant temperature gauge is in the red zone (H). In this case, immediately stop the vehicle in a safe place, and check the engine after it has cooled completely. (→P. 641)



CRUISING RANGE 200 km

CLY21BA070EN


ELAPSED TIME

Multi-information display

Display contents

The multi-information display presents the driver with a variety of driving-related data

- Trip information (→P. 131)
 Displays driving range, fuel consumption and other cruising related information
- ◆ Drive monitor (→P.134)
 Displays either the average fuel consumption after refueling or the driving range



- Dynamic radar cruise control display* (if equipped) (→P. 313)
- Dynamic radar cruise control with full-speed range display* (if equipped) (→P. 328)
- LKA (Lane-Keeping Assist) display* (if equipped) (→P. 344)

• Warning messages (\rightarrow P. 614)

Automatically displayed when a malfunction occurs in one of the vehicle's systems. Display can be switched by pressing the "DISP" button. (→P.131)

*: Automatically displayed when the system is used. Display can be switched by pressing the "DISP" button.

(→P. 131)




Trip information

■ Switching the display

Items displayed can be switched by pressing the "DISP" button.

The information displayed on the drive monitor will not be displayed on the trip information screen.






■ Driving range

CRUISING RANGE 200 km

-۸۸۸۶۲ + ۸۵ : تلفن شبانه روزی: Displays the estimated approximate distance that can be driven with the quantity of fuel remaining

- This distance is computed based on your average fuel consumption. As a result, the actual distance that can be driven may differ from that displayed.
 - When only a small amount of fuel is added to the tank, the display may not be updated.
 When refueling, turn the engine switch off. If the vehicle is refueled without turning the engine switch off, the display may not be updated.

■ Eco Driving Indicator Zone Display and average fuel consumption




- Displays Eco Driving Indicator Zone Display
 Suggests Zone of Eco driving and Eco driving ratio based on acceleration.
 - Eco driving ratio based on acceleration
 If the acceleration exceeds Zone of Eco driving, the right side of Eco Driving Indicator Zone Display blinks.
 - 2 Zone of Eco driving Eco Driving Indicator will not operate in the following conditions:
 - The shift lever is anything other than D.
 - Vehicles with paddle shift switches: Paddle shift switch is operated.
 - Normal mode, comfort mode (if equipped) or Eco drive mode is not selected. $(\rightarrow P.354)$
 - The vehicle speed is approximately 130 km/h (80 mph) or higher.
- Displays the average fuel consumption since the function was reset
 - The function can be reset by pressing the "DISP" button for longer than 1 second when the average fuel consumption is displayed.

On vehicles with a navigation system, the "Past record" screen on the Remote Touch screen will also be updated. (\rightarrow P. 140)

 Use the displayed average fuel consumption as a reference.

■ Current fuel consumption



Displays the current rate of fuel consumption

■ Average fuel consumption after refueling



Displays the average fuel consumption since the vehicle was last refueled

Use the displayed average fuel consumption as a reference.

■ Distance after refueling



Displays the distance the vehicle has been driven since the vehicle was last refueled

■ Elapsed time



Displays the elapsed time since it was last reset

The function can be reset by pressing the "DISP" button for longer than 1 second when the elapsed time is displayed.

■ Average vehicle speed



تلفن شبانه روزی: کام۸۶۲ میانه روزی: Displays the average vehicle speed since the function was reset


The function can be reset by pressing the "DISP" button for longer than 1 second when the average vehicle speed is displayed.

■ Tire inflation pressure (if equipped)



Displays inflation pressure of each tire

■ Customization




The multi-information display settings can be changed (\rightarrow P. 135)

Drive monitor

Either average fuel consumption after refueling or driving range can be selected and displayed.

If displayed on the drive monitor, other trip information or warning messages can be displayed simultaneously.



The information displayed on the drive monitor will not be displayed on the trip information screen.



Setting up the displays

1 While the vehicle is stopped, press the "DISP" button until the "Settings" screen appears.



2 Press and hold the "DISP" button until the screen changes.



3 Press and hold the "DISP" button after selecting the desired setting item by pressing the "DISP" button.



FarmaSOS

4 Press and hold the "DISP" button after selecting the desired setting by pressing the "DISP" button.

The display goes back to step 3.



5 Press and hold the "DISP" button after selecting the "EXIT" by pressing the "DISP" button.

The display goes back to step 1.



■ System check display

After turning the engine switch to IGNITION ON mode, "SYSTEM CHECK" is displayed while system operation is checked.

■ Tire inflation pressure (if equipped)

- It may take a few minutes to display the tire inflation pressure after the engine switch is turned to IGNITION ON mode. It may also take a few minutes to display the tire inflation pressure after inflation pressure has been adjusted.
- "---" may be displayed if the tire position information cannot be determined due to unfavorable radio wave conditions.
- Tire inflation pressure changes with temperature. The displayed values may also be different from the values measured using a tire pressure gauge.

■ When disconnecting and reconnecting battery terminals

The following information data will be reset:

- Driving range FarmaSOS.com
- Average fuel consumption
- Average fuel consumption after refueling
- Distance after refueling
- Elapsed time
- Average vehicle speed

■ Liquid crystal display

Small spots or light spots may appear on the display. This phenomenon is characteristic of liquid crystal displays, and there is no problem continuing to use the display.

■ Customization

Setting of available languages can be changed. (Customizable features \rightarrow P. 668)

A CAUTION

■ The information display at low temperatures

Allow the interior of the vehicle to warm up before using the liquid crystal information display. At extremely low temperatures, the information display monitor may respond slowly, and display changes may be delayed.

For example, there is a lag between the driver's shifting and the new gear number appearing on the display. This lag could cause the driver to downshift again, causing rapid and excessive engine braking and possibly an accident resulting in death or injury.

■ Cautions during setting up the display

As the engine needs to be running during setting up the display, ensure that the vehicle is parked in a place with adequate ventilation. In a closed area such as a garage, exhaust gases including harmful carbon monoxide (CO) may collect and enter the vehicle. This may lead to death or a serious health hazard.


↑ NOTICE

■ During setting up the display

Fuel consumption information

Fuel consumption information can be displayed on the Remote Touch screen.

The fuel consumption information can be displayed and operated on the side display.



Trip information

Press the "MENU" button on the Remote Touch, then select on the "Menu" screen.

If a does not appear, select on the "Menu" screen. If the "Information" screen appears, select "Fuel consumption" on the screen.

If the "Past Record" screen is displayed, select "Trip Information".

- 1) Resetting the consumption data
- 2 Fuel consumption in the past 15 minutes
- 3 Current fuel consumption
- 4 Average vehicle speed since the engine was started.
- (5) Elapsed time since the engine was started.



Average fuel consumption for the past 15 minutes is divided by color into past averages and averages attained since the engine switch was last turned to IGNITION ON mode. Use the displayed average fuel consumption as a reference.

The image is an example only, and may vary slightly from actual conditions.



Past record

Press the "MENU" button on the Remote Touch, then select on the "Menu" screen.

If a does not appear, select on the "Menu" screen. If the "Information" screen appears, select "Fuel consumption" on the screen.

If the "Trip Information" screen is displayed, select "Past Record".

- 1) Resetting the past record data
- 2 Best recorded fuel consumption
- 3 Average fuel consumption
- 4 Previous fuel consumption record
- 5 Updating the average fuel consumption data

The average fuel consumption history is divided by color into past متافن شبانه روزی: averages and the average fuel consumption since the last updated.

Use the displayed average fuel consumption as a reference.

The image is an example only, and may vary slightly from actual conditions.



■ Updating the past record data

Update the average fuel consumption by selecting "Update" to measure the current fuel consumption again.

■ Resetting the data

The fuel consumption data can be deleted by selecting "Clear".

■ Cruising range

Displays the estimated maximum distance that can be driven with the quantity of fuel remaining.

This distance is computed based on your average fuel consumption.

As a result, the actual distance that can be driven may differ from that displayed.



تلفن شبانه روزی: ۵۸۰۲۹۸۸۸–۲۲

Using the side display

Vehicle information can be displayed on the side display (\rightarrow P. 415), then select "<" or ">" to select the desired screen.

► Fuel consumption

Displays the average fuel consumption for the past 10 minutes in 1 minute intervals, as well as the cruising range.



▶ Past record

Displays the average fuel consumption and highest fuel consumption.



► Trip information

Displays the cruising range, average fuel consumption and the amount of time elapsed since the engine was started.



The image is an example only, and may vary slightly from actual conditions.

Operation of each component

3-1.	Key information
	Keys144
3-2.	Opening, closing and locking the doors
	Smart entry &
	start system153
	Wireless remote control177
	Doors186
	Trunk191
3-3.	Adjusting the seats
1 10000	Front seats198
	Power rear seat205
	Driving position memory 218
	Rear seat position memory 223
· ۲۱-۸۸۸۶۲ · ۸۵ :	Head restraints225
3-4.	Adjusting the steering wheel and mirrors
FarmaSOS	Steering wheel228
	Inside rear view mirror229
	Outside rear view
	mirrors232
3-5.	Opening, closing the windows and moon roof
	Power windows236
	Moon roof240


Keys

The keys

The following keys are provided with the vehicle.

- (1) Electronic keys
 - Operating the smart entry & start system (\rightarrow P.153)
 - Operating the wireless remote control function (\rightarrow P. 177)
- (2) Mechanical keys
- (3) Key number plate
- 4 Card key (electronic key) (if equipped)

Operating the smart entry & start system (\rightarrow P. 153)



Using the mechanical key

To take out the mechanical key:

Electronic keys: Slide the release lever and take the key out.

Card key: Press the lock release button and take the key out.

The mechanical key can only be inserted in one direction, as the key only has grooves on one side. If the key cannot be inserted in a lock cylinder, turn it over and re-attempt to insert it.

After using the mechanical key, store it in the electronic key. Carry the mechanical key together with the electronic key. If the electronic key battery is depleted or the entry function does not operate properly, you will need the mechanical key.

 $(\rightarrow P.631)$


CLY31BA006

■ Electronic keys

- Part of the electronic key uses leather. Refer to P. 514 for details on cleaning the leather portion.
- When cleaning the metallic portion, wet a cloth and firmly wring out any excess water from it, then thoroughly wipe off any dirt.
- When not using the electronic key for an extended period of time, store it in a dry place of normal temperature away from direct sunlight and interior light after removing any dirt.

■ Card key (if equipped)

- The card key is not waterproof.
- The mechanical key that is stored inside the card key should be used only if a problem arises, such as when the card key does not operate properly.
- If it is difficult to take out the mechanical key, push down the lock release button using a pen tip etc. If it is still difficult to pull it out, use a coin etc.
- To store the mechanical key in the card key. insert it while pressing the lock release button.



If the battery cover is not installed and the battery falls out or if the battery was removed because the key got wet, reinstall the battery with the positive terminal facing the Lexus emblem.



■ When required to leave the vehicle's key with a parking attendant

Turn the trunk opener main switch off and lock the glove box and the trunk storage extension (if equipped) as circumstances demand. (\rightarrow P. 192, 453, 494) Remove the mechanical key for your own use and provide the attendant with the electronic key only.

■ If you lose your mechanical keys


New genuine mechanical keys can be made by your Lexus dealer using the other mechanical key and the key number stamped on your key number plate. Keep the plate in a safe place such as your wallet, not in the vehicle.

■ When riding in an aircraft

When bringing an electronic key onto an aircraft, make sure you do not press any buttons on the electronic key while inside the aircraft cabin. If you are carrying an electronic key in your bag etc., ensure that the buttons are not likely to be pressed accidentally. Pressing a button may cause the electronic key to emit radio waves that could interfere with the operation of the aircraft.

■ Certification for the card key

► For vehicles sold in Korea



: DENSO CORPORATION

기자재의 명칭(모델명) :데이터전송용 무선기기(14AEX)

: See product. / Japan : KCC-CRM-DKR-14AEX

تلفن شبانه روزى: ۱۵۸۰۲۹۸۸ - ۲۱

- ► For vehicles sold in Republic of Serbia
 - Replace only with the same or equivalent type recommended by the manufacturer
 - Dispose of used batteries according to the local laws.



The latest "DECLARATION of CONFORMITY" (DoC) is The latest "DECLARATION of COI available at the following address: http://www.globaldenso.com/en/products/oem/index.html

Hereby, DENSO CORPORATION declares that this 14AEX is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

DENSO CORPORATION vakuuttaa täten että 14AEX tyyppinen laite on direktiivin 1999/5/EY oleellisten vaatimusten ja sitä koskevien direktiivin muiden ehtojen mukainen.

Hierbij verklaart DENSO CORPORATION dat het toestel 14AEX in overeenstemming is met de essentiële eisen en de andere relevante bepalingen van richtlijn 1999/5/EG.

Par la présente DENSO CORPORATION déclare que l'appareil 14AEX est conforme aux exigences essentielles et aux autres dispositions pertinentes de la directive 1999/5/CE.

Härmed intygar DENSO CORPORATION att denna 14AEX står I överensstämmelse med de väsentliga egenskapskrav och övriga relevanta bestämmelser som framgår av direktiv 1999/5/EG.

Undertegnede DENSO CORPORATION erklærer herved, at følgende udstyr 14AEX overholder de væsentlige krav og øvrige relevante krav i direktiv 1999/5/EF.

Hiermit erklärt DENSO CORPORATION, dass sich das Gerät 14AEX in Übereinstimmung mit den grundlegenden Anforderungen und den übrigen einschlägigen Bestimmungen der Richtlinie 1999/5/EG befindet.

ΜΕ ΤΗΝ ΠΑΡΟΥΣΑ DENSO CORPORATION ΔΗΛΩΝΕΙ ΟΤΙ 14ΑΕΧ ΣΥΜΜΟΡΦΩΝΕΤΑΙ ΠΡΟΣ ΤΙΣ ΟΥΣΙΩΔΕΙΣ ΑΠΑΙΤΉΣΕΙΣ ΚΑΙ ΤΙΣ ΛΟΙΠΈΣ ΣΧΕΤΙΚΈΣ ΔΙΑΤΑΞΕΙΣ ΤΗΣ ΟΔΗΓΙΑΣ 1999/5/EK.

Con la presente DENSO CORPORATION dichiara che questo 14AEX è conforme ai requisiti essenziali ed alle altre disposizioni pertinenti stabilite dalla direttiva 1999/5/CE.

Por medio de la presente DENSO CORPORATION declara que el 14AEX cumple con los requisitos esenciales y cualesquiera otras disposiciones aplicables o exigibles de la Directiva 1999/5/CE.

DENSO CORPORATION declara que este 14AEX está conforme com os requisitos essenciais e outras disposições da Directiva 1999/5/CE.

Hawnhekk, DENSO CORPORATION, jiddikjara li dan 14AEX jikkonforma mal-ħtiġijiet essenzjali u ma provvedimenti oħrajn relevanti li hemm fid-Dirrettiva 1999/5/EC.

Käesolevaga kinnitab DENSO CORPORATION seadme 14AEX vastavust direktiivi 1999/5/EÜ põhinõuetele ja nimetatud direktiivist tulenevatele teistele asjakohastele sätetele.

Alulírott, DENSO CORPORATION nyilatkozom, hogy a 14AEX megfelel a vonatkozó alapvető követelményeknek és az 1999/5/EC irányelv egyéb előírásainak.

DENSO CORPORATION týmto vyhlasuje, že 14AEX spĺňa základné požiadavky a všetky príslušné ustanovenia Smernice 1999/5/ES.

DENSO CORPORATION tímto prohlašuje, že tento 14AEX je ve shodě se základními požadavky a dalšími příslušnými ustanoveními směrnice 1999/5/ES.

DENSO CORPORATION izjavlja, da je ta 14AEX v skladu z bistvenimi zahtevami in ostalimi relevantnimi določili direktive 1999/5/ES.

Šiuo DENSO CORPORATION deklaruoja, kad šis 14AEX atitinka esminius reikalavimus ir kitas 1999/5/EB Direktyvos nuostatas.

Ar šo DENSO CORPORATION deklarē, ka 14AEX atbilst Direktīvas 1999/5/EK būtiskajām prasībām un citiem ar to saistītajiem noteikumiem.

Niniejszym DENSO CORPORATION oświadcza, że 14AEX jest zgodny z zasadniczymi wymogami oraz pozostałymi stosownymi postanowieniami Dyrektywy 1999/5/EC.

Hér með lýsir DENSO CORPORATION yfir því að 14AEX er í samræmi við grunnkröfur og aðrar kröfur, sem gerðar eru í tilskipun 1999/5/EC.

DENSO CORPORATION erklærer herved at utstyret 14AEX er i samsvar med de grunnleggende krav og øvrige relevante krav i direktiv 1999/5/EF.

С настоящето, DENSO CORPORATION, декларира, че 14AEX е в съответствие със съществените изисквания и другите приложими разпоредби на Директива 1999/5/EC.

Prin prezenta, DENSO CORPORATION, declară că aparatul 14AEX este in conformitate cu cerințele esențiale și cu alte prevederi pertinente ale Directivei 1999/5/CE.

Ovim, DENSO CORPORATION, izjavljuje da ovaj 14AEX je usklađen sa bitnim zahtjevima i drugim relevantnim odredbama Direktive 1999/5/EC.

Ovim, DENSO CORPORATION, deklariše da je 14AEX u skladu sa osnovnim zahtevima i ostalim relevantnim odredbama Direktive 1999/5/EC.

Ovim DENSO CORPORATION, izjavljuje da je 14AEX u sklau s bitnim zahtjevima i drugim relevantnim odredbama Direktive 1999/5/EC i Pravilnika o RiTT opremi (NN 25/2012).

Nepermjet kesaj, DENSO CORPORATION, deklaroj qe ky 14AEX eshte ne pajtim me kerkesat thelbesore dhe dispozitat e tjera perkatese te Direktives 1999/5/EC.

- -Replace only with the same or equivalent type recommended by the manufacturer.
- -Dispose of used batteries according to the local laws.

↑ NOTICE

■ To prevent key damage

- Do not drop the keys, subject them to strong shocks or bend them.
- Do not expose the keys to high temperatures for a long period of time.
- Do not get the keys wet or wash them in an ultrasonic washer etc.
- Do not attach metallic or magnetic materials to the keys or place the keys close to such materials.
- Do not disassemble the keys.
- Do not attach a sticker or anything else to the surface of the electronic key.
- Do not place the keys near objects that produce magnetic fields, such as TVs, audio systems and induction cookers, or medical electrical equipment, such as low-frequency therapy equipment.

■ Handling the electronic keys

- Observe the following to prevent deterioration, changes in shape and damage to the leather area.
 - Do not carry the electronic key together with hard objects, such as other keys or accessories.
 - Do not expose the electronic keys to direct sunlight or interior light for extended periods of time.
 - Do not place the electronic key on items made of vinyl, plastic or that contain wax.
 - They may stick to the leather surface if the items become warm.
 - Do not get the electronic key wet.
 Even if the electronic gets slightly wet, dry it with a soft cloth and let it dry in the shade.
 - Do not touch the electronic key with hands that have oil, medicine, hand cream or perfume on them.
 - When cleaning, do not use a leather cleaner, solvents or leather filling agents.
- Because the leather portion is dyed, if the electronic key touches clothing while it
 has sweat and moisture adhered to it, there is a possibility that the clothing may
 change color.

♠ NOTICE

■ In case of a smart entry & start system malfunction or other key-related problems

Take your vehicle with all the electronic keys provided with your vehicle, including the card key, to your Lexus dealer.

■ When an electronic key is lost

If the electronic key remains lost, the risk of vehicle theft increases significantly. Visit your Lexus dealer immediately with all remaining electronic keys and the card key that was provided with your vehicle.


■ Handling the card key

- Do not apply excess force when inserting the mechanical key into the card key.
 Doing so may damage the card key.
- If the battery or card key terminals get wet, the battery may corrode. If the key is dropped into water, or if drinking water etc. is spilled on the key, immediately remove the battery cover and wipe the battery and terminals. (To remove the battery cover, lightly grasp and pull it.) If the battery is corroded, have your Lexus dealer replace the battery.
- Do not crush the battery cover or use a screwdriver to remove the battery cover. Forcibly removing the battery cover may bend or damage the key.
- If the battery cover is frequently removed, the battery cover may become loose.
- When installing the battery, make sure to check the direction of the battery.
 Installing the battery in the wrong direction may cause the battery to deplete rapidly.
- The surface of the card key may be damaged, or its coating may peel off in the following situations:
 - The card key is carried together with hard objects, such as coins and keys.
 - The card key is scraped with a sharp object, such as the tip of a mechanical pencil.
 - The surface of the card key is wiped with thinner or benzene.

Smart entry & start system

Function summary

The following operations can be performed simply by carrying the electronic key (including the card key) on your person, for example in your pocket. (The driver should always carry the electronic key.)



- (1) Locks and unlocks the doors (→P. 155)
- 2 Opens the trunk (\rightarrow P. 155)
- ③ Starts the engine (→P. 259) SOS. COM

■ Operation signals

Doors:

The emergency flashers flash to indicate that the doors have been locked/unlocked. (Locked: Once; Unlocked: Twice)

Windows and moon roof:

A buzzer sounds to indicate that the windows and moon roof are operating.

Some models, the buzzer also sounds from the doors and the trunk.

■ Security feature

If a door is not opened within approximately 30 seconds after the vehicle is unlocked, the security feature automatically locks the vehicle again.

■ Welcome light illumination control

The front position, tail and license plate lights automatically turn on at night when the doors are unlocked using the entry function or wireless remote control if the headlight switch is in the "AUTO" position.

تلفن شبانه روزی: ۱۵۸۰۲۹۸۸ - ۲۱

امداد حودرو جارما

Unlocking and locking the doors

Grip the handle to unlock the doors.

Make sure to touch the sensor on the back of the handle.

The doors cannot be unlocked for 3 seconds after the doors are locked



Press the lock button to lock the door.

Check that the door is securely locked.

Pressing and holding the button closes the windows.

The moon roof will also close. (if equipped)



تلفن شبانه روزی: ۱۸۸۶۲ ۸۸۸


Opening the trunk

Press the button.

The trunk lid automatically opens fully.

When all the doors are unlocked using one of the following methods, the trunk can be opened without the electronic key:


- Entry function
- Wireless remote control
- Door lock switches
- Automatic door unlocking system
- Mechanical key



Antenna location and effective range

■ Antenna location

- 1 Antennas outside the cabin
- (2) Antennas inside the cabin
- (3) Antenna outside the trunk
- 4) Antenna inside the trunk



تلفن شبانه روزى: ٨٥٠ ٢٩ ٨٨٨٥ - ٢١٠

■ Effective range (areas within which the electronic key is detected)


When locking or unlocking the doors

The system can be operated when the electronic key is within about 0.7 m (2.3 ft.) of an outside door handle. (Only the doors detecting the key can be operated.)



The system can be operated when the electronic key is within about 0.7 m (2.3 ft.) of the trunk release button.

When starting the engine or changing engine switch modes







■ Alarms and warning indicators

A combination of exterior and interior alarms as well as warnings displayed on the multi-information display are used to prevent theft of the vehicle and unforeseeable accidents resulting from erroneous operation. Perform the appropriate correction procedure described in the following table:

Alarm	Situation	Correction procedure
Exterior alarm sounds once for 2 seconds.	An attempt was made to lock the doors using the entry function while the electronic key was still inside the passenger compartment.	Retrieve the electronic key from the passenger compartment and lock the doors again.
	The trunk was closed with the electronic key inside and all doors were locked.	Retrieve the electronic key from the trunk and close the trunk lid.
Exterior alarm sounds once for 60 seconds.	An attempt was made to exit the vehicle and lock the doors while carrying the electronic key without first turning the engine switch off.	Turn the engine switch off and lock the doors again. تلقن ش
Exterior alarm sounds once for 5 seconds.	An attempt was made to lock the vehicle while a door was open.	Close all of the doors and lock the doors again.

, 3,					
Alarm	Situation	Correction procedure			
Interior alarm pings continuously.	The engine switch was turned to ACCESSORY mode while the driver's door was open (or the driver's door was opened while the engine switch was in ACCESSORY mode).	Turn the engine switch off and close the driver's door.			
	The engine switch was turned off while the driver's door was open.	Close the driver's door.			
Interior alarm sounds continuously.*1	When the engine switch is in IGNITION ON or ACCESSORY mode, an attempt was made to open the door and exit the vehicle, and the shift lever was not in P.	Shift the shift lever to P and turn the engine switch off.			
Interior and exterior alarms sound continuously.*1	When the engine switch is in IGNITION ON or ACCESSORY mode, the driver's door was closed after the key was carried outside the vehicle, and the shift lever was not in P.	Shift the shift lever to P, turn the engine switch off and close the driver's door again.			
	The electronic key has a low battery.	Replace the electronic key battery.			
Interior alarm pings once.*1	An attempt was made to start the engine without the electronic key being present, or the electronic key was not functioning normally.	Start the engine with the electronic key present.*2			

Alarm	Situation	Correction procedure
Interior alarm pings once and exterior alarm sounds 3 times.*1	The driver's door was closed after the key was carried outside the vehicle, and the engine switch was not turned off.	<u> </u>
	An occupant carried the electronic key outside the vehicle and closed the door while the engine switch was not off.	Bring the electronic key back into the vehicle.

^{*1:} A warning message will be shown on the multi-information display in the instrument cluster.

تلفن شبانه روزی: ۱-۸۸۸۶۲ ۲۸ - ۲۱

^{*2:} If the engine does not start when the electronic key is inside the vehicle, the electronic key battery may be depleted or there may be difficulties receiving the signal from the key. (\(\rightarrow P. 163 \))

■ Switching the door unlock function

It is possible to set which doors the entry function unlocks using the wireless remote control.

- 1 Turn the engine switch off.
- 2 Cancel the intrusion sensor and tilt sensor of the alarm system to prevent unintended triggering of the alarm during the setting change. (if equipped) $(\rightarrow P. 115)$
- \blacksquare Press and hold \blacksquare , \blacksquare or ((\blacksquare for approximately 5 seconds while pressing and holding \blacksquare .

The setting changes each time an operation is performed, as shown below. (When changing the setting continuously, release the buttons, wait for at least 5 seconds, and repeat step $\boxed{3}$.)

Multi-information display	Unlocking function	Веер
*	Hold a door handle to unlock all doors	Exterior: Beeps twice Interior: Rings once
♣ → ♣	Hold the driver's door handle to unlock only the driver's door Hold a passenger's door handle to unlock all the doors: The passenger's door handle to unlock all the doors: The passenger's door handle to unlock all the doors: The passenger's door handle to unlock all the doors: The passenger's door handle to unlock all the driver's door handle to unlock only the driver's door handle to unlock all the doors:	
8 8		
	Hold the door handle to unlock the front and rear doors on your side	Exterior: Beeps 4 times Interior: Rings once
	Hold the door handle to unlock the door	Exterior: Beeps once Interior: Rings once

To prevent unintended triggering of the alarm, unlock the doors using the wireless remote control and open and close a door once after the settings have been changed. (If a door is not opened within 30 seconds after \Box is pressed, the doors will be locked again and the alarm will automatically be set.) In case that the alarm is triggered, immediately stop the alarm. (\rightarrow P. 113)

■ Battery-saving function

In the following circumstances, the entry function is disabled in order to prevent the vehicle battery from discharging and the electronic key battery from depleting.

- When the entry function has not been used for 30 days or more
- When the electronic key has been left within approximately 2 m (6 ft.) of the vehicle for 10 minutes or more

The system will resume operation when

- The vehicle is locked using the door handle lock switch when carrying the electronic key on your person.
- The vehicle is locked/unlocked using the wireless remote control function.
 (→P.177)
- The vehicle is locked/unlocked using the mechanical key. $(\rightarrow P. 631)$



تلفن شبانه روزی: ۵۸۰۲۹۸۸۸–۲۱

■ Conditions affecting operation

The smart entry & start system uses weak radio waves. In the following situations, the communication between the electronic key and the vehicle may be affected, preventing the smart entry & start system, wireless remote control and engine immobilizer system from operating properly. (Ways of coping: \rightarrow P. 631)

- When the electronic key battery is depleted
- Near a TV tower, electric power plant, gas station, radio station, large display, airport or other facility that generates strong radio waves or electrical noise
- When carrying a portable radio, cellular phone, cordless phone or other wireless communication device
- When the electronic key is in contact with, or is covered by the following metallic objects
 - Cards to which aluminum foil is attached
 - Cigarette boxes that have aluminum foil inside
 - Metallic wallets or bags
 - Coins
 - Hand warmers made of metal
 - Media such as CDs and DVDs
- When multiple electronic keys are in the vicinity
- When other wireless keys (that emit radio waves) are being used nearby
- When carrying the electronic key together with the following devices that emit radio waves
 - Another vehicle's electronic key or a wireless key that emits radio waves
 - Personal computers or personal digital assistants (PDAs)
 - Digital audio players
 - Portable game systems
- If window tint with a metallic content or metallic objects are attached to the rear window

■ Note for the entry function

- Even when the electronic key is within the effective range (detection areas), the system may not operate properly in the following cases:
 - The electronic key is too close to the window or outside door handle, near the ground, or in a high place when the doors are locked or unlocked.
 - The electronic key is near the ground or in a high place, or too close to the rear bumper center when the trunk is opened.
 - The electronic key is on the instrument panel, rear package tray or floor, or in the door pockets or glove box when the engine is started or engine switch modes are changed.
- Do not leave the electronic key on top of the instrument panel or near the door pockets when exiting the vehicle. Depending on the radio wave reception conditions, it may be detected by the antenna outside the cabin and the door will become lockable from the outside, possibly trapping the electronic key inside the vehicle.
- As long as the electronic key is within the effective range, the doors may be locked or unlocked by anyone. However, only the doors detecting the electronic key can be used to unlock the vehicle.
- Even if the electronic key is not inside the vehicle, it may be possible to start the engine if the electronic key is near the window.
- The doors may unlock if a large amount of water splashes on the door handle, such as in the rain or in a car wash when the electronic key is within the effective range. (The door will automatically be locked after approximately 30 seconds if the doors are not opened and closed.)
- Gripping the door handle when wearing a glove may not unlock the door.
- If the wireless remote control is used to lock the doors when the electronic key is near the vehicle, there is a possibility that the door may not be unlocked by the entry function. (Use the wireless remote control to unlock the doors.)
- A sudden approach to the effective range or door handle may prevent the doors from being unlocked. In this case, return the door handle to the original position and check that the doors unlock before pulling the door handle again.

■ When the vehicle is not driven for extended periods

To prevent theft of the vehicle, do not leave the electronic key within $2 \, \text{m}$ (6 ft.) of the vehicle.

■ Alarm

Using the smart entry & start system to lock the doors will set the alarm system. $(\rightarrow P. 112)$

■ To operate the system properly

• Make sure to carry the electronic key when operating the system. Do not get the electronic key too close to the vehicle when operating the system from the outside of the vehicle.

Depending on the position and holding condition of the electronic key, the key may not be detected correctly and the system may not operate properly. (The alarm may go off accidentally, or the door lock prevention function may not operate.)

- Do not leave the electronic key inside the trunk. The key confinement prevention function may not operate, depending on the location of the key (close to a spare tire, the inside edge of the trunk), conditions (inside a metal bag, close to metallic objects) and the radio waves in the surrounding area. (→P. 193)
- If the smart entry & start system does not operate properly
 - \bullet Locking and unlocking the doors and trunk: Use the mechanical key. (\rightarrow P. 631)
 - The starting the engine: → P. 634 → T A cities (وزی: ۵۲ A cities)

■ Electronic key battery depletion

- The standard battery life is 1 to 2 years. (The card key battery life is about a year and a half.)
- If the battery is low, an alarm will sound in the cabin when the engine is started or stopped. $(\rightarrow P. 158)$
- The battery becomes depleted even if the electronic key is not used because the key always receives radio waves. If the smart entry & start system or the wireless remote control does not operate, or the detection area becomes smaller, the battery may be depleted. Replace the battery when necessary. (→P. 575)
- To avoid serious deterioration, do not leave the electronic key within 1 m (3 ft.) of the following electrical appliances that produce a magnetic field:
 - TVs
 - Personal computers
 - Cellular phones, cordless phones and battery chargers
 - Recharging cellular phones or cordless phones
 - Table lamps
 - Induction cookers
- When the electronic key battery is fully depleted

 \rightarrow P. 575

■ Customization

Settings (e. g. smart entry & start system) can be changed. (Customizable features →P. 667)

■ Certification for the smart entry & start system

► For vehicles sold in Taiwan

經型式認證合格之低功率射頻電機, 非經許可, 公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。

低功率射頻電機之使用不得影響飛航安全及干擾合法通信;經發現有干擾現象時,應立即停用,並改善至無干擾時方得繼續使用。

前項合法通信. 指依電信法規定作業之無線電通信。

低功率射頻電機須忍受合法通信或工業、科學及醫療用電波輻射性電機 設備之干擾。

► For vehicles sold in Brazil

Este equipamento está homologado pela ANATEL de acordo com os procedimentos regulamentados pela Resolução 242/2000 e atende aos requisitos técnicos aplicados.

Este equipamento opera em caráter secundário, isto é, não tem direito a proteção contra interferência prejudicial, mesmo de estações do mesmo tipo, e não pode causar interferência a sistemas operando em caráter primário.



► For vehicles sold in Republic of Serbia

TOYOTA

TOYOTA MOTOR CORPORATION

1, TOYOTA-	CHO, TOYOTA, AICHI,	471-8571, JAPAN TEL:+81-565-28-2121
R&TT	E Declara	tion of Conformity
We,		
		CORPORATION Toyota, Aichi, 471-8572, Japan
hereby declare under our sole	e responsibility	that the product:
Product Name: LF Oscillator Product Model: TMLF-4 to which this declaration relat	9	mity with the essential requirements and
other relevant requirements o	of the R&TTE D	rirective (1999/5/EC). The product is
compliant with the following :	standards and/	or other normative documents:
-Health & safety requirer	_人人人タ nents:	تلفن شبانه روزی: EN 60950-1
		EN 301 489-01 & EN 301 489-03
-Effective uses of radio spectrum:		EN 300 330-2
Supplementary information:	rma	SOS.com
* CE mark		CE
* Member states intended for use		EU and EFTA
Date:	February 25,	2013
Signature:	Tetro	yn motus
	Tetsuya Matsı	10

Hereby, TOYOTA MOTOR CORPORATION, declares that this TMLF-4 is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

TOYOTA MOTOR CORPORATION vakuuttaa täten että TMLF-4 tyyppinen laite on direktiivin 1999/5/EY oleellisten vaatimusten ja sitä koskevien direktiivin muiden ehtojen mukainen.

Hierbij verklaart TOYOTA MOTOR CORPORATION dat het toestel TMLF-4 in overeenstemming is met de essentiële eisen en de andere relevante bepalingen van richtlijn 1999/5/EG.

Par la présente TOYOTA MOTOR CORPORATION déclare que l'appareil TMLF-4 est conforme aux exigences essentielles et aux autres dispositions pertinentes de la directive 1999/5/CE.

Härmed intygar TOYOTA MOTOR CORPORATION att denna TMLF-4 står I överensstämmelse med de väsentliga egenskapskrav och övriga relevanta bestämmelser som framgår av direktiv 1999/5/EG.

Undertegnede TOYOTA MOTOR CORPORATION erklærer herved, at følgende udstyr TMLF-4 overholder de væsentlige krav og øvrige relevante krav i direktiv 1999/5/EF.

Hiermit erklärt TOYOTA MOTOR CORPORATION, dass sich das Gerät TMLF-4 in Übereinstimmung mit den grundlegenden Anforderungen und den übrigen einschlägigen Bestimmungen der Richtlinie 1999/5/EG befindet.

ΜΕ ΤΗΝ ΠΑΡΟΥΣΑ ΤΟΥΟΤΑ MOTOR CORPORATION ΔΗΛΩΝΕΙ ΟΤΙ ΤΜLF-4 ΣΥΜΜΟΡΦΩΝΕΤΑΙ ΠΡΟΣ ΤΙΣ ΟΥΣΙΩΔΕΙΣ ΑΠΑΙΤΗΣΕΙΣ ΚΑΙ ΤΙΣ ΛΟΙΠΕΣ ΣΧΕΤΙΚΕΣ ΔΙΑΤΑΞΕΙΣ ΤΗΣ ΟΔΗΓΙΑΣ 1999/5/ΕΚ.

Con la presente TOYOTA MOTOR CORPORATION dichiara che questo TMLF-4 è conforme ai requisiti essenziali ed alle altre disposizioni pertinenti stabilite dalla direttiva 1999/5/CE.

Por medio de la presente TOYOTA MOTOR CORPORATION declara que el TMLF-4 cumple con los requisitos esenciales y cualesquiera otras disposiciones aplicables o exigibles de la Directiva 1999/5/CE.

TOYOTA MOTOR CORPORATION declara que este TMLF-4 está conforme com os requisitos essenciais e outras disposições da Directiva 1999/5/CE.

Hawnhekk, TOYOTA MOTOR CORPORATION, jiddikjara li dan TMLF-4 jikkonforma mal-ħtiġijiet essenzjali u ma provvedimenti oħrajn relevanti li hemm fid-Dirrettiva 1999/5/EC.

Käesolevaga kinnitab TOYOTA MOTOR CORPORATION seadme TMLF-4 vastavust direktiivi 1999/5/EÜ põhinõuetele ja nimetatud direktiivist tulenevatele teistele asjakohastele sätetele.

Alulírott, TOYOTA MOTOR CORPORATION nyilatkozom, hogy a TMLF-4 megfelel a vonatkozó alapvető követelményeknek és az 1999/5/EC irányelv egyéb előírásainak.

TOYOTA MOTOR CORPORATION týmto vyhlasuje, že TMLF-4 spĺňa základné požiadavky a všetky príslušné ustanovenia Smernice 1999/5/ES.

TOYOTA MOTOR CORPORATION tímto prohlašuje, že tento TMLF-4 je ve shodě se základními požadavky a dalšími příslušnými ustanoveními směrnice 1999/5/ES.

TOYOTA MOTOR CORPORATION izjavlja, da je ta TMLF-4 v skladu z bistvenimi zahtevami in ostalimi relevantnimi določili direktive 1999/5/ES.

Šiuo TOYOTA MOTOR CORPORATION deklaruoja, kad šis TMLF-4 atitinka esminius reikalavimus ir kitas 1999/5/EB Direktyvos nuostatas.

Ar šo TOYOTA MOTOR CORPORATION deklarē, ka TMLF-4 atbilst Direktīvas 1999/5/EK būtiskajām prasībām un citiem ar to saistītajiem noteikumiem.

Niniejszym TOYOTA MOTOR CORPORATION oświadcza, że TMLF-4 jest zgodny z zasadniczymi wymogami oraz pozostałymi stosownymi postanowieniami Dyrektywy 1999/5/EC.

Hér með lýsir TOYOTA MOTOR CORPORATION yfir því að TMLF-4 er í samræmi við grunnkröfur og aðrar kröfur, sem gerðar eru í tilskipun 1999/5/EC.

TOYOTA MOTOR CORPORATION erklærer herved at utstyret TMLF-4 er i samsvar med de grunnleggende krav og øvrige relevante krav i direktiv 1999/5/EF.

С настоящето, TOYOTA MOTOR CORPORATION, декларира, че TMLF-4 е в съответствие със съществените изисквания и другите приложими разпоредби на Директива 1999/5/EC.

Prin prezenta, TOYOTA MOTOR CORPORATION, declară că aparatul TMLF-4 este in conformitate cu cerințele esențiale și cu alte prevederi pertinente ale Directivei 1999/5/CE.

Ovim, TOYOTA MOTOR CORPORATION, izjavljuje da ovaj TMLF-4 je usklađen sa bitnim zahtjevima i drugim relevantnim odredbama Direktive 1999/5/EC.

Nepermjet kesaj, TOYOTA MOTOR CORPORATION, deklaroj qe ky TMLF-4 eshte ne pajtim me kerkesat thelbesore dhe dispozitat e tjera perkatese te Direktives 1999/5/EC.

Ovim TOYOTA MOTOR CORPORATION, izjavljuje da je TMLF-4 u sklau s bitnim zahtjevima i drugim relevantnim odredbama Direktive 1999/5/EC i Pravilnika o RiTT opremi (NN 25/2012).

Ovim, TOYOTA MOTOR CORPORATION, deklariše da je TMLF-4 u skladu sa osnovnim zahtevima i ostalim relevantnim odredbama Direktive 1999/5/EC.

İşbu belge ile TOYOTA MOTOR CORPORATION, bu TMLF-4 ürününün 1999/5/EC Yönetmeliği'nin temel gerekliliklerine ve diğer ilgili hükümlerine uygun olduğunu beyan eder.

Hereby, Tokai Rika Co., Ltd., declares that this B82UA is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

Tokai Rika Co., Ltd. vakuuttaa täten että B82UA tyyppinen laite on direktiivin 1999/5/EY oleellisten vaatimusten ja sitä koskevien direktiivin muiden ehtojen mukainen.

Hierbij verklaart Tokai Rika Co., Ltd. dat het toestel B82UA in overeenstemming is met de essentiële eisen en de andere relevante bepalingen van richtlijn 1999/5/EG.

Par la présente Tokai Rika Co., Ltd. déclare que l'appareil B82UA est conforme aux exigences essentielles et aux autres dispositions pertinentes de la directive 1999/5/CE.

Härmed intygar Tokai Rika Co., Ltd. att denna B82UA står I överensstämmelse med de väsentliga egenskapskrav och övriga relevanta bestämmelser som framgår av direktiv 1999/5/EG.

Undertegnede Tokai Rika Co., Ltd. erklærer herved, at følgende udstyr B82UA overholder de væsentlige krav og øvrige relevante krav i direktiv 1999/5/EF.

Hiermit erklärt Tokai Rika Co., Ltd., dass sich das Gerät B82UA in Übereinstimmung mit den grundlegenden Anforderungen und den übrigen einschlägigen Bestimmungen der Richtlinie 1999/5/EG befindet.

ΜΕ ΤΗΝ ΠΑΡΟΥΣΑ Tokai Rika Co., Ltd. ΔΗΛΩΝΕΙ ΟΤΙ Β82UΑ ΣΥΜΜΟΡΦΩΝΕΤΑΙ ΠΡΟΣ ΤΙΣ ΟΥΣΙΩΔΕΙΣ ΑΠΑΙΤΗΣΕΙΣ ΚΑΙ ΤΙΣ ΛΟΙΠΕΣ ΣΧΕΤΙΚΕΣ ΔΙΑΤΑΞΕΙΣ ΤΗΣ ΟΔΗΓΙΑΣ 1999/5/ΕΚ.

Con la presente Tokai Rika Co., Ltd. dichiara che questo B82UA è conforme ai requisiti essenziali ed alle altre disposizioni pertinenti stabilite dalla direttiva 1999/5/CE.

Por medio de la presente Tokai Rika Co., Ltd. declara que el B82UA cumple con los requisitos esenciales y cualesquiera otras disposiciones aplicables o exigibles de la Directiva 1999/5/CE.

Tokai Rika Co., Ltd. declara que este B82UA está conforme com os requisitos essenciais e outras disposições da Directiva 1999/5/CE.

Hawnhekk, Tokai Rika Co., Ltd., jiddikjara li dan B82UA jikkonforma mal-ħtiġijiet essenzjali u ma provvedimenti oħrajn relevanti li hemm fid-Dirrettiva 1999/5/EC.

Käesolevaga kinnitab Tokai Rika Co., Ltd. seadme B82UA vastavust direktiivi 1999/5/EÜ põhinõuetele ja nimetatud direktiivist tulenevatele teistele asjakohastele sätetele.

Alulírott, Tokai Rika Co., Ltd. nyilatkozom, hogy a B82UA megfelel a vonatkozó alapvető követelményeknek és az 1999/5/EC irányelv egyéb előírásainak.

Tokai Rika Co., Ltd. týmto vyhlasuje, že B82UA spĺňa základné požiadavky a všetky príslušné ustanovenia Smernice 1999/5/ES.

Tokai Rika Co., Ltd. tímto prohlašuje, že tento B82UA je ve shodě se základními požadavky a dalšími příslušnými ustanoveními směrnice 1999/5/ES.

Tokai Rika Co., Ltd. izjavlja, da je ta B82UA v skladu z bistvenimi zahtevami in ostalimi relevantnimi določili direktive 1999/5/ES.

Šiuo Tokai Rika Co., Ltd. deklaruoja, kad šis B82UA atitinka esminius reikalavimus ir kitas 1999/5/EB Direktyvos nuostatas.

Ar šo Tokai Rika Co., Ltd. deklarē, ka B82UA atbilst Direktīvas 1999/5/EK būtiskajām prasībām un citiem ar to saistītajiem noteikumiem.

Niniejszym Tokai Rika Co., Ltd. oświadcza, że B82UA jest zgodny z zasadniczymi wymogami oraz pozostałymi stosownymi postanowieniami Dyrektywy 1999/5/EC.

Hér með lýsir Tokai Rika Co., Ltd. yfir því að B82UA er í samræmi við grunnkröfur og aðrar kröfur, sem gerðar eru í tilskipun 1999/5/EC.

Tokai Rika Co., Ltd. erklærer herved at utstyret B82UA er i samsvar med de grunnleggende krav og øvrige relevante krav i direktiv 1999/5/EF.

С настоящето, Tokai Rika Co., Ltd., декларира, че B82UA е в съответствие със съществените изисквания и другите приложими разпоредби на Директива 1999/5/EC.

Prin prezenta, Tokai Rika Co., Ltd., declară că aparatul B82UA este in conformitate cu cerințele esențiale și cu alte prevederi pertinente ale Directivei 1999/5/CE.

Ovim, Tokai Rika Co., Ltd., izjavljuje da ovaj B82UA je usklađen sa bitnim zahtjevima i drugim relevantnim odredbama Direktive 1999/5/EC.

Nepermjet kesaj, Tokai Rika Co., Ltd., deklaroj qe ky B82UA eshte ne pajtim me kerkesat thelbesore dhe dispozitat e tiera perkatese te Direktives 1999/5/EC.

Ovim Tokai Rika Co., Ltd., izjavljuje da je B82UA u sklau s bitnim zahtjevima i drugim relevantnim odredbama Direktive 1999/5/EC i Pravilnika o RiTT opremi (NN 25/2012).

Ovim, Tokai Rika Co., Ltd., deklariše da je B82UA u skladu sa osnovnim zahtevima i ostalim relevantnim odredbama Direktive 1999/5/EC.

İşbu belge ile Tokai Rika Co., Ltd., bu B82UA ürününün 1999/5/EC Yönetmeliği'nin temel gerekliliklerine ve diğer ilgili hükümlerine uygun olduğunu beyan eder.

The DECLARATION of CONFORMITY (DoC) is available at the following address: http://www.tokai-rika.co.jp/pc



► For vehicles sold in Dominican Republic

FCC ID: NI4TMLF-4

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference; and (2) This device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

A CAUTION

- Caution regarding interference with electronic devices
 - People with implantable cardiac pacemakers, cardiac resynchronization therapypacemakers or implantable cardioverter defibrillators should maintain a reasonable distance between themselves and the smart entry & start system antennas.
 (→P. 156)

The radio waves may affect the operation of such devices. If necessary, the entry function can be disabled. Ask your Lexus dealer for details, such as the frequency of radio waves and timing of the emitted radio waves. Then, consult your doctor to see if you should disable the entry function.

Users of any electrical medical device other than implantable cardiac pacemakers, cardiac resynchronization therapy-pacemakers or implantable cardioverter defibrillators should consult the manufacturer of the device for information about its operation under the influence of radio waves.

Radio waves could have unexpected effects on the operation of such medical devices.

Ask your Lexus dealer for details on disabling the entry function.

■ When using the smart entry & start system and operating the power windows or moon roof

Operate the power window or moon roof after checking to make sure that there is no possibility of any passenger having any of their body parts caught in the window or moon roof. Also, do not allow children to operate the smart entry & start system. It is possible for children and other passengers to get caught in the power window or moon roof.



■ When opening the trunk

Do not press the Lexus parking assist monitor system camera by mistake.

If the camera or surrounding area receives a strong impact, the camera may move off its installed position and/or angle.



تلفن شبانه روزی: ۱۲۰۸۸۶۲۰۲۵ تلفن شبانه روزی:

Wireless remote control

Function summary

The wireless remote control can be used to lock and unlock the vehicle.

▶Type A


- 1 Locks all the doors
 - Check that the door is securely locked.
- (2) Closes the windows and moon roof (press and hold)*
- (3) Unlocks all the doors


On some models:

Pressing the button unlocks the driver's door. Pressing the button Type B again within 3 seconds unlocks the other doors.

- (4) Opens the windows and moon roof (press and hold)*
- (5) Opens the trunk (press and hold) The trunk lid automatically opens fully.
- 6 Sounds the alarm (press and hold) (\rightarrow P. 178)
 - *: These settings must be changed using the customize function, $(\rightarrow P.667)$







■ Operation signals

Doors:

The emergency flashers flash to indicate that the doors have been locked/unlocked. (Locked: Once; Unlocked: Twice)

Windows and moon roof:

A buzzer sounds to indicate that the windows and moon roof are operating.

Some models, the buzzer sounds from the doors and the trunk.

■ Welcome light illumination control

 \rightarrow P.154

■ Door lock buzzer

If an attempt to lock the doors is made when a door is not fully closed, a buzzer sounds continuously for 5 seconds. Fully close the door to stop the buzzer, and lock the vehicle once more.

■ Panic mode (if equipped)

When (I) is pressed for longer than about one second, an alarm will sound intermittently and the vehicle lights will flash to deter any person from trying to break into or damage your vehicle.

To stop the alarm, press any button on the electronic key.



Security feature FarmaSOS.com

 \rightarrow P.154

■ Alarm

Using the wireless remote control to lock the doors will set the alarm system. $(\rightarrow P. 112)$

■ Conditions affecting operation

 \rightarrow P.163

■ If the wireless remote control does not operate properly

Locking and unlocking the doors and trunk: Use the mechanical key. $(\rightarrow P. 631)$

■ Electronic key battery depletion

 \rightarrow P. 166

■ When the electronic key battery is fully depleted

 \rightarrow P. 575

■ Customization

Settings (e.g. wireless remote control system) can be changed. (Customizable features \rightarrow P. 667)

■ Certification for wireless remote control

▶ For vehicles sold in Aruba, Curacao, Dominican Republic and Republic of Panama

FCC ID: NI4TMRF-001 FCC ID: HYQ14ADF

FCC ID: HYQ14AEF

NOTE:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC WARNING:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

► For vehicles sold in Taiwan

經型式認證合格之低功率射頻電機,非經許可,公司、商號或使用者均不得擅 自變更頻率、加大功率或變更原設計之特性及功能。

低功率射頻電機之使用不得影響飛航安全及干擾合法通信;經發現有干擾現象時,應立即停用,並改善至無干擾時方得繼續使用。

前項合法通信,指依電信法規定作業之無線電通信。

低功率射頻電機須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之 干擾。 ► For vehicles sold in Republic of Paraguay

[Para los vehículos que se venden en Paraguay] Nombre del proveedor en Paraguay:Toyotoshi S.A. Dirección:Av.Mariscal Lopez 2801/2899 Asuncion,Paraguay

► For vehicles sold in Brazil

Este equipamento está homologado pela ANATEL de acordo com os procedimentos regulamentados pela Resolução 242/2000 e atende aos requisitos técnicos aplicados.

Este equipamento opera em caráter secundário, isto é, não tem direito a proteção contra interferência prejudicial, mesmo de estações do mesmo tipo, e não pode causar interferência a sistemas operando em caráter primário.





► For vehicles sold in Korea



장호명/세소사 기자재의 명칭(모델명)

제조년월/제조국

식별부호

: Tokai Rika Co., Ltd.

: 특정소출력무선기기(데이터전송용 무선기기) (B76EA)

: Shown on product./Japan : KCC-CRM-TRJ-B76EA

► For vehicles sold in Singapore

Complies with IDA Standards DA101418



تلفن شبانه روزی: ۱۳۵۸ ۲۹۸۸ – ۲۱

► For vehicles sold in Republic of Serbia

Hereby, Tokai Rika Co., Ltd., declares that this B76EA is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

Tokai Rika Co., Ltd. vakuuttaa täten että B76EA tyyppinen laite on direktiivin 1999/5/EY oleellisten vaatimusten ja sitä koskevien direktiivin muiden ehtojen mukainen.

Hierbij verklaart Tokai Rika Co., Ltd. dat het toestel B76EA in overeenstemming is met de essentiële eisen en de andere relevante bepalingen van richtlijn 1999/5/EG.

Par la présente Tokai Rika Co., Ltd. déclare que l'appareil B76EA est conforme aux exigences essentielles et aux autres dispositions pertinentes de la directive 1999/5/CE.

Härmed intygar Tokai Rika Co., Ltd. att denna B76EA står I överensstämmelse med de väsentliga egenskapskrav och övriga relevanta bestämmelser som framgår av direktiv

Undertegnede Tokai Rika Co., Ltd. erklærer herved, at følgende udstyr B76EA overholder de væsentlige krav og øvrige relevante krav i direktiv 1999/5/EF.

Hiermit erklärt Tokai Rika Co., Ltd., dass sich das Gerät B76EA in Übereinstimmung mit den grundlegenden Anforderungen und den übrigen einschlägigen Bestimmungen der Richtlinie 1999/5/EG befindet.

ME THN ΠΑΡΟΥΣΑ Tokai Rika Co., Ltd. ΔΗΛΩΝΕΙ ΟΤΙ Β76ΕΑ ΣΥΜΜΟΡΦΩΝΕΤΑΙ ΠΡΟΣ ΤΙΣ ΟΥΣΙΩΔΕΙΣ ΑΠΑΙΤΗΣΕΙΣ ΚΑΙ ΤΙΣ ΛΟΙΠΕΣ ΣΧΕΤΙΚΕΣ ΔΙΑΤΑΞΕΙΣ ΤΗΣ ΟΔΗΓΙΑΣ 1999/5/ΕΚ.

Con la presente Tokai Rika Co., Ltd. dichiara che questo B76EA è conforme ai requisiti essenziali ed alle altre disposizioni pertinenti stabilite dalla direttiva 1999/5/CE.

Por medio de la presente Tokai Rika Co., Ltd. declara que el B76EA cumple con los requisitos esenciales y cualesquiera otras disposiciones aplicables o exigibles de la Directiva 1999/5/CE.

Tokai Rika Co., Ltd. declara que este B76EA está conforme com os requisitos essenciais e outras disposições da Directiva 1999/5/CE.

Hawnhekk, Tokai Rika Co., Ltd., jiddikjara li dan B76EA jikkonforma mal-ħtiġijiet essenzjali u ma provvedimenti oħrajn relevanti li hemm fid-Dirrettiva 1999/5/EC.

Käesolevaga kinnitab Tokai Rika Co., Ltd. seadme B76EA vastavust direktiivi 1999/5/EÜ põhinõuetele ja nimetatud direktiivist tulenevatele teistele asjakohastele sätetele.

Alulírott, Tokai Rika Co., Ltd. nyilatkozom, hogy a B76EA megfelel a vonatkozó alapvető követelményeknek és az 1999/5/EC irányelv egyéb előírásainak.

Tokai Rika Co., Ltd. týmto vyhlasuje, že B76EA spĺňa základné požiadavky a všetky príslušné ustanovenia Smernice 1999/5/ES.

Tokai Rika Co., Ltd. tímto prohlašuje, že tento B76EA je ve shodě se základními požadavky a dalšími příslušnými ustanoveními směrnice 1999/5/ES.

Tokai Rika Co., Ltd. izjavlja, da je ta B76EA v skladu z bistvenimi zahtevami in ostalimi relevantnimi določili direktive 1999/5/ES.

Šiuo Tokai Rika Co., Ltd. deklaruoja, kad šis B76EA atitinka esminius reikalavimus ir kitas 1999/5/EB Direktyvos nuostatas.

Ar šo Tokai Rika Co., Ltd. deklarē, ka B76EA atbilst Direktīvas 1999/5/EK būtiskajām prasībām un citiem ar to saistītajiem noteikumiem.

Niniejszym Tokai Rika Co., Ltd. oświadcza, że B76EA jest zgodny z zasadniczymi wymogami oraz pozostałymi stosownymi postanowieniami Dyrektywy 1999/5/EC.

Hér með lýsir Tokai Rika Co., Ltd. yfir því að B76EA er í samræmi við grunnkröfur og aðrar kröfur, sem gerðar eru í tilskipun 1999/5/EC.

Tokai Rika Co., Ltd. erklærer herved at utstyret B76EA er i samsvar med de grunnleggende krav og øvrige relevante krav i direktiv 1999/5/EF.

С настоящето, Tokai Rika Co., Ltd., декларира, че В76EA е в съответствие със съществените изисквания и другите приложими разпоредби на Директива 1999/5/EC.

Prin prezenta, Tokai Rika Co., Ltd., declară că aparatul B76EA este in conformitate cu cerințele esențiale și cu alte prevederi pertinente ale Directivei 1999/5/CE.

Ovim, Tokai Rika Co., Ltd., izjavljuje da ovaj B76EA je usklađen sa bitnim zahtjevima i drugim relevantnim odredbama Direktive 1999/5/EC.

Nepermjet kesaj, Tokai Rika Co., Ltd., deklaroj qe ky B76EA eshte ne pajtim me kerkesat thelbesore dhe dispozitat e tjera perkatese te Direktives 1999/5/EC.

Ovim Tokai Rika Co., Ltd., izjavljuje da je B76EA u sklau s bitnim zahtjevima i drugim relevantnim odredbama Direktive 1999/5/EC i Pravilnika o RiTT opremi (NN 25/2012).

Ovim, Tokai Rika Co., Ltd., deklariše da je B76EA u skladu sa osnovnim zahtevima i ostalim relevantnim odredbama Direktive 1999/5/EC.

İşbu belge ile Tokai Rika Co., Ltd., bu B76EA ürününün 1999/5/EC Yönetmeliği'nin temel gerekliliklerine ve diğer ilgili hükümlerine uygun olduğunu beyan eder.

The DECLARATION of CONFORMITY (DoC) is available at the following address: http://www.tokai-rika.co.jp/pc





تلفن شبانه روزی: ۱۵۸۰۲۹۸۸ - ۲۱



Observe the following precautions.

Failing to do so may result in death or serious injury.

■ When using the wireless remote control and operating the power windows or moon roof

Operate the power window or moon roof after checking to make sure that there is no possibility of any passenger having any of their body parts caught in the window or moon roof. Also, do not allow children to operate the wireless remote control. It is possible for children and other passengers to get caught in the power window or moon roof.

- Jam protection function
 - Never try jamming any part of your body to activate the jam protection function intentionally.
 - The jam protection function may not work if something gets caught just before the window or moon roof fully closes.




Doors

Unlocking and locking the doors

The vehicle can be locked and unlocked using the entry function, wireless remote control or door lock switches.

- Entry function
 - \rightarrow P.153
- ◆ Wireless remote control
 - \rightarrow P. 177
- Door lock switches
 - 1 Locks all the doors
 - (2) Unlocks all the doors




◆ Inside lock buttons

- 1 Locks the door
- (2) Unlocks the door

For Korea and other countries with airbag manual on-off system except South Africa: The front doors can be opened by pulling the inside handle even if the lock buttons are in the lock position.

Other than listed above: The driver's door can be opened by pulling the inside handle even if the lock button is in the lock position.





تلفن شبانه روزی: ۱۳۵۰ ۱۳۹۸ - ۲۱ م

Locking the front doors from the outside without a key

- ▶ Except for Korea
- 1 Move the inside lock button to the lock position.
- **2** Close the door while pulling the door handle.
- ▶ For Korea
- 1 Move the inside lock button to the lock position.
- 2 Close the door.

The door cannot be locked if the engine switch is in ACCESSORY or IGNITION ON mode, or the electronic key is left inside the vehicle.


The key may not be detected correctly and the door may be locked.

Rear door child-protector lock

The door cannot be opened from inside the vehicle when the lock is set.

- 1 Unlock
- 2 Lock

These locks can be set to prevent children from opening the rear doors. Push down on each rear door switch to lock both rear doors.



Automatic door locking and unlocking systems

The following functions can be set or canceled:

For instructions on customizing, refer to P. 667.

Function	Operation
Speed linked door locking function	All doors are automatically locked when vehicle speed is approximately 20 km/h (12 mph) or higher.
Shift position linked door locking function	All doors are automatically locked when shifting the shift lever to position other than P.
Shift position linked door unlocking function	All doors are automatically unlocked when shifting the shift lever to P.
Driver's door linked door unlocking function	All doors are automatically unlocked when driver's door is opened.

■ Impact detection door lock release system

In the event that the vehicle is subject to a strong impact, all the doors are unlocked. Depending on the force of the impact or the type of accident, however, the system may not operate.

Door closer

In the event that a door is left slightly open, the door closer will automatically close it to the fully closed position.

- The door closer will operate regardless of the engine switch mode.
- The door closer will not function if the door has been closed while pulling the inside or outside door handle.
- The door can be opened by pulling the inside or outside door handle, even when the door closer is operating (except when the lock button is in the lock position or the child-protector lock is set).
- The motor sound may be heard for several seconds after the door closer closes the door. This does not indicate a malfunction.

■ Using the mechanical key

The doors can also be locked and unlocked with the mechanical key. $(\rightarrow P. 631)$

■ If a wrong key is used

The key cylinder rotates freely to isolate inside mechanism.

■ Customization

Settings (e.g. unlocking function using a key) can be changed. (Customizable features →P. 667)

A CAUTION

■To prevent an accident

Observe the following precautions while driving the vehicle.

Failure to do so may result in a door opening and an occupant throwing out of the vehicle, resulting in death or serious injury.

- Ensure that all doors are properly closed and locked.
- Do not pull the inside handle of the doors while driving.
- For Korea and other countries with airbag manual on-off system except South Africa

Be especially careful for the front doors, as the doors may be opened even if the inside lock buttons are in locked position.

► Other than listed above

Be especially careful for the driver's door, as the door may be opened even if the inside lock button is in locked position.

• Set the rear door child-protector locks when children are seated in the rear seats.

 $\wedge\omega$: تلفن شبانه روزی

Door closer

In the event that a door is left slightly open, the door closer will automatically close it to the fully closed position.

If the child-protector lock is set, the door closer will not stop during operation even if an attempt is made to open the door from inside the vehicle. Be careful not to catch fingers or anything else in the door. Failure to do so may result in serious injury.

↑ NOTICE

■ To prevent door closer malfunction

Do not frequently repeat opening and closing of doors, or apply excessive force to a door while the door closer is operating.

Trunk

The trunk can be opened using the trunk opener, entry function or wireless remote control.

The trunk can be closed using the trunk closer.

Opening the trunk from inside the vehicle

Press the opener switch.

The trunk lid automatically opens fully.



Opening the trunk from outside the vehicle

- تلفن شبانه روزی: ۱۳۰۵ Entry function ۲۱−۸۸۸۶۲ میاند دروزی: ۱۳۰۵ استان شبانه روزی: ۱۳۰۵ استان ا
 - \rightarrow P. 153
- Wireless remote control aSOS.com
 - \rightarrow P.177

Trunk closer switch


Pressing the switch closes the trunk lid automatically. (A buzzer sounds.)

Pressing the switch while the trunk lid is closing opens the trunk lid again.



When closing the trunk

Using the trunk grip, lower the trunk without applying force to the side and push the trunk down from the outside to close it.




Luggage security system

The trunk opener switch can be temporarily disabled to protect luggage stored in the trunk against theft.

Turn the main switch in the glove box off to disable the trunk opener.

- (1) On
- 2 Off

The trunk lid cannot be opened even with the wireless remote control or the entry function.



■ Trunk lid light/trunk light

The trunk lid light/trunk light turns on when the trunk is opened.

■ Trunk easy closer

In the event that the trunk lid is left slightly open, the trunk easy closer will automatically close it to the fully closed position.

■ Function to prevent the trunk being locked with the electronic key inside (when all the doors are locked)

Closing the trunk lid with the electronic key left inside the trunk will sound an alarm. In this case, the trunk lid can be opened by pressing the button on the trunk lid.

■ Overload protection function

The trunk lid will not operate when excessive load is present on the top of the trunk lid.

■ Fall-down protection function

While the trunk lid is opening automatically, applying excessive force to it will stop the opening operation to prevent the trunk lid from rapidly falling down.

■ Jam protection function

While the trunk lid is closing automatically, the trunk lid will stop closing and open if something gets caught.

■ Internal trunk release lever (for Korea)

The trunk lid can be opened by pulling the glow-in-the-dark lever located on the inside of the trunk lid to the side.

The lever will continue to glow for some time after the trunk lid is closed.



■ Using the mechanical key

The trunk can be also opened using the mechanical key. $(\rightarrow P. 633)$

■ When leaving a key to the vehicle with a parking attendant

 \rightarrow P.146

Observe the following precautions.

Failure to do so may result in death or serious injury.

■ Before driving

- Make sure that the trunk lid is fully closed. If the trunk lid is not fully closed, it may
 open unexpectedly while driving and hit near-by objects or luggage in the trunk
 may be thrown out, causing an accident.
- Do not allow children to play in the trunk.
 If a child is accidentally locked in the trunk, they could suffer from heat exhaustion, suffocation or other injuries.
- Do not allow a child to open or close the trunk lid.
 Doing so may cause the trunk lid to open unexpectedly, or cause the child's hands, head, or neck to be caught by the closing trunk lid.

Important points while driving

Never let anyone sit in the trunk. In the event of sudden braking or a collision, they are susceptible to death or serious injury.

تلفن شبانه روزی: ۱۵۸۰۲۹۸۸۸–۲۲۰

■ Using the trunk

Observe the following precautions.

Failure to do so may cause parts of the body to be caught, resulting in serious injury.

- Remove any heavy loads, such as snow and ice, from the trunk lid before opening it. Failure to do so may cause the trunk lid to suddenly shut again after it is opened.
- When opening or closing the trunk lid, thoroughly check to make sure the surrounding area is safe.
- If anyone is in the vicinity, make sure they are safe and let them know that the trunk is about to open or close.
- Use caution when opening or closing the trunk lid in windy weather as it may move abruptly in strong wind.
- The trunk lid may suddenly shut if it is not opened fully. It is more difficult to open or close the trunk lid on an incline than on a level surface, so beware of the trunk lid unexpectedly opening or closing by itself. Make sure that the trunk lid is fully open and secure before using the trunk.




- When closing the trunk lid, take extra care to prevent your fingers etc. from being caught.
- When closing the trunk lid, make sure to press it lightly on its outer surface. If the trunk handle is used to fully close the trunk lid, it may result in hands or arms being caught.



• Do not attach any accessories other than genuine Lexus parts to the trunk lid. Such additional weight on the trunk lid may cause the lid to suddenly shut again after it is opened.

■Trunk easy closer

In the event that the trunk lid is left slightly open, the trunk easy closer will automatically close it to the fully closed position. It takes several seconds before the trunk easy closer begins to operate. Be careful not to catch fingers or anything else in the trunk lid, as this may cause bone fractures or other serious injuries.



■ Power trunk lid

Observe the following precautions when operating the power trunk lid. Failure to do so may cause serious injury.

- Check the safety of the surrounding area to make sure there are no obstacles or anything that could cause any of your belongings to get caught.
- If anyone is in the vicinity, make sure they are safe and let them know that the trunk is about to open or close.
- If the trunk closer switch is pressed while the trunk lid is opening during automatic operation, the trunk lid stops opening. Take extra care when on an incline, as the trunk lid may open or close suddenly.
- On an incline, the trunk lid may suddenly shut after it opens automatically. Make sure the trunk lid is fully open and secure before using the trunk.
- In the following situations, the power trunk lid may detect an abnormality and automatic operation may be stopped. In this case, the trunk lid has to be operated manually. Take extra care in this situation, as the stopped trunk lid may suddenly shut, causing an accident.
 - · When the trunk lid contacts an obstacle
 - When the battery voltage suddenly drops, such as when the engine switch is turned to IGNITION ON mode or the engine is started during automatic operation
- Do not attach any accessories other than genuine Lexus parts to the trunk lid. The power trunk lid may not operate, causing itself to malfunction, or the trunk lid may suddenly shut again after it is opened.

■ Jam protection function

Observe the following precautions.

Failure to do so may cause serious injury.

- Never use any part of your body to intentionally activate the jam protection function.
- The iam protection function may not work if something gets caught just before the trunk lid fully closes. Be careful not to catch fingers or anything else in the trunk lid.
- The jam protection function may not work depending on the shape of the object that is caught. Be careful not to catch fingers or anything else.

NOTICE

■ To prevent trunk easy closer malfunctions


Do not apply force to the trunk lid while the trunk easy closer is operating.

■ To prevent damage to the power trunk lid

- Make sure that there is no luggage or snow on the trunk lid before operating the power trunk lid. In addition, make sure that there is no ice between the trunk lid and frame that prevents movement of the trunk lid. Operating the power trunk lid when excessive load is present on the trunk lid may cause a malfunction.
- Do not apply excessive force to the trunk lid while the power trunk lid is operating.

Front seats

Adjustment procedure



(1) Seat position adjustment switch

The height of the driver's head restraint is automatically adjusted simultaneously with the seat position adjustment operation.

 $oldsymbol{\Omega}$ تلفن شبانه روزی:

- (2) Seatback angle adjustment switch
- (3) Head restraint height adjustment switch (\rightarrow P. 225)
- (4) Seat cushion (front) angle adjustment switch
- (5) Vertical height adjustment switch
- 6 Lumbar/pelvic support adjustment switch

Driver's seat: firmness, vertical, backward and forward positioning


Front passenger's seat: firmness, backward and forward positioning (if equipped)

- (7) Seat cushion length adjustment switch
- (8) Ottoman angle adjustment switch (if equipped)

If forward adjustment is performed while the ottoman is raised, the ottoman will move downward.


Operating the front passenger's seat from the driver's seat

- ▶ Vehicles without relaxation seat
- 1 Tilts the seatback forward
- (2) Tilts the seatback backward
- (3) Moves the seat forward
- (4) Moves the seat backward



- ▶ Vehicles with relaxation seat
- 1) Tilts the seatback forward and moves the seat forward
- 2 Tilts the seatback backward and moves the seat backward

If the rear seat is not in the neutral position, pressing the button once will move the rear seat to the neutral position. Pressing the button again will move the front passenger's seat to the neutral position.



- (3) Tilts the seatback forward
- (4) Tilts the seatback backward
- (5) Moves the seat forward
- (6) Moves the seat backward


Operating the front passenger's seat from the rear seat (vehicles with relaxation seat)

- ▶ 5-seat models
- 1 Moves the front passenger's seat forward

The signal beeps when the seat operation stops at the forward limit.

2) Moves the front passenger's seat backward

The seatback will return to the neutral position. If the head restraint is folded, it will rise before the seatback moves.




1 Moves the front passenger's seat forward

The signal beeps when the seat operation stops at the forward limit.

2 Moves the front passenger's seat backward

The seatback will return to the neutral position. If the head restraint is folded, it will rise before the seatback moves.






Power easy access system

The seat and steering wheel are automatically adjusted to allow the driver or front passenger to enter and exit the vehicle easily.

■ Driver's seat

When all of the following have been performed, the driver's seat and steering wheel are automatically adjusted to a position that allows driver to enter and exit the vehicle easily.

- The shift lever has been shifted to P.
- The engine switch has been turned off.
- The driver's seat belt has been unfastened.



When any of the following has been performed, the driver's seat and steering wheel automatically return to their original positions.

- The engine switch has been turned to ACCESSORY mode.
- The driver's seat belt has been fastened.

■ Front passenger's seat

If the front passenger's door is opened while the vehicle is stopped, the adjusted lumbar/pelvic support (if equipped), ottoman (if equipped), etc. will return to its original position.

■ Operating the foldable head restraint (vehicles with relaxation seat)

- If the seatback angle is adjusted using the switches located on the side of the front passenger's seat or center console when the engine switch is in IGNITION ON mode, the head restraint will operate as follows:
 - When tilting the seatback forward: After the seatback movement ends, the head
 restraint starts to rise and fold. A signal beeps once operation is complete. If the
 switch is released during the operation, the head restraint will return to the neutral position.
 - When tilting the seatback backward: If the head restraint is folded, it will return to the neutral position.
- In the following situations, the head restraint will not operate even when the seat-back angle adjustment switch is operated:
 - · The engine switch is off.
 - The weight of an occupant or heavy object, etc. is detected on the front passenger's seat.
 - The front passenger's seat belt is fastened.
 - The front passenger's door is open.

Operating the front passenger's seat from the rear seat (vehicles with relaxation seat)

The front passenger's seat can be operated when the engine switch is in IGNITION ON mode. However, in the following situations, the front passenger's seat does not move even when the switch is operated:

- The weight of an occupant or heavy object etc. is detected on the front passenger's seat.
- The front passenger's seat belt is fastened.
- The front passenger's door is open. (The front seat will not move forward.)

■ Seat cushion automatic length adjustment (driver's seat)

If the front of the cushion gets too close to the area around the instrument panel when the seat position is being adjusted, the seat cushion will automatically retract.

■ Seat operation automatic stop function (vehicles with relaxation seat)

If a front seat is likely to come into contact with the retractable table (4-seat models) or the ottoman during seat operation or activation of the power easy access system, a buzzer will sound and seat slide operation will be stopped partway.

(A warning message will be shown on the multi-information display.)

■ Power easy access system operations

- When exiting the vehicle, the power easy access system may not operate if the seat is already close to the rearmost position, etc.
- If the seat position is adjusted during the power easy access system operation, the operation will stop.
- If the seat position is adjusted during or after the power easy access system operation when the driver is exiting the vehicle, the power easy access system will not operate when entering the vehicle.

■ Customization

The distance that the driver's seat moves backward during the power easy access system can be changed. (Customizable features \rightarrow P. 667)

A CAUTION

■ When adjusting the seat position

- Take care when adjusting the seat position to ensure that other passengers are not injured by the moving seat.
- Do not put your hands under the seat or near the moving parts to avoid injury.
 Fingers or hands may become jammed in the seat mechanism.

■ Seat adjustment

To reduce the risk of sliding under the lap belt during a collision, do not recline the seat more than necessary.

If the seat is too reclined, the lap belt may slide past the hips and apply restraint forces directly to the abdomen, or your neck may contact the shoulder belt, increasing the risk of death or serious injury in the event of an accident.

Adjustments should not be made while driving as the seat may unexpectedly move and cause the driver to lose control of the vehicle.

Operating the front passenger's seat from the driver's seat or rear seat

Do not operate the front passenger's seat when a passenger is seated in it. In addition, do not let anyone sit down in the front passenger's seat while the seat is being operated or when the head restraint is being folded. The front passenger may catch their legs between the instrument panel and seat, or the head restraint may interfere with their head, resulting in injury.

 \blacksquare When adjusting the seat positions or the front passenger ottoman (if equipped)

Make sure to leave enough space around the feet so they do not get stuck.

- When using the front passenger ottoman (if equipped)
 - Do not operate the front passenger ottoman when the vehicle is moving.
 Failure to do so may cause death or serious injury in the event of sudden braking or a collision.
 - Do not sit on the front passenger ottoman of the passenger seat.
 Doing so may cause seat belts to be worn improperly, which may lead to serious injury or death in the event of sudden braking or a collision.
 - Do not step on the front passenger ottoman.
 Doing so could damage the front passenger ottoman, or could cause you to seriously injure yourself by falling over.
 - Stow the front passenger ottoman when you get in or out of the vehicle or when the front passenger ottoman is not in use to avoid stumbling over it.
 - Do not allow anyone to put their hands or feet under the passenger seat when stowing the front passenger ottoman.

تلفن شبانه روزی: NOTICE + ۲ \ −۸۸۸۶۲ + ۸۵


Operating the front passenger's seat from the driver's seat or rear seat

Before operating the front passenger's seat, make sure that there is no luggage or any other objects on the seat or in the footwell that could prevent its operation. Such items may result in excess force being applied, causing damage to the seat and/or the luggage.

- To prevent a front passenger ottoman malfunction (if equipped)
 - Do not place any objects in the front passenger footwell that could prevent the operation of the front passenger ottoman.
 - Do not place heavy luggage on the front passenger ottoman.
 - Do not place anything under the front passenger ottoman when in use. There is a possibility that something may get caught and cause damages when stowing the front passenger ottoman.

Power rear seat*

▶ 5-seat models without relaxation seat




1 Seat selection switch

The indicator light for the seat that can be operated comes on.

- (2) Seat position adjustment switch
- تلفن شبانه روزی: Seatback upper angle adjustment switch
- (4) Head restraint height adjustment switch $(\rightarrow P. 225)$
- 5 Pelvic support seat switches SOS. COM

▶ 5-seat models with relaxation seat




This illustration is for a left-hand drive vehicle.

The right-hand rear seat (left-hand drive vehicle) or left-hand rear seat (right-hand drive vehicle) is a relaxation seat, which is equipped with a seatback angle adjustment function and an ottoman.

- Seat selection switch
 The indicator light for the seat that can be operated comes on.
- 2 Seat position adjustment switch
- 3 Seatback upper angle adjustment switch
- 4 Head restraint height adjustment switch (\rightarrow P. 225)
- (5) Seatback angle adjustment switch
- 6 Ottoman angle adjustment switch
- 7 Front passenger's seat control switch (\rightarrow P. 200)
- 8 Relaxation mode switch
- Rear seat relaxation system/pelvic support seat switches
- 10 Pelvic support seat switches

▶ 4-seat models



The right-hand rear seat (left-hand drive vehicle) or left-hand rear seat (right-hand drive vehicle) is a relaxation seat, which is equipped with a seatback angle adjustment function and an ottoman.

- Seat selection switch
 The indicator light for the seat that can be operated comes on.
- (2) Seat position adjustment switch مراكب المعالية المعا
- 3 Seatback upper angle adjustment switch
- 4 Head restraint height adjustment switch (\rightarrow P. 225)
- (5) Seatback angle adjustment switch
- 6 Ottoman angle adjustment switch
- 7 Front passenger's seat control switch (\rightarrow P. 200)
- 8 Relaxation mode switch
- Rear seat relaxation system/pelvic support seat controller

Seat return function linked to the door opening operation

The seat will return to the neutral position automatically when the door is opened for easier entry and exit of the vehicle.

Returning the rear seat from the front seats


▶ Vehicles without relaxation seat

The seat will return to the neutral position while the button is pressed and held.



Vehicles with relaxation seat

The seat will return to the neutral position while the button is pressed and held.



FarmaS

Relaxation mode operation (relaxation seat)

Relaxation mode can be entered by operating a switch. The front passenger seat will move forward, and then the seatback of the relaxation seat will recline and the ottoman will simultaneously rise.

▶ 5-seat models

Pressing the switch will cause a beep to sound and operation will start.

- 1 Enters relaxation mode
- 2 Returns to the neutral position


To stop the operation part-way through, press either side of the switch again, or press any other seat adjustment button.




Pressing the switch will cause a beep to sound and operation will start.

- 1) Enters relaxation mode
- 2 Returns to the neutral position

To stop the operation part-way through, press either side of the switch again, or press any other seat adjustment button.





Pelvic support seat with seat vibrator

Pelvic support seat with seat vibrator, which features a support plate mounted in the seatback and a vibration function, is equipped on each outer rear seat. The support plate position and vibration speed can be adjusted according to the occupant's preferences.


▶ 5-seat models without relaxation seat



- 1) Support plate position adjustment switch
- (2) Vibration switch

Press to operate the vibration function. Vibration will start in the same speed level as when previously operated. Each time is pressed, the speed changes between 3 levels. Pressing "OFF" stops the vibration function.

▶ 5-seat models with relaxation seat




This illustration is for a left-hand drive vehicle.

- 1 Support plate position adjustment switch
- (2) Vibration switch

Press to operate the vibration function. Vibration will start in the same speed level as when previously operated. Each time is pressed, the speed changes between 3 levels. Pressing "OFF" stops the vibration function.

- ▶ 4-seat models
- 1 Support plate position adjustment switch
- 2 Vibration switch


Press to operate the vibration function. Vibration will start in the same speed level as when previously operated. Each time to pressed, the speed changes between 3 levels. Pressing "OFF" stops the vibration function.



Rear seat relaxation system (vehicles with relaxation seat)

Pneumatic chambers built into the right-hand rear seat (left-hand drive vehicles) or the left-hand rear seat (right-hand drive vehicles) provide the occupant with pressure of different speeds and intensities.

▶ 5-seat models



- 1 Turns the system on and off

 If no buttons are selected within approximately 3 minutes of operating this switch, the system will automatically turn off.
- 2 Starts the program partial pressure for the whole back
- 3 Starts the program
 Stretches and relaxes the lower back


- 4 Starts operation for the upper back
- 5 Starts operation for the lower back
- 6 Adjusts the intensity of the air pressure
 - 3 intensity levels are available.
- 7 Adjusts the speed of the air unit3 speed levels are available.

- ▶ 4-seat models
- 1 Turns the system on and off

 If no buttons are selected within approximately 3 minutes of operating this switch, the system will automatically turn off.
- 2 Starts the program Partial pressure for the whole back
- 3 Starts the program Stretches and relaxes the lower back
- 4 Starts operation for the upper back



- 6 Adjusts the intensity of the air pressure
 - 3 intensity levels are available. ٢٠٠٨ : تلفن شبانه روزى:
- 7 Adjusts the speed of the air unit
 3 speed levels are available. SOS.com



■ Seat return function linked to the door opening operation

- Operating conditions
 The engine switch is in IGNITION ON mode.
- Canceling operation partway through
 During the seat return operation, performing either of the following actions cancels the operation:
 - Pressing the "SET", "M" or "C" button (→P. 223)
 - · Pressing any of the seat adjustment switches
- Disabling the seat return function
 Pressing the "C" button will disable the seat return function.

The indicator light comes on when the seat return function is disabled.

Pressing the button again will enable the seat return function.



Seat return operation after turning the engine switch off The seat will automatically return to the neutral position if the door is opened within approximately 45 seconds of the engine switch being turned off.

■ Relaxation mode (relaxation seat)

- Operating conditions
 Relaxation mode can be entered when the engine switch is in IGNITION ON mode. However, in the following situations, relaxation mode cannot be entered even when the switch is operated:
 - The weight of an occupant or heavy object etc. is detected on the front passenger's seat.
 - The front passenger's seat belt is fastened.
 - The front passenger's door is open. (The front seat will not move forward.)
- Operation after turning the engine switch off The rear seat can be returned to the neutral position as long as the relaxation mode switch is operated within approximately 45 seconds of the engine switch being turned off.

■ Pelvic support seat with seat vibrator

- Operating conditions
 The engine switch is in IGNITION ON mode.
- Automatic stop function
 - Vibration will automatically stop approximately 15 minutes after starting.
 - Vibration will automatically stop if the adjacent rear door is opened.
- Pelvic support seat return function The position of the support plate will automatically return to the neutral position if the adjacent rear door is opened.

■ Rear seat relaxation system (vehicles with relaxation seat)

- Operating conditions
 The engine switch is in IGNITION ON mode.
- Automatic stop function
 Each operation will automatically stop approximately 15 minutes after starting.





■ Power rear seats

Seat adjustment

To reduce the risk of sliding under the lap belt during a collision, do not recline the seat more than necessary.

If the seat is too reclined, the lap belt may slide past the hips and apply restraint forces directly to the abdomen, or your neck may contact the shoulder belt, increasing the risk of death or serious injury in the event of an accident.

Adjustments should not be made while driving as the seat may unexpectedly move and cause the driver to lose control of the vehicle.

 When adjusting the seat position and ottoman angle (vehicles with relaxation seat)

Keep sufficient footwell space to prevent your feet from being caught by the front seat.

- When returning the rear seats to the neutral position
 To avoid injuring the rear passengers, wait until they have gotten out of the vehicle before operating the switch.
- Using the ottoman (vehicles with relaxation seat)
 - Do not sit on the ottoman.
 If someone sits on the ottoman, the seat belt cannot be fitted properly, and they may be thrown from the seat, resulting in death or serious injury in the event of an accident or sudden braking.
 - When getting in or out of the vehicle, retract the ottoman. If the ottoman is not retracted, it may cause a fall, resulting in injury.
 - Do not operate the ottoman when the vehicle is moving.
 - Do not allow anyone to put their hands or feet under the passenger seat when stowing the ottoman.

■ Using the pelvic support seat with seat vibrator and rear seat relaxation system

- Those who are pregnant, have recently given birth, or suffer from ailments requiring rest (heart disease etc.) should consult a doctor before use.
- Do not allow children to use the pelvic support seat vibration function or the rear seat relaxation function.
- Do not use immediately after consuming a meal or alcohol, or for an extended period of time.
- If you feel sick while using the pelvic support seat vibration function or the rear seat relaxation function, immediately discontinue use.

♠ NOTICE

- To prevent an ottoman malfunction (vehicles with relaxation seat)
 - Do not place any objects in the rear seat footwell that could prevent the operation of the ottoman.
 - Do not place heavy luggage on the ottoman.
 - Do not place any objects under the ottoman while it is raised for use. These objects may interfere with the ottoman being folded, causing damage to the ottoman or the objects themselves.



تلفن شبانه روزی: ۱۵۸۰۲۹۸۸ - ۲۱

Driving position memory

This feature automatically adjusts the front seats, steering wheel, outside rear view mirrors and height of seat belt shoulder anchor to suit your preferences.

Driving position memory

Your preferred driving position (the position of the driver's seat, steering wheel, outside rear view mirrors and height of seat belt shoulder anchor) can be recorded and recalled by pressing a switch.

Three different driving positions can be recorded into memory.

■ Recording procedure

- 1 Check that the shift lever is in P.
- 2 Turn the engine switch to IGNITION ON mode.
- 3 Adjust the driver's seat, steering wheel, outside rear view mirrors and seat belt shoulder anchor height to the desired positions.
- 4 Press the "SET" switch, then within 3 seconds press switch "1", "2" or "3" until the buzzer sounds.


If the selected switch has already been preset, the previously recorded position will be overwritten.



To record the position of the front passenger's seat, adjust the front passenger's seat to the desired position and perform step 4 using the switches on the front passenger's side.

■ Recall procedure

- 1 Check that the shift lever is in P.
- **2** Turn the engine switch to IGNITION ON mode.
- 3 Press one of the switches for the driving position you want to recall until the buzzer sounds



■ When you want to stop the position recall operation part-way through

Perform any of the following operations:

- Press the "SET" switch.
- Press switch "1", "2" or "3".
- Operate any of the seat adjustment switches (only cancels seat position recall).
- Operate the tilt and telescopic steering control switch (only cancels steering wheel position recall).
- Operate the seat belt shoulder anchor height adjusting switch (only cancels height of seat belt shoulder anchor recall).

■ Front passenger's seat position recall limitations

Vehicles with front passenger ottoman:

The memorized position will only be recalled if the front passenger ottoman is in a position higher than the memorized position. It will not move in an upward direction.

Vehicles with relaxation seat:

When retractable table (4-seat models) or ottoman is used, rearward memories cannot be recalled.

■ Automatic front passenger ottoman adjustment (if equipped)

While the memorized position is being recalled, if it appears that the front edge of the cushion will make contact with the area surrounding the instrument panel, the front passenger ottoman will be automatically stowed.

Operating the driving position memory after turning the engine switch off

Driver's seat:

Recorded driving positions (except the steering wheel position) can be recalled up to 180 seconds after the driver's door is opened and up to 60 seconds after it is closed again.

Front passenger's seat:

Recorded seat positions can be recalled up to 180 seconds after the front passenger's door is opened.

■ In order to correctly use the driving position memory function

If a seat position is already in the furthest possible position and the seat is operated in the same direction, the recorded position may be slightly different when it is recalled.

Memory recall function (driver's side only)

Each electronic key (including a card key) can be registered to recall your preferred driving position.

■ Registering procedure

Record your driving position to switch "1", "2" or "3" before performing the following:

- لفن شبانه روزی: Using the wireless remote control
- 1 Turn the engine switch off and close the driver's door.
- while pressing the desired switch ("1", "2" or "3"), press on the wireless remote control until the buzzer sounds.



To prevent unintended triggering of the alarm, open and close a door once after a driving position has been recorded. (If a door is not opened within 30 seconds after is pressed, the doors will be locked again and the alarm will automatically be set.)

In case that the alarm is triggered, immediately stop the alarm.

 $(\to P. 113)$

▶ Using the door lock switch

Carry only one of the keys (including the card key) to which you want to link the driving position. If 2 or more keys are in the vehicle, the driving position cannot be linked properly.

- 1 Turn the engine switch off and close the driver's door.
- while pressing the recalled switch, press and hold the door lock switch (either lock or unlock) until the buzzer sounds.



■ Recall procedure

1 Carry the electronic key that has been registered to the driving position, and then unlock and open the driver's door using the smart entry & start system or wireless remote control.

The driving position will move to the recorded position (not including the steering wheel). However, the seat will move to a position slightly behind the recorded position in order to make entering the vehicle easier.

If the driving position is in a position that has already been recorded, the seat and outside rear view mirrors will not move.

2 Turn the engine switch to ACCESSORY mode or fasten your seatbelt.

The seat and steering wheel will move to the recorded position.

■ Cancelation procedure

- Using the wireless remote control
- 1 Turn the engine switch off and close the driver's door.
- **2** While pressing the "SET" switch, press on the wireless remote control until the buzzer sounds.
- ▶ Using the door lock switch

Carry only the key you want to cancel and then close the driver's door. If 2 or more keys are in the vehicle, the driving position cannot be canceled properly.

- 1 Turn the engine switch off and close the driver's door.
- 2 While pressing the "SET" switch, press the lock or unlock side on the door lock switch until the buzzer sounds.

Recalling the driving position using the memory recall function

- Different driving positions can be registered for each electronic key. Therefore, the driving position that is recalled may be different depending on the key being carried.
- If a door other than the driver's door is unlocked with the smart entry & start system, the driving position cannot be recalled. In this case, press the driving position switch which has been set.
- Seat operation automatic stop function (vehicles with relaxation seat)

If a front seat is likely to come into contact with the retractable table (4-seat models) or the ottoman during seat operation or activation of the power easy access system, a buzzer will sound and seat slide operation will be stopped partway. (A warning message will be shown on the multi-information display.)

A CAUTION

■ Seat adjustment caution

Take care during seat adjustment so that the seat does not strike the rear passenger or squeeze your body against the steering wheel.


Rear seat position memory*

The rear seat position can be memorized and recalled with the touch of a button.

Entering a position to memory

- 1 Turn the engine switch to IGNITION ON mode.
- **2** Adjust the rear seat to the desired position.
- **3** Press the "SET" button until the signal beeps.

If the preset is being used, the previously recorded seat position will be overwritten.



Recalling the memorized position

Press the "M" button until the signal beeps.

Relaxation seat:

The memorized position will only be recalled if the ottoman is in a position higher than the memorized position. It will not move in an upward direction.



Disabling the seat return function

Pressing the "C" button will disable the seat position recall or seat return function.

The indicator light comes on when the function is disabled.

Pressing the button again will enable the seat position recall or seat return function



■ Seat return function linked to the door opening operation

Operating conditions

The engine switch is in IGNITION ON mode.

Canceling operation partway through

During the seat return operation, performing either of the following actions cancels the operation:

- Pressing the "SET", "M" or "C" button
- Pressing any of the seat adjustment switches
- الفن شيانه روزي Seat return operation after turning the engine switch off

The seat will automatically return to the neutral position if the door is opened within approximately 45 seconds of the engine switch being turned off.

A CAUTION

■ Seat adjustment caution


Take care during seat adjustment so that the rear passengers do not strike the front seats.

Head restraints

Head restraints are provided for all seats.

Front seats

- 1 Vertical adjustment
- 7 Horizontal adjustment*



*: For vehicles with relaxation seat, driver's seat only.

Outer rear seats

- Manual type
 Vertical adjustment


 Power type


 Vertical adjustment

Pull the head restraints up when rais- 2 Side support adjustment

Push and hold the lock release button when lowering.


(2) Horizontal adjustment





Rear center seat (5-seat models)


- 1 To use
- 2 To fold



Active head restraints* (not available for a foldable head restraint)

If the vehicle detects an impact during a rear-end collision, the front part of the head restraint moves forward and upward to help reduce the risk of whiplash to the seat occupant.

When reversing, even a small amount of force applied from the rear, such as a minor rear impact, may cause the head restraints to move.



FarmaSOS.com


*: Front seats

■ Removing the head restraints

For removal and installation of the head restraint, contact your Lexus dealer.

Adjusting the height of the head restraints (except rear center seat)

Make sure that the head restraints are adjusted so that the center of the head restraint is closest to the top of your ears.



■ When using the rear seat head restraints

Manual type:

Always raise the head restraint one level from the stowed position when using.

Rear center seat:

Make sure to pull the head restraint forward when using the rear center seat.

■ Active head restraints (if equipped)

- The active head restraint on the front passenger seat will not activate if the seat is unoccupied. However, it may activate during a rear-end collision if luggage is in the seat or the seat belt is fastened.
- Once the active head restraint has activated, the head restraint remains protruded forward and upward. After it has operated, have it repaired at your Lexus dealer.

A CAUTION

Head restraint precautions

Observe the following precautions regarding the head restraints. Failure to do so may result in death or serious injury.

- Use the head restraints designed for each respective seat.
- Adjust the head restraints to the correct position at all times.
- Manual type: After adjusting the head restraints, push down on them and make sure they are locked in position.
- Do not drive with the head restraints removed.
- The active head restraint on the front passenger seat (if equipped)

Do not place anything, such as a cushion, on the front passenger's seat.

Doing so will disperse the passenger's weight, which may prevents the sensor from detecting the passenger's weight properly. As a result, the active head restraint may not activate in the event of an accident.

Active head restraint precautions (if equipped)

- Do not put head restraint covers.
- For removal, installation, modification, disassembly or disposal of the active head restraints, contact your Lexus dealer.


Inappropriate handling of the active head restraints may prevent them from operating properly during an accident.

Steering wheel

Adjustment procedure

Operating the switch moves the steering wheel in the following directions:

- (1) Up
- 2 Down
- (3) Toward the driver
- (4) Away from the driver



■ The steering wheel can be adjusted when

The engine switch is in ACCESSORY or IGNITION ON mode*.

- *: If the driver's seat belt is fastened, the steering wheel can be adjusted regardless of engine switch mode.
- Tautomatic adjustment of the steering position علفن شبانه روزى

A desired steering position can be entered to memory and recalled automatically by the driving position memory system. $(\rightarrow P. 218)$

■ Power easy access system 13003

The steering wheel and driver's seat move in accordance with engine switch mode and the driver's seat belt condition. $(\rightarrow P. 201)$



Do not adjust the steering wheel while driving.

Doing so may cause the driver to mishandle the vehicle and cause an accident, resulting in death or serious injury.


Inside rear view mirror

The rear view mirror's position can be adjusted to enable sufficient confirmation of the rear view.

Adjusting the height of rear view mirror

The height of the rear view mirror can be adjusted to suit your driving posture.

Adjust the height of the rear view mirror by moving it up and down.



تلفن شبانه روزی: ۱۵۸۰۲۹۸۸ - ۲۱

Anti-glare function

Responding to the level of brightness of the headlights of vehicles behind, the reflected light is automatically reduced.

Type A:

Type B:


Changing automatic anti-glare function mode


Changing automatic anti-glare function mode

ON/OFF

1 ON

2 OFF





When the automatic anti-glare function is in ON mode, the indicator illuminates.


The function will set to ON mode each time the engine switch is turned to IGNI-TION ON mode.

Pressing the button turns the function to OFF mode. (The indicator also turns off.)

■ To prevent sensor error

To ensure that the sensors operate properly, do not touch or cover them.

▶ Type A



▶ Type B



A CAUTION

Do not adjust the position of the mirror while driving.

Doing so may lead to mishandling of the vehicle and cause an accident, resulting in death or serious injury.

تلفن شبانه روزی: ۱۳۵۰ ۲۹۸۸ - ۲۲


Outside rear view mirrors

Adjustment procedure

- 1 Select the mirror to be adjusted.
 - 1 Left
 - 2 Neutral position
 - 3 Right




- **2** To adjust the mirror, press the switch.
 - (1) Up
 - 2 Right
 - (3) Down
 - (4) Left



Folding and extending the mirrors

- Using the switch
 - 1 Folds the mirrors
 - 2 Extends the mirrors



■ Setting automatic mode

Automatic mode allows the folding of extending of the mirrors to be linked to locking/unlocking of the doors.

To set to automatic mode, put the switch in the neutral position.

The indicator will come on.



Indicator

FarmaSOS.com

Linked mirror function when reversing

When the mirror select switch is in the "L" or "R" position, the outside rear view mirrors will automatically angle downwards when the vehicle is reversing in order to give a better view of the ground.

To disable this function, move the mirror select switch to the neutral position (between "L" and "R").

■ Adjusting the mirror angle when the vehicle is reversing

With the shift lever in R, adjust the mirror angle at a desired position.

The adjusted angle will be memorized and the mirror will automatically tilt to the memorized angle whenever the shift lever is shifted to R from next time

The memorized downward tilt position of the mirror is linked to the normal position (angle adjusted with the shift lever in other than R). Therefore, if the normal position is changed after adjustment, the tilt position will also change. When the normal position is changed, readjust the angle in reversing.

■ Mirror angle can be adjusted when ~

The engine switch is in ACCESSORY or IGNITION ON mode.

■ When the mirrors are fogged up

The outside rear view mirrors can be cleared using the mirror defoggers. Turn on the rear window defogger to turn on the outside rear view mirror defoggers. $(\rightarrow P.445)$

■ Automatic adjustment of the mirror angle

A desired mirror face angle can be entered to memory and recalled automatically by the driving position memory. (\rightarrow P. 218)

■ Auto anti-glare function

When the anti-glare inside rear view mirror is set to automatic mode, the outside rear view mirrors will activate in conjunction with the anti-glare inside rear view mirror to reduce reflected light. $(\rightarrow P.230)$

■ Using automatic mode in cold weather

When automatic mode is used in cold weather, the door mirror could freeze up and automatic stowing and return may not be possible. In this event, remove any ice and snow from the door mirror, then either operate the mirror using manual mode or move the mirror by hand.

■ Important points while driving

Observe the following precautions while driving.

Failure to do so may result in loss of control of the vehicle and cause an accident, resulting in death or serious injury.

- Do not adjust the mirrors while driving.
- Do not drive with the mirrors folded.
- Both the driver and passenger side mirrors must be extended and properly adjusted before driving.

■ When a mirror is moving

To avoid personal injury and mirror malfunction, be careful not to get your hand caught by the moving mirror.

■ When the mirror defoggers are operating

Do not touch the rear view mirror surfaces, as they can become very hot and burn you.




Power windows

Opening and closing procedures

The power windows can be opened and closed using the switches.

Operating the switch moves the windows as follows:

- (1) Closing
- 2 One-touch closing*
- 3 Opening
- 4 One-touch opening*
 - *: To stop the window partway, operate the switch in the opposite direction.



Window lock switch

Press the switch down to lock the passenger window switches.

Use this switch to prevent children from accidentally opening or closing a passenger window.



- The power windows can be operated when
 - The engine switch is in IGNITION ON mode.
- Operating the power windows after turning the engine off

The power windows can be operated for approximately 45 seconds even after the engine switch is turned to ACCESSORY mode or turned off. They cannot, however, be operated once either front door is opened.

■ Jam protection function

If an object becomes jammed between the window and the window frame while the window is closing, window movement is stopped and the window is opened slightly.

■ Catch protection function

If an object becomes caught between the door and window while the window is opening, window movement is stopped.

■ When the window cannot be opened or closed

When the jam protection function or catch protection function operates unusually and the door window cannot be opened or closed, perform the following operations with the power window switch of that door.

- Stop the vehicle. With the engine switch in IGNITION ON mode, within 4 seconds of the jam protection function or catch protection function activating, continuously operate the power window switch in the one-touch closing direction or one-touch opening direction so that the door window can be opened and closed.
- If the door window cannot be opened and closed even when performing the above operations, perform the following procedure for function initialization.
 - Turn the engine switch to IGNITION ON mode.
 - 2 Pull and hold the power window switch in the one-touch closing direction and completely close the door window.
- 3 Release the power window switch for a moment, resume pulling the switch in the one-touch closing direction, and hold it there for approximately 6 seconds or more.
- Press and hold the power window switch in the one-touch opening direction. After the door window is completely opened, continue holding the switch for an additional 1 second or more.
- Selease the power window switch for a moment, resume pressing the switch in the one-touch opening direction, and hold it there for approximately 4 seconds or more.
- 6 Pull and hold the power window switch in the one-touch closing direction again. After the door window is completely closed, continue holding the switch for a further 1 second or more.

If you release the switch while the window is moving, start again from the beginning. If the window reverses and cannot be fully closed or opened, have the vehicle inspected by your Lexus dealer.

■ Door lock linked window operation

- The power windows can be closed using the entry function. $(\rightarrow P.155)$
- The power windows can be opened and closed using the mechanical key. $(\rightarrow P. 631)$

■ Customization

Settings (e.g. linked door lock operation) can be changed. (Customizable features →P. 667)

▲ CAUTION

Observe the following precautions.

Failure to do so may result in death or serious injury.

■ Closing the windows

- The driver is responsible for all the power window operations, including the operation for the passengers. In order to prevent accidental operation, especially by a child, do not let a child operate the power windows. It is possible for children and other passengers to have body parts caught in the power window. Also, when riding with a child, it is recommended to use the window lock switch. (→P. 236)
- Check to make sure that all passengers do not have any part of their body in a position where it could be caught when a window is being operated.
- When using the smart entry & start system, wireless remote control or mechanical key and operating the power windows, operate the power window after checking to make sure that there is no possibility of any passenger having any of their body parts caught in the window. Also do not let a child operate window by the smart entry & start system, wireless remote control or mechanical key. It is possible for children and other passengers to get caught in the power window.
- When exiting the vehicle, turn the engine switch off, carry the key and exit the vehicle along with the child. There may be accidental operation, due to mischief, etc., that may possibly lead to an accident.

■ Jam protection function

- Never use any part of your body to intentionally activate the jam protection function.
- The jam protection function may not work if something gets jammed just before the window is fully closed. Be careful not to get any part of your body jammed in the window.

■ Catch protection function

- Never use any part of your body or clothing to intentionally activate the catch protection function.
- The catch protection function may not work if something gets caught just before the window is fully opened. Be careful not to get any part of your body or closing caught in the window.

امداد حودرو فارما

تلفن شبانه روزی: ۱۳۵۰ ۱۳۹۸ - ۲۱ م

Moon roof*

Use the overhead switches to open and close the moon roof and tilt it up and down.


Opening and closing

1 Opens the moon roof*

The moon roof stops slightly before the fully open position to reduce wind noise.


Press the switch again to fully open the moon roof.

- (2) Closes the moon roof*
 - *: Lightly press either way of the moon roof switch to stop the moon roof partway.



Tilting up and down

- 1 Tilts the moon roof up*
- 2) Tilts the moon roof down*
 - *: Lightly press either way of the moon roof switch to stop the moon roof partway.



■ The moon roof can be operated when

The engine switch is in IGNITION ON mode.

Operating the moon roof after turning the engine off

The moon roof can be operated for approximately 45 seconds after the engine switch is turned to ACCESSORY mode or turned off. It cannot, however, be operated once either front door is opened.

■ Jam protection function

If an object is detected between the moon roof and the frame while the moon roof is closing or tilting down, travel is stopped and the moon roof opens slightly.

■ Sunshade

The sunshade can be opened and closed manually. However, the sunshade will open automatically when the moon roof is opened.

■ Door lock linked moon roof operation

- The moon roof can be closed using the entry function. $(\rightarrow P. 155)$
- The moon roof can be opened and closed using the mechanical key. $(\rightarrow P. 631)$

تلفن شبانه روزي: ۱۹۸۸۸۶۲۰۸۵ تلفن شبانه روزي: ۱۹۸۸۸۶۲۰۸۵

■ When the moon roof does not close normally

Perform the following procedure:

- If the moon roof closes but then re-opens slightly
- 1 Stop the vehicle.
- 2 Press and hold the "CLOSE" switch.*1
 The moon roof will close, reopen and pause for approximately 10 seconds.*2
 Then it will close again, tilt up and pause for approximately 1 second. Finally, it will tilt down, open and close.
- 3 Check to make sure that the moon roof is completely closed and then release the switch.
- If the moon roof tilts down but then tilts back up
- 1 Stop the vehicle.
- 2 Press and hold the "UP" switch*1 until the moon roof moves into the tilt up position and stops.
- Release the "UP" switch once and then press and hold the "UP" switch again. *1

 The moon roof will pause for approximately 10 seconds in the tilt up position. *2

 Then it will adjust slightly and pause for approximately 1 second. Finally, it will tilt down, open and close.
- 4 Check to make sure that the moon roof is completely closed and then release the switch.
- *1: If the switch is released at the incorrect time, the procedure will have to be performed again from the beginning.
- *2: If the switch is released after the above mentioned 10 second pause, automatic operation will be disabled. In that case, press and hold the "CLOSE" or "UP" switch, and the moon roof will tilt up and pause for approximately 1 second. Then it will tilt down, open and close. Check to make sure that the moon roof is completely closed and then release the switch.

If the moon roof does not fully close even after performing the above procedure correctly, have the vehicle inspected by your Lexus dealer.

■ Moon roof open warning buzzer

The buzzer sounds and a message is shown on the multi-information display in the instrument cluster when the engine switch is turned off and the driver's door is opened with the moon roof open.

■ Customization

Settings (e.g. linked door lock operation) can be changed. (Customizable features →P. 667)

A CAUTION

Observe the following precautions.

Failure to do so may cause death or serious injury.

Opening the moon roof

- Do not allow any passengers to put their hands or heads outside the vehicle while it is moving.
- Do not sit on top of the moon roof.

■ Closing the moon roof

- The driver is responsible for moon roof opening and closing operations. In order to prevent accidental operation, especially by a child, do not let a child operate the moon roof. It is possible for children and other passengers to have body parts caught in the moon roof.
- Check to make sure that all passengers do not have any part of their body in a position where it could be caught when the moon roof is being operated.
- When using the smart entry & start system, wireless remote control or mechanical key and operating the moon roof, operate the moon roof after checking to make sure that there is no possibility of any passenger having any of their body parts caught in the moon roof. Also, do not let a child operate moon roof by the smart entry & start system, wireless remote control or mechanical key. It is possible for children and other passengers to get caught in the moon roof.
- When exiting the vehicle, turn the engine switch off, carry the key and exit the vehicle along with the child. There may be accidental operation, due to mischief, etc., that may possibly lead to an accident.

■ Jam protection function

- Never use any part of your body to intentionally activate the jam protection function.
- The jam protection function may not work if something gets caught just before the moon roof fully closes.



Driving

4-1.	Before driving	4-5.	Using the driving support	
	Driving the vehicle246		systems	
	Cargo and luggage257		Cruise control3	09
	Trailer towing258		Dynamic radar	040
	Driving procedures		cruise control	313
	Engine (ignition) switch259		Dynamic radar cruise control with	
	Automatic transmission		full-speed range3	328
	(vehicles without paddle shift switches)264	•	LKA	
			(Lane-Keeping Assist)3	344
	Automatic transmission		Driving mode select	
	(vehicles with paddle shift switches)269	78 79 32 • A\D :	switch3	354
	Turn signal lever278		Electronically modulated	
	Parking brake279		air suspension3	58
			Driving assist systems3	60
	Brake Hold282		PCS (Pre-Crash	
	Horn284		Safety system)3	68
4-3.	Operating the lights and		BSM	
	wipers Headlight switch285	4-6.	(Blind Spot Monitor)3	381
			• The Blind Spot Monitor	
	AHS (Adaptive High-beam		function3	
	System)291		• The RCTA function3	90
	Fog light switch298		Lexus night view3	393
	Windshield wipers and		Driving tips	
	washer		Winter driving tips3	399
	Headlight cleaner switch 304		Eco-friendly driving tips4	-03
4-4.	Refueling			
	Opening the fuel tank cap 305			

Driving the vehicle

The following procedures should be observed to ensure safe driving:

Starting the engine

 \rightarrow P. 259

Driving

- With the brake pedal depressed, shift the shift lever to D. $(\rightarrow P. 264, 269)$
- If the parking brake is in manual mode, release the parking brake. $(\rightarrow P. 279)$
- **3** Gradually release the brake pedal and gently depress the accelerator pedal to accelerate the vehicle.

Stopping

- 1 With the shift lever in D, depress the brake pedal.
- If necessary, set the parking brake.

 If the vehicle is to be stopped for an extended period of time, shift the shift lever to P or N. (→P. 264, 269)

Parking the vehicle

- 1 With the shift lever in D, depress the brake pedal.
- Set parking brake (\rightarrow P. 279), and shift the shift lever to P (\rightarrow P. 264, 269).
- **3** Press the engine switch to stop the engine.
- 4 Lock the door, making sure that you have the electronic key on your person.

If parking on a hill, block the wheels as needed.

Starting off on a steep uphill

- 1 Make sure that the parking brake is set and shift the shift lever to D.
- **2** Gently depress the accelerator pedal.
- **3** Release the parking brake.

■ When starting off on a uphill

Hill-start assist control will operate. $(\rightarrow P. 360)$

■ Driving in the rain

- Drive carefully when it is raining, because visibility will be reduced, the windows may become fogged-up, and the road will be slippery.
- Drive carefully when it starts to rain, because the road surface will be especially slippery.
- Refrain from high speeds when driving on an expressway in the rain, because there
 may be a layer of water between the tires and the road surface, preventing the
 steering and brakes from operating properly.

■ Engine speed while driving

In the following conditions, the engine speed may become high while driving. This is due to automatic up-shifting control or down-shifting implementation to meet driving conditions. It does not indicate sudden acceleration.

- The vehicle is judged to be driving uphill or downhill
- When the accelerator pedal is released
- When the brake pedal is depressed while sport mode is selected

■ Breaking in your new Lexus

To extend the life of the vehicle, observing the following precautions is recommended:

- For the first 300 km (186 miles): Avoid sudden stops.
- For the first 1000 km (621 miles):
 - Do not drive at extremely high speeds.
 - Avoid sudden acceleration.
 - Do not drive continuously in low gears.
 - Do not drive at a constant speed for extended periods.

■ Drum-in-disc type parking brake system

Your vehicle has a drum-in-disc type parking brake system. This type of brake system needs bedding-down of the brake shoes periodically or whenever the parking brake shoes and/or drum are replaced. Have your Lexus dealer perform the bedding down operation.

Operating your vehicle in a foreign country

Comply with the relevant vehicle registration laws and confirm the availability of the correct fuel. $(\rightarrow P. 652)$

■ Regarding engine speed when idling (1UR-FSE engine)

When idling with the shift lever in P or N for an extensive period of time, the engine speed may rise to approximately 1000 rpm (r/min). This is not a malfunction. After a set period of time, the engine will return to its previous engine speed.

Observe the following precautions.

Failure to do so may result in death or serious injury.

■ When starting the vehicle

Always keep your foot on the brake pedal while stopped with the engine running. This prevents the vehicle from creeping.

■ When driving the vehicle

- Do not drive if you are unfamiliar with the location of the brake and accelerator pedals to avoid depressing the wrong pedal.
 - Accidentally depressing the accelerator pedal instead of the brake pedal will result in sudden acceleration that may lead to an accident.
 - When backing up, you may twist your body around, leading to a difficulty in operating the pedals. Make sure to operate the pedals properly.
 - Make sure to keep a correct driving posture even when moving the vehicle only slightly. This allows you to depress the brake and accelerator pedals properly.
 - Depress the brake pedal using your right foot. Depressing the brake pedal using your left foot may delay response in an emergency, resulting in an accident.
- Do not drive the vehicle over or stop the vehicle near flammable materials.
 The exhaust system and exhaust gases can be extremely hot. These hot parts may cause a fire if there is any flammable material nearby.

Observe the following precautions.

Failure to do so may result in death or serious injury.

■ When driving the vehicle

- During normal driving, do not turn off the engine. Turning the engine off while driving will not cause loss of steering or braking control, however, power assist to the steering will be lost. This will make it more difficult to steer smoothly, so you should pull over and stop the vehicle as soon as it is safe to do so.
 - In the event of an emergency, such as if it becomes impossible to stop the vehicle in the normal way: \rightarrow P. 595
- Use engine braking (downshift) to maintain a safe speed when driving down a steep hill.
 - Using the brakes continuously may cause the brakes to overheat and lose effectiveness. $(\rightarrow P. 264, 269)$
- Do not adjust the positions of the steering wheel, the seat, or the inside or outside rear view mirrors while driving.
 Doing so may result in a loss of vehicle control.
- Always check that all passengers' arms, heads or other parts of their body are not outside the vehicle.

تلفن شیانه روزی: ۵۸ • ۲۹۸۸۸–۲۱ •

Observe the following precautions.

Failure to do so may result in death or serious injury.

■ When driving on slippery road surfaces

- Sudden braking, acceleration and steering may cause tire slippage and reduce your ability to control the vehicle.
- Sudden acceleration, engine braking due to shifting, or changes in engine speed could cause the vehicle to skid.
- After driving through a puddle, lightly depress the brake pedal to make sure that
 the brakes are functioning properly. Wet brake pads may prevent the brakes from
 functioning properly. If the brakes on only one side are wet and not functioning
 properly, steering control may be affected.

■ When shifting the shift lever

- Do not let the vehicle roll backward while the shift lever is in a driving position, or roll forward while the shift lever is in R.
 Doing so may cause the engine to stall or lead to poor brake and steering performance, resulting in an accident or damage to the vehicle.
- Do not shift the shift lever to P while the vehicle is moving.
 Doing so can damage the transmission and may result in a loss of vehicle control.
- Do not shift the shift lever to R while the vehicle is moving forward.
 Doing so can damage the transmission and may result in a loss of vehicle control.
- Do not shift the shift lever to a driving position while the vehicle is moving backward.
 - Doing so can damage the transmission and may result in a loss of vehicle control.
- Do not shift the shift lever to N while the vehicle is moving. Doing so will disengage the engine from the transmission. Engine braking is not available when N is selected.
- Be careful not to shift the shift lever with the accelerator pedal depressed. Shifting the shift lever to a gear other than P or N may lead to unexpected rapid acceleration of the vehicle that may cause an accident and result in death or serious injury.

Observe the following precautions.

Failure to do so may result in death or serious injury.

■ If a brake pad wear warning message is displayed

Have your Lexus dealer check and replace the brake pads as soon as possible. The rotor damage can result if the pads are not replaced when needed.

Moderate levels of the brake pad and disc wear allow enhanced braking power. As a result, the discs may wear more quickly than conventional brake discs. Therefore, when replacing the brake pads, Lexus recommends that you also have the thickness of the discs measured.

It is dangerous to drive the vehicle when the wear limits of the brake pads and/or those of the brake discs are exceeded.

■ When the vehicle is stopped

- Do not race the engine.
 If the vehicle is in any gear other than P or N, the vehicle may accelerate suddenly and unexpectedly, causing an accident.
- In order to prevent accidents due to the vehicle rolling away, always keep depressing the brake pedal while the engine is running, and apply the parking brake as necessary.
- If the vehicle is stopped on an incline, in order to prevent accidents caused by the vehicle rolling forward or backward, always depress the brake pedal and securely apply the parking brake as needed.
- Avoid revving or racing the engine.
 Running the engine at high speed while the vehicle is stopped may cause the exhaust system to overheat, which could result in a fire if combustible material is nearby.

A CAUTION

Observe the following precautions.

Failure to do so may result in death or serious injury.

■ When the vehicle is parked

• Do not leave glasses, cigarette lighters, spray cans, or soft drink cans in the vehicle when it is in the sun.

Doing so may result in the following:

- Gas may leak from a cigarette lighter or spray can, and may lead to a fire.
- The temperature inside the vehicle may cause the plastic lenses and plastic material of glasses to deform or crack.
- Soft drink cans may fracture, causing the contents to spray over the interior of the vehicle, and may also cause a short circuit in the vehicle's electrical components.
- Do not leave cigarette lighters in the vehicle. If a cigarette lighter is in a place such
 as the glove box or on the floor, it may be lit accidentally when luggage is loaded
 or the seat is adjusted, causing a fire.
- Do not attach adhesive discs to the windshield or windows. Do not place containers such as air fresheners on the instrument panel or dashboard. Adhesive discs or containers may act as lenses, causing a fire in the vehicle.
- Do not leave a door or window open if the curved glass is coated with a metallized film such as a silver-colored one. Reflected sunlight may cause the glass to act as a lens, causing a fire.
- Always apply the parking brake, shift the shift lever to P, stop the engine and lock the vehicle.
 - Do not leave the vehicle unattended while the engine is running.

 If the vehicle is parked with the shift lever in P but the parking brake is not set, the vehicle may start to move, possibly leading to an accident.
- Do not touch the exhaust pipes while the engine is running or immediately after turning the engine off.

Doing so may cause burns.

A CAUTION

Observe the following precautions.

Failure to do so may result in death or serious injury.

■ When taking a nap in the vehicle

Always turn the engine off. Otherwise, if you accidentally move the shift lever or depress the accelerator pedal, this could cause an accident or fire due to engine overheating. Additionally, if the vehicle is parked in a poorly ventilated area, exhaust gases may collect and enter the vehicle, leading to death or a serious health hazard.

■ When braking

- When the brakes are wet, drive more cautiously.
 Braking distance increases when the brakes are wet, and this may cause one side of the vehicle to brake differently than the other side. Also, the parking brake may not securely hold the vehicle.
- If the electronically controlled brake system does not operate, do not follow other vehicles closely and avoid hills or sharp turns that require braking.
 In this case, braking is still possible, but the brake pedal should be depressed more firmly than usual. Also, the braking distance will increase. Have your brakes fixed immediately.
- The brake system consists of 2 or more individual hydraulic systems; if one of the systems fails, the other(s) will still operate. In this case, the brake pedal should be depressed more firmly than usual and the braking distance will increase. Have your brakes fixed immediately.

■ If the vehicle becomes stuck (AWD models)

Do not spin the wheels excessively when any of the tires is up in the air, or the vehicle is stuck in sand, mud, etc. This may damage the driveline components or propel the vehicle forward or backward, causing an accident.

♠ NOTICE

■ When driving the vehicle

- Do not depress the accelerator and brake pedals at the same time during driving, as this may restrain the engine output.
- Do not use the accelerator pedal or depress the accelerator and brake pedals at the same time to hold the vehicle on a hill.

■ When parking the vehicle

Always set the parking brake, and shift the shift lever to P. Failure to do so may cause the vehicle to move or the vehicle may accelerate suddenly if the accelerator pedal is accidentally depressed.

Avoiding damage to vehicle parts

- Do not turn the steering wheel fully in either direction and hold it there for an extended period of time.
 Doing so may damage the power steering motor.
- When driving over bumps in the road, drive as slowly as possible to avoid damaging the wheels, underside of the vehicle, etc.

If you get a flat tire while driving

A flat or damaged tire may cause the following situations. Hold the steering wheel firmly and gradually depress the brake pedal to slow down the vehicle.

- It may be difficult to control your vehicle.
- The vehicle will make abnormal sounds or vibrations.
- The vehicle will lean abnormally. Information on what to do in case of a flat tire $(\rightarrow P. 618)$

♠ NOTICE

■ When encountering flooded roads

Do not drive on a road that has flooded after heavy rain etc. Doing so may cause the following serious damage to the vehicle:

- Engine stalling
- Short in electrical components
- Engine damage caused by water immersion

In the event that you drive on a flooded road and the vehicle is flooded, be sure to have your Lexus dealer check the following:

- Brake function
- Changes in quantity and quality of oil and fluid used for the engine, transmission, transfer (AWD models), differential, etc.
- Lubricant condition for the propeller shaft, bearings and suspension joints (where possible), and the function of all joints, bearings, etc.

تلفن شبانه روزی: ۱۹۸۸/۶۲۰۸۵ تلفن شبانه روزی:

Cargo and luggage

Take notice of the following information about storage precautions. cargo capacity and load:



■ Things that must not be carried in the trunk

The following things may cause a fire if loaded in the trunk:

- Receptacles containing gasoline
- Aerosol cans
- ■Storage precautions

Observe the following precautions.

Failure to do so may prevent the pedals from being depressed properly, may block the driver's vision, or may result in items hitting the driver or passengers, possibly causing an accident.

- Stow cargo and luggage in the trunk whenever possible.
- Do not place cargo or luggage in or on the following locations.
 - At the feet of the driver ١٩٤٥ : درني: At the feet of the driver
 - On the front passenger or rear seats (when stacking items)
 - On the package tray
 - On the instrument panel
 - On the dashboard Masos.com
 - In front of the Remote Touch screen
- Secure all items in the occupant compartment.
- Load and distribution
 - Do not overload your vehicle.
 - Do not apply loads unevenly. Improper loading may cause deterioration of steering or braking control which may cause death or serious injury.

Trailer towing

Lexus does not recommend towing a trailer with your vehicle. Lexus also does not recommend the installation of a tow hitch or the use of a tow hitch carrier for a wheelchair, scooter, bicycle, etc. Your Lexus is not designed for trailer towing or for the use of tow hitch mounted carriers.

Towing capacity: 0 kg (0 lb.)



تلفن شبانه روزی: ۱۵۸۰۲۹۸۸ - ۲۱

Engine (ignition) switch

Performing the following operations when carrying the electronic key on your person starts the engine or changes engine switch modes.

Starting the engine

- 1 Turn the engine switch to IGNITION ON mode (\rightarrow P. 260) and check that the parking brake is set.
- 2 Check that the shift lever is set in P.
- **3** Firmly depress the brake pedal.

The engine switch indicator will turn green. If the indicator does not turn green, the engine cannot be started.

Press the engine switch shortly and firmly.

When operating the engine switch, one short, firm press is enough. It is not necessary to press and hold the switch.

The engine will crank until it starts or for up to 30 seconds, whichever is less.

Continue depressing the brake pedal until the engine is completely started.

The engine can be started from any engine switch mode.



Stopping the engine

- 1 Stop the vehicle.
- **2** Set the parking brake $(\rightarrow P. 279)$, and shift the shift lever to P.
- **3** Press the engine switch.
- Release the brake pedal and check that the indicator on the engine switch is off.

Changing engine switch modes

Modes can be changed by pressing the engine switch with brake pedal released. (The mode changes each time the switch is pressed.)

(1) Off*

The emergency flashers can be used.

2 ACCESSORY mode

Some electrical components such as the audio system can be used.


The engine switch indicator turns amber.

(3) IGNITION ON mode

All electrical components can be used.

The engine switch indicator turns amber.

*: If the shift lever is in a position other than P when turning off the engine, the engine switch will be turned to ACCESSORY mode, not to off.



■ Auto power off function

If the vehicle is left in ACCESSORY mode for more than 20 minutes with the shift lever in P, the engine switch will automatically turn off.

■ Electronic key battery depletion

 \rightarrow P. 166

■ Conditions affecting operation

 \rightarrow P. 163

■ Notes for the entry function

 \rightarrow P.164

■ If the engine does not start

The engine immobilizer system may not have been deactivated. $(\rightarrow P. 104)$ Contact your Lexus dealer.

■Steering lock

After turning the engine switch off and opening and closing the doors, the steering wheel will be locked due to the steering lock function. Operating the engine switch again automatically cancels the steering lock.

■ When the steering lock cannot be released

The green indicator light on the engine switch will flash and a message will be shown on the multi-information display. Press the engine switch again while turning the steering wheel left and right.



■ Steering lock motor overheating prevention

To prevent the steering lock motor from overheating, the motor may be suspended if the engine is turned on and off repeatedly in a short period of time. In this case, refrain from operating the engine. After about 10 seconds, the steering lock motor will resume functioning.

■ When the engine switch indicator flashes in amber

The system may be malfunctioning. Have the vehicle inspected by your Lexus dealer immediately.

■ If the electronic key battery is depleted

- \rightarrow P. 575
- If the smart entry & start system has been deactivated in a customized setting
 - \rightarrow P. 631



A CAUTION

■ When starting the engine

Always start the engine while sitting in the driver's seat. Do not depress the accelerator pedal while starting the engine under any circumstances. Doing so may cause an accident resulting in death or serious injury.

■ Caution while driving

If engine failure occurs while the vehicle is moving, do not lock or open the doors until the vehicle reaches a safe and complete stop. Activation of the steering lock in this circumstance may lead to an accident, resulting in death or serious injury.

Stopping the engine in an emergency

If you want to stop the engine in an emergency while driving the vehicle, press and hold the engine switch for more than 2 seconds, or press it briefly 3 times or more in succession. $(\rightarrow P.595)$

However, do not touch the engine switch while driving except in an emergency. Turning the engine off while driving will not cause loss of steering or braking control, however, power assist to the steering will be lost. This will make it more difficult to steer smoothly, so you should pull over and stop the vehicle as soon as it is safe to do so.

↑ NOTICE

■To prevent battery discharge

Do not leave the engine switch in ACCESSORY or IGNITION ON mode for long periods of time without the engine running.

- When starting the engine
 - Do not race a cold engine.
 - If the engine becomes difficult to start or stalls frequently, have your vehicle checked by your Lexus dealer immediately.
- Symptoms indicating a malfunction with the engine switch


If the engine switch seems to be operating somewhat differently than usual, such as the switch sticking slightly, there may be a malfunction. Contact your Lexus dealer immediately.



تلفن شبانه روزی: ۱۵۸۰۲۹۸۸ - ۲۱

Automatic transmission (vehicles without paddle shift switches)

Shifting the shift lever



While the engine switch is in IGNITION ON mode, move the shift lever with the brake pedal depressed.

When shifting the shift lever between P and D, make sure that the vehicle is completely stopped.

Shift position purpose maSOS.com

Shift position	Purpose and condition
Р	Parking the vehicle/starting the engine
R	Reversing
N	Condition in which the power is not transmitted
D	Normal driving*
S	S mode driving (→P. 265)

^{*:} To improve fuel efficiency and reduce noises, set the shift lever in D for normal driving.

Selecting shift ranges in S mode

To enter S mode, shift the shift lever to the S position.

When in S mode, changing the shift range allows restriction of the highest gear, preventing unnecessary upshifting and enabling the level of engine braking force to be selected.

- 1 Upshifting
- (2) Downshifting



The initial shift range in S mode is set automatically between 3 and 7 according to vehicle speed and driving conditions.

■ Shift ranges and their functions

Meter display	rmasOS Function
S2 - S8	A gear in the range between 1 and the selected gear is automatically chosen depending on vehicle speed and driving conditions
S1	Setting the gear at 1

A lower shift range will provide greater engine braking forces than a higher shift range.

Selecting the driving mode

■ Sport mode/Comfort mode/Eco drive mode

 \rightarrow P. 354

■ Snow mode

Snow mode can be selected to suit the conditions when driving on slippery road surfaces, such as on snow.

Press the switch.

The snow mode indicator light will come on.

Press the switch again to return to normal mode.



■S mode

- When the shift range is 6 or lower, holding the shift lever toward "+" sets the shift range to 8.
- When the shift lever is moved toward "-", the shift range is downshifted to a range that enables engine braking force that is suitable to driving conditions.
- To prevent the engine from over-revving, upshifting may automatically occur.

■ Downshifting restrictions warning buzzer (in the S mode)

To help ensure safety and driving performance, downshifting operation may sometimes be restricted. In some circumstances, downshifting may not be possible even when the shift lever is operated. (A buzzer will sound twice.)

■ When driving with cruise control, dynamic radar cruise control or dynamic radar cruise control with full speed range activated

Even when performing the following actions with the intent of enabling engine braking, engine braking will not activate because cruise control, dynamic radar cruise control or dynamic radar cruise control with full speed range will not be canceled.

- ullet While driving in S mode, downshifting to 7, 6, 5 or 4. (\rightarrow P. 309, 313, 328)
- ullet When switching the driving mode to sport mode while driving in D position. (\rightarrow P. 354)

■ Snow mode automatic deactivation

Snow mode is automatically deactivated if the engine switch is turned off after driving in snow mode.

■ Shift lock system

The shift lock system is a system to prevent accidental operation of the shift lever in starting.

The shift lever can be shifted from P only when the engine switch is in IGNITION ON mode and the brake pedal is being depressed.

■ If the shift lever cannot be shifted from P

First, check whether the brake pedal is being depressed.

If the shift lever cannot be shifted with your foot on the brake pedal, there may be a problem with the shift lock system. Have the vehicle inspected by your Lexus dealer immediately.

The following steps may be used as an emergency measure to ensure that the shift lever can be shifted.


Releasing the shift lock:

1 Turn the engine switch to IGNITION ON mode (\rightarrow P. 260) and check that the parking brake is set.


تلفن شيانه روزي: ٨٨٠ ٢

- **2** Turn the engine switch off.
- 3 Depress the brake pedal.
- ▶ Left-hand drive vehicles
- Pry the cover up with a flathead screw-driver or equivalent tool.

To prevent damage to the cover, cover the tip of the screwdriver with a rag.








- ► Right-hand drive vehicles
- Pry the cover up with a flathead screwdriver or equivalent tool.

To prevent damage to the cover, cover the tip of the screwdriver with a rag.

5 Press the shift lock override button. The shift lever can be shifted while the button is pressed.





■ AI-SHIFT

The AI-SHIFT automatically selects the suitable gear according to driver performance and driving conditions.

The AI-SHIFT automatically operates when the shift lever is in the D and S position.

A CAUTION

■ When driving on slippery road surfaces

Be careful of downshifting and sudden acceleration, as this could result in the vehicle skidding to the side or spinning.


■ To prevent an accident when releasing the shift lock

Before pressing the shift lock override button, make sure to set the parking brake and depress the brake pedal.

If the accelerator pedal is accidentally depressed instead of the brake pedal when the shift lock override button is pressed and the shift lever is shifted out of P, the vehicle may suddenly start, possibly leading to an accident resulting in death or serious injury.

Automatic transmission (vehicles with paddle shift switches)

Shifting the shift lever



While the engine switch is in IGNITION ON mode, move the shift lever with the brake pedal depressed.

When shifting the shift lever between P and \overline{D} , make sure that the vehicle is completely stopped.

Shift position purpose

Shift position	Meter display	Purpose and condition
Р	P	Parking the vehicle/starting the engine
R	R	Reversing
N	N	Condition in which the power is not transmitted
D	D	Normal driving*1
	(paddle shift switches activated)	Shift range selection (→P. 271)
М	M 4	M mode driving *2 (→P. 272)

^{*1:} To improve fuel efficiency and reduce noises, set the shift lever in D for normal

*2: Any gear can be fixed when driving in M mode.

Farmas OS. com

Selecting shift ranges in the D position

To drive using temporary shift range selection, operate the "-" or "+"paddle shift switch while the shift lever is in the D position.

Changing the shift range allows restriction of the highest gear, preventing unnecessary upshifting and enabling the level of engine braking force to be selected.


When the "-" paddle shift switch is operated, the shift range is downshifted to a range that enables engine braking force that is suitable to driving conditions.

1 Upshifting

(2) Downshifting

The selected shift range, from D1 to D8, will be displayed in the meter.

To return to normal D position driving, the "+" paddle shift switch must be held down for a period of time.



■ Shift ranges and their functions

Meter display	Function
D2-D8 Fa	A gear in the range between 1 and the selected gear is automatically chosen depending on vehicle speed and driving conditions
D1	Setting the gear at 1

A lower shift range will provide greater engine braking forces than a higher shift range.

Selecting gears in the M position


To enter M mode, shift the shift lever to the M position.

Gears can be selected by operating the shift lever or paddle shift switches, allowing you to drive in the gear of your choosing.

- 1 Upshifting
- 2 Downshifting

The gear changes once every time the shift lever or paddle shift switch is operated.

The selected gear, from M1 to M8, will be fixed and displayed in the meter.




- When in the M position, the gear will not change unless the shift lever or paddle shift switches are operated. However, even when in the M position, the gears will be automatically changed in the following situation:
 - When vehicle speed drops (downshift only).
 - When the automatic transmission fluid or engine coolant temperature is low.
 - · When the automatic transmission fluid temperature is high.
 - When the needle of the tachometer is in the red zone (the range which exceeds the allowable revs of the engine).
- When in the vehicle speed is low, the gear will not upshift even if the shift lever or paddle shift switches are operated.

Gear Shift Indicator (if equipped)

The Gear Shift Indicator display is a guide to help the driver achieve improved fuel economy and reduced exhaust emissions within limits of engine performance.

- 1) When not in operation
- 2 Shift-up indicator



■ Gear Shift Indicator function

- This function automatically operates during M mode.
- By following the Shift-up indicator and shifting up accordingly, it is possible to achieve improved fuel economy and reduced exhaust emissions.
- The Gear Shift Indicator does not have a similar function for downshifting.
- Depending on the driving conditions, the Gear Shift Indicator may not display the Shift-up indicator while driving in M mode.

Selecting the driving mode

■ Sport mode/Comfort mode/Eco drive mode

 \rightarrow P. 354

■ Snow mode

Snow mode can be selected to suit the conditions when driving on slippery road surfaces, such as on snow.

Press the switch

The snow mode indicator light will come on.

Press the switch again to return to normal mode.



■ Automatic deactivation of shift range selection in the D position

Shift range selection in the D position will be deactivated in the following situations:

- When the vehicle comes to a stop
- If the accelerator pedal is depressed for more than a certain period of time
- When the shift lever is shifted to other than D

■ Downshifting restrictions warning buzzer

To help ensure safety and driving performance, downshifting operation may sometimes be restricted. In some circumstances, downshifting may not be possible even when the shift lever or paddle shift switch is operated. (A buzzer will sound twice.)

■ When driving with cruise control, dynamic radar cruise control or dynamic radar cruise control with full speed range activated

Even when performing the following actions with the intent of enabling engine braking, engine braking will not activate because cruise control, dynamic radar cruise control or dynamic radar cruise control with full speed range will not be canceled.

- While driving in the D position, downshifting to 7, 6, 5 or 4. $(\rightarrow P. 309, 313, 328)$
- When switching the driving mode to sport mode while driving in D position. $(\rightarrow P.354)$

■ Snow mode automatic deactivation

Snow mode is automatically deactivated if the engine switch is turned off after driving in snow mode.

■ Shift lock system

The shift lock system is a system to prevent accidental operation of the shift lever in starting.

The shift lever can be shifted from P only when the engine switch is in IGNITION ON mode and the brake pedal is being depressed.

■ If the shift lever cannot be shifted from P

First, check whether the brake pedal is being depressed.

If the shift lever cannot be shifted with your foot on the brake pedal, there may be a problem with the shift lock system. Have the vehicle inspected by your Lexus dealer immediately.

The following steps may be used as an emergency measure to ensure that the shift lever can be shifted.

Releasing the shift lock:

1 Turn the engine switch to IGNITION ON mode (\rightarrow P. 260) and check that the parking brake is set.

تلفن شيانه روزي: ٨٨٠ ٢

- **2** Turn the engine switch off.
- 3 Depress the brake pedal.
- ▶ Left-hand drive vehicles
- Pry the cover up with a flathead screw-driver or equivalent tool.

To prevent damage to the cover, cover the tip of the screwdriver with a rag.




5 Press the shift lock override button. The shift lever can be shifted while the button is pressed.



- ► Right-hand drive vehicles
- Pry the cover up with a flathead screw-driver or equivalent tool.

To prevent damage to the cover, cover the tip of the screwdriver with a rag.

5 Press the shift lock override button. The shift lever can be shifted while the button is pressed.





■ If the automatic transmission fluid temperature warning message is displayed

If the automatic transmission fluid temperature warning message is displayed while driving, make sure you return to normal D position driving and reduce speed by easing off the accelerator pedal. Stop the vehicle in a safe place, shift the shift lever to the P position and let the engine idle until the warning message goes out. When the warning message goes out, the vehicle can be driven again. If the warning message does not go out after waiting a while, have your vehicle inspected by your Lexus dealer.

■ AI-SHIFT

The AI-SHIFT automatically selects the suitable gear according to driver performance and driving conditions.

The AI-SHIFT automatically operates when the shift lever is in the D position. (Shifting the shift lever to the M position cancels the function.)

A CAUTION

■ When driving on slippery road surfaces

Be careful of downshifting and sudden acceleration, as this could result in the vehicle skidding to the side or spinning.

■ Gear Shift Indicator display (if equipped)

For safety, the driver should not look only at the display. Refer to the display when it is safe to do so while considering actual traffic and road conditions.

Failure to do so may lead to an accident.

■ To prevent an accident when releasing the shift lock

Before pressing the shift lock override button, make sure to set the parking brake and depress the brake pedal.


If the accelerator pedal is accidentally depressed instead of the brake pedal when the shift lock override button is pressed and the shift lever is shifted out of P, the vehicle may suddenly start, possibly leading to an accident resulting in death or serious injury.

تلفن شبانه روزى: ۱۵۸۰۲۹۸۸ - ۲۱

Turn signal lever

Operating instructions

- 1 Right turn
- 2 Lane change to the right (move the lever partway and release it)
 The right hand signals will flash 3 times.
- 3 Lane change to the left (move the lever partway and release it)
 The left hand signals will flash 3 times.
- (4) Left turn



■ Turn signals can be operated when

The engine switch is in IGNITION ON mode.

- If the indicator flashes faster than usual

 Check that a light bulb in the front or rear turn signal lights has not burned out.
- If the turn signals stop flashing before a lane change has been performed Operate the lever again.
- To discontinue flashing of the turn signals during a lane change Operate the lever in the opposite direction.
- Customization

The number of times the turn signals flash during a lane change can be changed. (Customizable features \rightarrow P. 667)

Parking brake

A selections can be made as desired from the following modes.

Manual mode


1 Sets the parking brake

The parking brake indicator light will come on. $(\rightarrow P. 281)$

Press and hold the parking brake switch if an emergency occurs and it is necessary to operate the parking brake while driving. The parking brake is applied only while the switch is being pressed.

(2) Releases the parking brake

Operate the parking brake switch while depressing the brake pedal. Make sure that the parking brake indicator light goes off.



Automatic mode

The parking brake is set or released automatically according to shift lever operation.

Turns automatic mode on/off

When automatic mode is turned on, the indicator on the switch comes on and it operates in the following manner:

- When the shift lever is moved into P, the parking brake will be set.
- When the shift lever is moved out of P, the parking brake will be released.

Operate the shift lever with the brake pedal depressed.



■ Parking the vehicle

→P. 246

■ Parking brake operation

- When the engine switch is not in IGNITION ON mode, the parking brake cannot be released using the parking brake switch.
- When the engine switch is not in IGNITION ON mode, automatic mode (automatic brake setting and releasing) is not available.
- If the parking brake is operated repeatedly over a short period of time, the system may restrict operation to prevent overheating. If this happens, refrain from operating the parking brake. Normal operation will return after about 1 minute.

■ Parking brake operation sound

When the parking brake operates, a motor sound (whirring sound) may be heard. This does not indicate a malfunction.

■ Parking brake indicator light

Depending on the engine switch mode, the parking brake indicator light will come on and stay on as described below:

IGNITION ON mode: Comes on until the parking brake is released. Not in IGNITION ON mode: Stays on for approximately 15 seconds.

• When the engine switch is turned off with the parking brake set, the parking brake indicator light will stay on for about 15 seconds. This does not indicate a malfunction.

■ Parking brake engaged warning buzzer

A buzzer will sound if the vehicle is driven at a speed of approximately 5 km/h (3 mph) or more with the parking brake engaged.

■ When there is a malfunction in the system

Warning lights and/or warning message will turn on or flash. (\rightarrow P. 607, 614) Depending on the condition, the parking brake indicator light may flash.

■ Usage in winter time

 \rightarrow P.399



■ When parking the vehicle

Before you leave the vehicle, set the parking brake, shift the shift lever to P and make sure that the vehicle does not move.

■ When the system malfunctions

Stop the vehicle in a safe place and check the warning messages.

■ When the parking brake cannot be released due to a malfunction

Use the parking brake release tool to manually release the parking brake. $(\rightarrow P. 629)$


Driving the vehicle with the parking brake set will lead to brake components overheating, which may affect braking performance and increase brake wear.

Brake Hold

The brake hold system keeps the brake applied when the shift lever is in D. N. or S (vehicles without paddle shift switches) or M (vehicles with paddle shift switches) with the system on and the brake pedal has been depressed to stop the vehicle. The system releases the brake when the accelerator pedal is depressed with the shift lever in D. S or M to allow smooth start off

Turns the brake hold system on

The brake hold standby indicator (green) comes on. While the system is holding the brake, the brake hold operated indicator (yellow) comes on.



تلفن شبانه روزی: 🗘 Brake hold system operating conditions

The brake hold system cannot be turned on in the following conditions:

- The trunk or hood is not closed.
- The driver's door is not closed.
- The driver is not wearing the seat belt.

If any of the conditions above are detected when the brake hold system is enabled, the system will turn off and the brake hold standby indicator light will go off. In addition, if any of the conditions are detected while the system is holding the brake, a warning buzzer will sound and a message will be shown on the multi-information display. The parking brake will then be set automatically.

■ Brake hold function

- If the brake pedal is left released for a period of about 3 minutes after the system has started holding the brake, the parking brake will be set automatically. In this case, a warning buzzer sounds and a message is shown on the multi-information display.
- To turn the system off while the system is holding the brake, firmly depress the brake pedal and press the switch again.
- The brake hold function may not hold the vehicle when the vehicle is on a steep. incline. In this situation, it may be necessary for the driver to apply the brakes. The multi-information display will inform the driver of this situation.
- When the parking brake is set automatically while the system is holding the brakes The parking brake will not be released automatically. Release the parking brake by operating the parking brake switch, making sure that the parking brake indicator light goes off. $(\rightarrow P. 279)$
- When there is a malfunction in the system Warning lights and/or warning messages will turn on or flash. $(\rightarrow P. 607, 614)$



■ When the vehicle is on a steep incline

When using the brake hold system on a steep incline exercise caution. The brake hold function may not hold the vehicle in such a situation.

■ When stopped on a slippery road

The system cannot stop the vehicle when the gripping ability of the tires has been exceeded. Do not use the system when stopped on a slippery road.



■ When parking the vehicle

The brake hold system is not designed for use when parking the vehicle for a long period of time. Turning the engine switch off while the system is holding the brake may release the brake, which would cause the vehicle to move. When operating the engine switch, depress the brake pedal, set the parking brake and shift the shift lever to P.

Horn

To sound the horn, press on or close to the mark.





تلفن شبانه روزی: ۱۳۵۰ ۱۳۹۸ - ۲۱ م

Headlight switch


The headlights can be operated manually or automatically.

Operating instructions

Turning the end of the lever turns on the lights as follows:

- ► Left-hand drive vehicles
- 1 o The daytime running lights turn on. $(\rightarrow P. 288)$
- 2) FDOS The front position, tail, license plate and instrument panel lights turn on.
- 3 The headlights and all lights listed above turn on.
- 4 AUTO The headlights, daytime running lights (→P. 288) and all the lights listed above turn on and off automatically.


(When the engine switch is in IGNITION ON mode.)



- ► Right-hand drive vehicles
- 1) OFF The daytime running lights turn on. $(\rightarrow P. 288)$
- The front position, tail, license plate and instrument panel lights turn on.
- ③ **■D** The headlights and all lights listed above turn on.
- (4) AUTO The headlights, daytime running lights (→P. 288) and all the lights listed above turn on and off automatically.

 (When the engine switch is

(When the engine switch is in IGNITION ON mode.)



تلفن شبانه روزی: ۱۵۸۰۲۹۸۸ - ۲۱


Turning on the high beam headlights

1) With the headlights on, push the lever away from you to turn on the high beams.

Pull the lever toward you to the center position to turn the high beams off.

2) Pull the lever toward you and release it to flash the high beams once.


You can flash the high beams with the headlights on or off.



Follow me home system (if equipped)

This system allows the headlights, tail, license plate and front position lights to be turned on for 30 seconds when the engine switch is off.

Pull the lever toward you and release it with the light switch in Auro, o or OFF after turning the engine switch off.



FarmaS(

The lights are turned off in the following situations.

- The engine switch is turned to IGNITION ON mode.
- The light switch is turned on.
- The light switch is pulled toward you and then released.

AFS (Adaptive Front-lighting System)

AFS (Adaptive Front-lighting System) secures excellent visibility at intersections and on curves by automatically adjusting the direction of the light axis of the headlights according to vehicle speed and the degree of the tire's angle as controlled by steering input.

AFS operates at speeds of 10 km/h (6 mph) or higher.

■ Daytime running light system

To make your vehicle more visible to other drivers during daytime driving, the daytime running lights turn on automatically whenever the engine is started and the parking brake is released with the headlight switch off or in the AUTO position. (Illuminate brighter than the front position lights.) Daytime running lights are not designed for use at night.

■ Headlight control sensor

The sensor may not function properly if an object is placed on the sensor, or anything that blocks the sensor is affixed to the windshield.

Doing so interferes with the sensor detecting the level of ambient light and may cause the automatic headlight system to malfunction.



■ Automatic light off system

▶ For GCC countries*, Yemen, Jordan, Lebanon and Syria

The headlights and tail lights turn off automatically if the engine switch is switched to ACCESSORY mode or turned off and the driver's door is opened.

To turn the lights on again, turn the engine switch to IGNITION ON mode, or turn the light switch off once and then back to so so so.

- ▶ Vehicles with a follow me home system
- When the light switch is in ≥0€, , ≦○ or ≣○: The headlights turn off automatically if the engine switch is switched to ACCESSORY mode or turned off.
- When the light switch is in AUTO: The headlights and all lights turn off automatically if the engine switch is switched to ACCESSORY mode or turned off.

To turn the lights on again, turn the engine switch to IGNITION ON mode, or turn the light switch off once and then back to \$\infty\$0\in , \$\equiv \infty\$0 or \$\equiv 0.

▶ Vehicles without a follow me home system except for GCC countries*, Yemen, Jordan, Lebanon and Syria

When the light switch is in Auro: The headlights and tail lights turn off 30 seconds after the engine switch is turned to ACCESSORY mode or turned off and a door is opened and all of the doors and trunk are closed. (The lights turn off immediately if on the key is pressed after all the doors are closed.)

To turn the lights on again, turn the engine switch to IGNITION ON mode, or turn the light switch off once and then back to 0.00, 0.00, 0.00 or 0.00.

If any of the doors or trunk lid is kept open, the lights automatically turn off after 20 minutes.

- *: Saudi Arabia, Sultanate of Oman, Bahrain, United Arab Emirates, Qatar, Kuwait
- Light reminder buzzer (except for GCC countries*, Yemen, Jordan, Lebanon and Syria)

A buzzer sounds when the engine switch is turned off or turned to ACCESSORY mode and the driver's door is opened while the lights are turned on.

*: Saudi Arabia, Sultanate of Oman, Bahrain, United Arab Emirates, Qatar, Kuwait

■ Automatic headlight leveling system

The level of the headlights is automatically adjusted according to the number of passengers and the loading condition of the vehicle to ensure that the headlights do not interfere with other road users.

■ Battery-saving function

In the following conditions, the remaining lights will go off automatically after 20 minutes in order to prevent the vehicle battery from being discharged:

- The headlights and/or tail lights are on.
- The engine switch is turned to ACCESSORY mode or turned off.
- Vehicles with a follow me home system: The light switch is in

 □

 O, □

 O or AUTO.

This function will be canceled in any of the following situations:

- When the engine switch is turned to IGNITION ON mode.
- When the light switch is operated.
- When the door or trunk is opened or closed.

■ Customization

Settings (e.g. light sensor sensitivity) can be changed. (Customizable features \rightarrow P. 667)

♠ NOTICE

■To prevent battery discharge


Do not leave the lights on longer than necessary when the engine is not running.


تلفن شبانه روزی: ۱۹۸۰ ۲۹۸۸۶۲ ۲۲۰

AHS (Adaptive High-beam System)*

The Adaptive High-beam System uses an in-vehicle camera sensor to assess the brightness of streetlights, the lights of oncoming and preceding vehicles, etc., and automatically turns high beam and variable shade beam on or off as necessary.

When variable shade beam is on. the illumination of the area surrounding oncoming vehicles and preceding vehicles is partially shielded while all other areas continue to be illuminated in high beam. This enables forward lighting to be optimized without blinding surrounding traffic.









Activating the Adaptive High-beam System

Push the lever away from you with the headlight switch in AUTO, ■○ or ■○ position.



2 Press the Adaptive High-beam System switch.

The Adaptive High-beam System indicator will come on when the headlights are turned on automatically to indicate that the system is active.



تلفن شبانه روزی: ۱۵۸۰۲۹۸۸۸–۲۲۰


Turning the high beam on/off manually

■ Switching to low beam

Pull the lever to original position.

The Adaptive High-beam System indicator will turn off.

Push the lever away from you to activate the Adaptive High-beam System again.




■ Switching to high beam

Press the Adaptive High-beam System switch.

The Adaptive High-beam System indicator will turn off and the high beam indicator will turn on.

Press the switch to activate the Adaptive High-beam System again.



High beam, low beam and variable shade beam automatic turning on conditions

- When all of the following conditions are fulfilled, high beam will be automatically turned on (after approximately 1 second):
 - Vehicle speed is above approximately 60 km/h (37 mph).
 - The area ahead of the vehicle is dark.
 - There are no oncoming or preceding vehicles with headlights or tail lights turned on.
- If any of the following conditions are fulfilled, low beam will be automatically turned on, depending on the location of oncoming or preceding vehicles:
 - Vehicle speed drops below approximately 40 km/h (25 mph).
 - The area ahead of the vehicle is not dark.
 - Preceding vehicles are moving quickly and high beams may blind the drivers of the other vehicles.
- When all of the following conditions are fulfilled, variable shade beam will be automatically turned on, depending on the location of oncoming or preceding vehicles:
 - Vehicle speed is above approximately 60 km/h (37 mph).
 - The area ahead of the vehicle is dark.

■ The Adaptive High-beam System can be operated when

The engine switch is in IGNITION ON mode.

■ Camera sensor detection information

- High beam may not be automatically turned off or changed to variable shade beam in the following situations:
 - When oncoming vehicles suddenly appear from a curve
 - · When the vehicle is cut in front of by another
 - When oncoming or preceding vehicles are hidden from sight due to repeated curves, road dividers or roadside trees
- High beam may be turned off or variable shade beam may be changed to if an oncoming vehicle that is using fog lights without using the headlights is detected.
- House lights, street lights, red traffic signals, and illuminated billboards or signs may
 cause the high beam to turn off or variable shade beam to be changed to and may
 change the area that is shielded.
- The following factors may affect the amount of time taken to turn high beam on or off, or the speed by which the shielded areas change:
 - The brightness of headlights, fog lights, and tail lights of oncoming and preceding vehicles
 - The movement and direction of oncoming and preceding vehicles
 - · When a oncoming or preceding vehicle only has operational lights on one side
 - · When a oncoming or preceding vehicle is a two-wheeled vehicle
 - The condition of the road (gradient, curve, condition of the road surface etc.)
 - The number of passengers and amount of luggage
- High beam and variable shade beam may be turned on or off when unexpected by the driver.
- Small vehicles, such as bicycles, may not be detected.

- In the situations below, the system may not be able to correctly detect the surrounding brightness levels, and may flash or expose oncoming or preceding vehicles to the high beam or may continue using the low beam. Therefore, in these situations you should consider turning the high beams on or off manually rather than relying on the Adaptive High-beam System.
 - In bad weather (rain, snow, fog, sandstorms etc.)
 - The windshield is obscured by fog, mist, ice, dirt etc.
 - The windshield is cracked or damaged.
 - The inside rear view mirror or camera sensor is deformed or dirty.
 - The camera sensor temperature is extremely high.
 - Surrounding brightness levels are equal to those of headlights, tail lights or fog lights.
 - Vehicles ahead have headlights that are either switched off, dirty, are changing color, or have are not aimed properly.
 - When driving through an area of intermittently changing brightness and darkness.
 - When frequently and repeatedly driving ascending/descending roads, or roads with rough, bumpy or uneven surfaces (such as stone-paved roads, gravel tracks etc.).
 - · When frequently and repeatedly taking curves or driving on a winding road.
 - There is a highly reflective object ahead of the vehicle, such as a sign or a mirror.
 - The back of a vehicle ahead is highly reflective, such as a container on a truck.
 - The vehicle's headlights are damaged or dirty.
 - The vehicle is listing or tilting, due to a flat tire, a trailer being towed etc.
- Turning the high beam on during Adaptive High-beam System (except vehicles with both LED headlights and near-infrared ray transmitters)

When the vehicle is traveling at a high speed, the system will turn on the inner high beam together with the outer high beam.

■ Customization

The variable shade beam can be turned off. (Customizable features \rightarrow P. 667)



■ Limitations of the Adaptive High-beam System

Do not rely on the Adaptive High-beam System. Always drive safely, taking care to observe your surroundings and turn the high beam on or off manually if necessary.

4-3. Operating the lights and wipers

№ NOTICE

■ Notes when using the Adaptive High-beam System

Observe the following to ensure that the Adaptive High-beam System functions correctly.




- Do not touch the camera sens
- Do not subject the inside rear view mirror or the camera sensor to a strong impact.
- Do not disassemble the camera sensor.
- Do not spill liquid onto the inside rear view mirror or the camera sensor.
- Do not apply window tinting or stickers to the camera sensor or the area of windshield near the camera sensor.
- Do not place items on the dashboard. There is a possibility that the camera sensor will mistake items reflected in the windshield for streetlights, the headlights of other vehicles, etc.
- Do not install a parking tag or any other accessories near or around the inside rear view mirror and the camera sensor.
- Do not overload the vehicle.
- Do not modify the vehicle.
- If the windshield needs to be replaced, contact your Lexus dealer.

Fog light switch

The fog lights secure excellent visibility in difficult driving conditions, such as in rain and fog.

- ▶ Front fog light switch
- 1 o Turns the front fog lights off
- 2 #D Turns the front fog lights on




- ► Front and rear fog light switch (left-hand drive vehicles)
- 1 o Turns the front and rear fog lights off
- ② 起 Turns the front fog lights on

Releasing the switch ring returns it to



Operating the switch ring again turns only the rear fog lights off.




- ► Front and rear fog light switch (right-hand drive vehicles)
- 1) OFF Turns the front and rear fog lights off
- 2 # Turns the front fog lights on

Releasing the switch ring returns it to



Operating the switch ring again turns only the rear fog lights off.



■ Fog lights can be used when

Front fog lights: The headlights or the front position lights are turned on.

Rear fog lights: The front fog lights are turned on.

Windshield wipers and washer

Operating the wiper lever

Operate the lever as follows to operate the wipers.


- ▶ Left-hand drive vehicles
- 1 _ Temporary operation
- 2) Auto Rain-sensing wiper operation

The wipers will operate automatically when the sensor detects falling rain. The system automatically adjusts wiper timing in accordance with rain volume and vehicle speed.


- (3) Low speed wiper operation
- (4) High speed wiper operation

When "AUTO" mode is selected, الفن شبانه روزی: ها the sensor sensitivity can be adjusted by turning the switch ring.

- 5 Increases the sensitivity
- (6) Decreases the sensitivity
- Washer/wiper dual operation
 Wipers will automatically operate a couple of times after the washer squirts.








- ► Right-hand drive vehicles
- 1 MIST Temporary operation
- 2) Auto Rain-sensing wiper operation


The wipers will operate automatically when the sensor detects falling rain. The system automatically adjusts wiper timing in accordance with rain volume and vehicle speed.


- 3 Lo Low speed wiper operation
- 4 HI High speed wiper operation

When "AUTO" mode is selected, the sensor sensitivity can be adjusted by turning the switch ring.

- (5) Decreases the sensitivity
- (6) Increases the sensitivity









■ The windshield wiper and washer can be operated when

The engine switch is in IGNITION ON mode.

■ Dripping prevention wiper sweep

After washing and the wiper has operated several times, the wipers operate one more time after a short delay to prevent dripping.

However, the last sweep will not happen if the vehicle is traveling above 170 km/h (106 mph).

■ Effects of vehicle speed on wiper operation

Even when the wipers are not in "AUTO" mode, vehicle speed affects the time until the drip prevention wiper sweep occurs.


With low speed windshield wiper operation selected, wiper operation will be switched from low speed to intermittent wiper operation only when the vehicle is stationary.

(However, when the sensor sensitivity is adjusted to the highest level, the mode cannot be switched.)

■ Raindrop sensor

 The raindrop sensor judges the amount of raindrops.

An optical sensor is adopted. It may not operate properly when sunlight from the rising or setting of the sun intermittently strikes the windshield, or if bugs etc. are present on the windshield.



- If the wiper is turned to "AUTO" mode while the engine switch is in IGNITION ON mode, the wipers will operate once to show that "AUTO" mode is activated.
- If the temperature of the raindrop sensor is 90°C (194°F) or higher, or -15°C (5°F) or lower, automatic operation may not occur. In this case, operate the wipers in any mode other than "AUTO" mode.

■ If no windshield washer fluid sprays

Check that the washer nozzles are not blocked if there is washer fluid in the windshield washer fluid reservoir.

Outside rear view mirror defogger activation linked to windshield wiper operation

The outside rear view mirror defoggers automatically turn on when you operate the windshield wipers.

The outside rear view mirror defoggers automatically turn off approximately 15 minutes after the wipers stop.

For details about the outside rear view mirror defoggers: →P. 445

A CAUTION

■ Caution regarding the use of windshield wipers in "AUTO" mode

The windshield wipers may operate unexpectedly if the sensor is touched or the windshield is subject to vibration in "AUTO" mode. Take care that your fingers or anything else do not become caught in the windshield wipers.

■ Caution regarding the use of washer fluid

When it is cold, do not use the washer fluid until the windshield becomes warm. The fluid may freeze on the windshield and cause low visibility. This may lead to an accident, resulting in death or serious injury.



■ When the windshield is dry

Do not use the wipers, as they may damage the windshield.

■ When there is no washer fluid spray from the nozzle

Damage to the washer fluid pump may be caused if the lever is pulled toward you and held continually.


■ When a nozzle becomes blocked

In this case, contact your Lexus dealer. * مبانه روزی: Do not try to clear it with a pin or other object. The nozzle will be damaged.

Headlight cleaner switch

Washer fluid can be sprayed on the headlights.

Press the switch to clean the headlights.



■ The headlight cleaners can be operated when
The engine switch is in IGNITION ON mode and the headlight switch is turned on.

■ Windshield washer linked operation

When the windshield washer is operated with the engine switch in IGNITION ON mode and the headlights on, the headlight cleaners will operate once. $(\rightarrow P.~300)$



■ When the washer fluid tank is empty

Do not press the switch continually as the washer fluid pump may overheat.

Opening the fuel tank cap

Perform the following steps to open the fuel tank cap:

Before refueling the vehicle

- Close all the doors and windows, and turn the engine switch off.
- Confirm the type of fuel.

■ Fuel types

→P. 665

■ Fuel tank opening for unleaded gasoline

To help prevent incorrect fueling, your vehicle has a fuel tank opening that only accommodates the special nozzle on unleaded fuel pumps.



A CAUTION

■ When refueling the vehicle

Observe the following precautions while refueling the vehicle. Failure to do so may result in death or serious injury.

- After exiting the vehicle and before opening the fuel door, touch an unpainted metal surface to discharge any static electricity. It is important to discharge static electricity before refueling because sparks resulting from static electricity can cause fuel vapors to ignite while refueling.
- Always hold the grips on the fuel tank cap and turn it slowly to remove it. A whooshing sound may be heard when the fuel tank cap is loosened. Wait until the sound cannot be heard before fully removing the cap. In hot weather, pressurized fuel may spray out the filler neck and cause injury.
- Do not allow anyone that has not discharged static electricity from their body to come close to an open fuel tank.
- Do not inhale vaporized fuel.
 Fuel contains substances that are harmful if inhaled.
- Do not smoke while refueling the vehicle.
 Doing so may cause the fuel to ignite and cause a fire.
- Do not return to the vehicle or touch any person or object that is statically charged.

This may cause static electricity to build up, resulting in a possible ignition hazard.

■ When refueling

Observe the following precautions to prevent fuel overflowing from the fuel tank:

- Securely insert the fuel nozzle into the fuel filler neck.
- Stop filling the tank after the fuel nozzle automatically clicks off.
- Do not top off the fuel tank.

⚠ NOTICE


■ Refueling

Do not spill fuel during refueling.

Doing so may damage the vehicle, such as causing the emission control system to operate abnormally or damaging fuel system components or the vehicle's painted surface.

Opening the fuel tank cap


1 Press the opener switch.



2 Turn the fuel tank cap slowly to open.




Hang the fuel tank cap on the back of the fuel filler door.



FarmaS


■ When the fuel filler door cannot be opened by pressing the inside switch

Remove the cover inside the trunk and pull the lever.



Closing the fuel tank cap

After refueling, turn the fuel tank cap until you hear a click. Once the cap is released, it will turn slightly in the opposite direction.



A CAUTION

■ When replacing the fuel tank cap

Do not use anything but a genuine Lexus fuel tank cap designed for your vehicle. Doing so may cause a fire or other incident which may result in death or serious injury.

Cruise control*

Summary of functions

Use the cruise control to maintain a set speed without depressing the accelerator pedal.

- (1) Indicators
- (2) Cruise control switch




Setting the vehicle speed

1 Press the "ON•OFF" button to activate the cruise control.


Cruise control indicator will come on.

Press the button again to deactivate the cruise control.



- 2 Accelerate or decelerate the vehicle to the desired speed, and push the lever down to set the speed.
 - "SET" indicator will come on.

The vehicle speed at the moment the lever is released becomes the set speed.




Adjusting the set speed

To change the set speed, operate the lever until the desired set speed is obtained.

- 1) Increases the speed
- 2 Decreases the speed

Fine adjustment: Momentarily move the lever in the desired direction.

Large adjustment: Hold the lever in the desired direction.



The set speed will be increased or decreased as follows:

Fine adjustment: By approximately 1.6 km/h (1 mph) each time the lever is operated.

Large adjustment: The set speed can be increased or decreased continually until the lever is released.


Canceling and resuming the constant speed control

1 Pulling the lever toward you cancels the constant speed control.

The speed setting is also canceled when the brakes are applied.

2 Pushing the lever up resumes the constant speed control.

Resuming is available when the vehicle speed is more than approximately $40 \, \text{km/h} \, (25 \, \text{mph})$.



Cruise control can be set when

- The shift lever is in the D or range 4 or higher of S has been selected.
 (vehicles without paddle shift switches)
- The shift lever is in D. (vehicles with paddle shift switches)
- Range 4 or higher of D has been selected by using the paddle shift.
 (vehicles with paddle shift switches)
- Vehicle speed is above approximately 40 km/h (25 mph).

■ Accelerating after setting the vehicle speed

- The vehicle can be accelerated normally. After acceleration, the set speed resumes.
- Even without canceling the cruise control, the set speed can be increased by first accelerating the vehicle to the desired speed and then pushing the lever down to set the new speed.

■ Automatic cruise control cancelation

Cruise control will stop maintaining the vehicle speed in any of the following situations.

- Actual vehicle speed falls more than approximately 16 km/h (10 mph) below the preset vehicle speed.
 At this time, the memorized set speed is not retained.
- Actual vehicle speed is below approximately 40 km/h (25 mph).
- VSC is activated.
- •TRC is activated for a period of time. OS. COM
- When the VSC or TRC system is turned off by pressing the VSC OFF switch.

If the warning message for the cruise control is shown on the multi-information display

Press the "ON \cdot OFF" button once to deactivate the system, and then press the button again to reactivate the system.

If the cruise control speed cannot be set or if the cruise control cancels immediately after being activated, there may be a malfunction in the cruise control system. Have the vehicle inspected by your Lexus dealer.



■To avoid operating the cruise control by mistake

Switch the cruise control off using the "ON•OFF" button when not in use.

■ Situations unsuitable for cruise control

Do not use cruise control in any of the following situations.

Doing so may result in loss of control and could cause an accident resulting in death or serious injury.

- In heavy traffic
- On roads with sharp bends
- On winding roads
- On slippery roads, such as those covered with rain, ice or snow
- On steep hills
 Vehicle speed may exceed the set speed when driving down a steep hill.

تلفن شیانه روزی: ۲۱–۸۸۸۶۲۰۸۵

Dynamic radar cruise control*

Summary of functions

Dynamic radar cruise control supplements conventional cruise control with a vehicle-to-vehicle distance control. In vehicle-to-vehicle distance control mode, the vehicle automatically accelerates or decelerates in order to maintain a set following distance from vehicles ahead.



- 2 Display
- (3) Set speed
- (4) Indicators
- (5) Cruise control switch



Setting the vehicle speed (vehicle-to-vehicle distance control mode)

1 Press the "ON•OFF" button to activate the cruise control.


Radar cruise control indicator will come on.


Press the button again to deactivate the cruise control.

Accelerate or decelerate the vehicle to the desired speed, and push the lever down to set the speed.

"SET" indicator will be displayed.

The vehicle speed at the moment the lever is released becomes the set speed.






Adjusting the set speed

To change the set speed, operate the lever until the desired set speed is displayed.

- 1 Increases the speed
- (2) Decreases the speed

Fine adjustment: Momentarily move the lever in the desired direction.

Large adjustment: Hold the lever in the desired direction.



In the vehicle-to-vehicle distance control mode, the set speed will be increased or decreased as follows:

Fine adjustment: By approximately $1 \, \text{km/h} (0.6 \, \text{mph})$ each time the lever is operated

Large adjustment: By approximately $5 \, \text{km/h} (3.1 \, \text{mph})$ for each $0.75 \, \text{seconds}$ the lever is held

In the constant speed control mode (\rightarrow P.320), the set speed will be increased or decreased as follows:

Fine adjustment: By approximately 1.6 km/h (1 mph) each time the lever is operated

Large adjustment: The set speed can be increased or decreased continually until the lever is released.


Changing the vehicle-to-vehicle distance

Pressing the button changes the vehicle-to-vehicle distance as follows:

- (1) Long
- (2) Medium
- 3 Short

The vehicle-to-vehicle distance is set automatically to long mode when the engine switch is turned to IGNITION ON mode.

If a vehicle is running ahead of you, the preceding vehicle mark will also be displayed.



Vehicle-to-vehicle distance settings

Select a distance from the table below. Note that the distances shown correspond to a vehicle speed of 80 km/h (50 mph). Vehicle-to-vehicle distance increases/decreases in accordance with vehicle speed.

Distance options	Vehicle-to-vehicle distance
Long	Approximately 50 m (160 ft.)
Medium	Approximately 40 m (130 ft.)
Short	Approximately 30 m (100 ft.)


Canceling and resuming the speed control

1 Pulling the lever toward you cancels the cruise control.

The speed setting is also canceled when the brakes are applied.

2 Pushing the lever up resumes the cruise control and returns vehicle speed to the set speed.

Resuming is available when the vehicle speed is more than approximately 40 km/h (25 mph).






تلفن شبانه روزی: ۱۵۸۰۲۹۸۸۸–۲۲۰

Driving in vehicle-to-vehicle distance control mode

This mode employs a radar sensor to detect the presence of vehicles up to approximately 120 m (400 ft.) ahead, determines the current vehicle-to-vehicle following distance, and operates to maintain a suitable following distance from the vehicle ahead.

Note that vehicle-to-vehicle distance will close in when traveling on long downhill slopes.



1 Example of constant speed cruising

When there are no vehicles ahead

The vehicle travels at the speed set by the driver. The desired vehicle-to-vehicle distance can also be set by operating the vehicle-to-vehicle distance control.

2 Example of deceleration cruising When the vehicle ahead is driving slower than the set speed

When a vehicle is detected running ahead of you, the system automatically decelerates your vehicle. When a greater reduction in vehicle speed is necessary, the system applies the brakes. A warning tone warns you when the system cannot decelerate sufficiently to prevent your vehicle from closing in on the vehicle ahead.

(3) Example of follow-up cruising

When following a vehicle driving slower than the set speed

The system continues follow-up cruising while adjusting for changes in the speed of the vehicle ahead in order to maintain the vehicle-to-vehicle distance set by the driver.

(4) Example of acceleration

When there are no longer any vehicles ahead driving slower than the set speed

The system accelerates until the set speed is reached. The system then returns to constant speed cruising.

Approach warning

When your vehicle is too close to a vehicle ahead, and sufficient automatic deceleration via the cruise control is not possible, the display will flash and the buzzer will sound to alert the driver. An example of this would be if another driver cuts in front of you while you are following a vehicle. Apply the brakes to ensure an appropriate vehicle-to-vehicle distance.

■ Warnings may not occur when

In the following instances, there is a possibility that the warnings will not occur:

- When the speed of the vehicle ahead matches or exceeds your vehicle speed
- When the vehicle ahead is traveling at an extremely slow speed
- Immediately after the cruise control speed was set
- At the instant the accelerator is applied

Selecting conventional constant speed control mode

When constant speed control mode is selected, your vehicle will maintain a set speed without controlling the vehicle-to-vehicle distance. Select this mode only when vehicle-to-vehicle distance control mode does not function correctly due to dirt etc.

1 Press the "ON•OFF" button to activate the cruise control.

Radar cruise control indicator will come on.

Press the button again to deactivate the cruise control.



(Push the lever forward and hold for approximately 1 second.)

Cruise control indicator will come on.

When in constant speed control متلفن شبانه روزی: mode, to return to vehicle-to-vehicle distance control mode, push the lever forward again and hold for approximately 1 second.


After the desired speed has been set, it is not possible to return to vehicle-to-vehicle distance control mode.

If the engine switch is turned off and then turned to IGNITION ON mode again, the vehicle will automatically return to vehicle-to-vehicle distance control mode.

Adjusting the speed setting:

 \rightarrow P. 315

Canceling and resuming the speed setting: \rightarrow P. 317



Dynamic radar cruise control can be set when

- The shift lever is in the D or range 4 or higher of S has been selected.
 (vehicles without paddle shift switches)
- The shift lever is in D. (vehicles with paddle shift switches)
- Range 4 or higher of D has been selected by using the paddle shift.
 (vehicles with paddle shift switches)
- Vehicle speed is above approximately 50 km/h (30 mph).

■ Accelerating after setting the vehicle speed

The vehicle can accelerate normally. After acceleration, the set speed resumes. However, during vehicle-to-vehicle distance control mode, the vehicle speed may decrease below the set speed in order to maintain the distance to the vehicle ahead.

■ Automatic cancelation of vehicle-to-vehicle distance control

Vehicle-to-vehicle distance control driving is automatically canceled in the following situations:

- Actual vehicle speed falls below approximately 40 km/h (25 mph).
- VSC is activated.
- TRC is activated for a period of time.
- When the VSC or TRC system is turned off by pressing the VSC OFF switch.
- The sensor cannot operate correctly because it is covered in some way.
- The windshield wipers are operating at high speed (when the wiper switch is set to the "AUTO" mode or the high speed wiper operation position).
- When snow mode is set.

If vehicle-to-vehicle distance control driving is automatically canceled for any other reason, there may be a malfunction in the system. Contact your Lexus dealer.

■ Automatic cancelation of constant speed control

The cruise control will stop maintaining the vehicle speed in the following situations:

- Actual vehicle speed is more than approximately 16 km/h (10 mph) below the set vehicle speed.
 - At this time, the memorized set speed is not retained.
- Actual vehicle speed falls below approximately 40 km/h (25 mph).
- VSC is activated.
- TRC is activated for a period of time.
- When the VSC or TRC system is turned off by pressing the VSC OFF switch.

■ Radar sensor and grille cover

Always keep the sensor and grille cover clean to ensure that the vehicle-to-vehicle distance control operates properly. (Some obstructions, such as snow, ice and plastic objects, cannot be detected by the obstruction sensor.)

Dynamic radar cruise control is canceled if an obstruction is detected.

1 Grille cover

(2) Radar sensor



■ Warning messages and buzzers for dynamic radar cruise control

Warning messages and buzzers are used to indicate a system malfunction or to inform the driver of the need for caution while driving. $(\rightarrow P. 614)$

■ Certification for the dynamic radar cruise control

► For vehicles sold in Jordan

TRC approval's number: TRC/LPD/2008/85

► For vehicles sold in Taiwan

經型式認證合格之低功率射頻電機,非經許可,公司、商號或使用者均不得 擅自變更頻率、加大功率或變更原設計之特性及功能。

低功率射頻電機之使用不得影響飛航安全及干擾合法通信;經發現有干擾現象時,應立即停用,並改善至無干擾時方得繼續使用。 前項合法通信,指依電信法規定作業之無線電通信。 低功率射頻電機須忍受合法通信或工業、科學及醫療用電波輻射性電機設備 之干擾。

► For vehicles sold in Thailand



To avoid hazard that may happen from electromagnetic wave, please keep the distance more than 45 cm from pre-crash sensor when it is being operated.

This telecommunication equipment conforms to technical standard NTC TS 1011-2549.

A CAUTION

■ Before using dynamic radar cruise control

Do not overly rely on vehicle-to-vehicle distance control.

Be aware of the set speed. If automatic deceleration/acceleration is not appropriate, adjust the vehicle speed, as well as the distance between your vehicle and vehicles ahead by applying the brakes etc.

Cautions regarding the driving assist systems

Observe the following precautions.

Failure to do so may cause an accident resulting in death or serious injury.

- Assisting the driver to measure following distance The dynamic radar cruise control is only intended to help the driver in determining the following distance between the driver's own vehicle and a designated vehicle traveling ahead. It is not a mechanism that allows careless or inattentive driving, and it is not a system that can assist the driver in low-visibility conditions. It is still necessary for driver to pay close attention to the vehicle's surroundings.
- Assisting the driver to judge proper following distance
 The dynamic radar cruise control determines whether the following distance
 between the driver's own vehicle and a designated vehicle traveling ahead is
 appropriate or not. It is not capable of making any other type of judgement.
 Therefore, it is absolutely necessary for the driver to remain vigilant and to determine whether or not there is a possibility of danger in any given situation.
- Assisting the driver to operate the vehicle The dynamic radar cruise control has no capability to prevent or avoid a collision with a vehicle traveling ahead. Therefore, if there is ever any danger, the driver must take immediate and direct control of the vehicle and act appropriately in order to ensure the safety of all involved.

- To avoid inadvertent cruise control activation
 - Switch the cruise control off using the "ON•OFF" button when not in use.
- Situations unsuitable for dynamic radar cruise control

Do not use dynamic radar cruise control in any of the following situations. Doing so may result in inappropriate speed control and could cause an accident resulting in death or serious injury.

- In heavy traffic
- On roads with sharp bends
- On winding roads
- On slippery roads, such as those covered with rain, ice or snow
- On steep downhills, or where there are sudden changes between sharp up and down gradients
 Vehicle speed may exceed the set speed when driving down a steep hill.
- At entrances to expressways
- When weather conditions are bad enough that they may prevent the sensors from functioning correctly (fog, snow, sandstorm, heavy rain, etc.)
- When an approach warning buzzer is heard often

■ When the sensor may not be correctly detecting the vehicle ahead

Apply the brakes as necessary when any of the following types of vehicles are in front of you.

As the sensor may not be able to correctly detect these types of vehicles, the approach warning (\rightarrow P. 319) will not be activated, and a fatal or serious accident may result.

- Vehicles that cut in suddenly
- Vehicles traveling at low speeds
- Vehicles that are not moving
- Vehicles with small rear ends (trailers with no load on board etc.)
- Motorcycles traveling in the same lane
- Conditions under which the vehicle-to-vehicle distance control may not function correctly

Apply the brakes as necessary in the following conditions as the radar sensor may not be able to correctly detect vehicles ahead, and a fatal or serious accident may result:

- When water or snow thrown up by the surrounding vehicles hinders the functioning of the sensor
- When your vehicle is pointing upwards (caused by a heavy load in the trunk etc.)
- When the road curves or when the lanes are narrow
- When steering wheel operation or your position in the lane is unstable
- When the vehicle ahead of you decelerates suddenly

■ Handling the radar sensor

Observe the following to ensure the cruise control system can function effectively.

Otherwise, the system may not function correctly and could result in an accident.

- Keep the sensor and grille cover clean at all times.
 Clean the sensor and grille cover with a soft cloth so you do not mark or damage them.
- Do not subject the sensor or surrounding area to a strong impact.
 If the sensor moves even slightly off position, the system may malfunction. If the sensor or surrounding area is subject to a strong impact, always have the area inspected and adjusted by your Lexus dealer.
- Do not disassemble the sensor.
- Do not attach accessories or stickers to the sensor, grille cover or surrounding area.
- Do not modify or paint the sensor and grille cover.
- If the radar sensor needs to be replaced, contact your Lexus dealer.


تلفن شبانه روزی: ۱۵۰۸۸۸۸ تلفن شبانه روزی: ۱۵۸۸۶ میانه

Dynamic radar cruise control with full-speed range *

Summary of functions

Dynamic radar cruise control with full-speed range supplements conventional cruise control with a vehicle-to-vehicle distance control. In vehicle-to-vehicle distance control mode, the vehicle automatically accelerates, decelerates or stops in order to maintain a set following distance from vehicles ahead.

- 1) Vehicle-to-vehicle distance button
- (2) Display
- (3) Set speed
- (4) Indicators
- (5) Cruise control switch



Setting the vehicle speed (vehicle-to-vehicle distance control mode)

1 Press the "ON•OFF" button to activate the cruise control.


Radar cruise control indicator will come on.


Press the button again to deactivate the cruise control.

Accelerate or decelerate the vehicle to the desired speed, and push the lever down to set the speed.

"SET" indicator will be displayed.

If this is performed when vehicle speed is less than about 50 km/h (30 mph) and the vehicle ahead can be detected, your vehicle will start following the vehicle ahead of you at a set speed of about 50 km/h (30 mph) (vehicle-to-vehicle distance control mode only).





Scom

Adjusting the set speed

To change the set speed, operate the lever until the desired set speed is displayed.

1 Increases the speed

(Except when the vehicle has been stopped by system control in vehicleto-vehicle distance control mode)

(2) Decreases the speed

Fine adjustment: Momentarily move the lever in the desired direction.

Large adjustment: Hold the lever in the desired direction.




Fine adjustment: By approximately $1\,\mathrm{km/h}$ (0.6 mph) each time the lever is operated

Large adjustment: By approximately $5\,\mathrm{km/h}$ (3.1 mph) for each 0.75 seconds the lever is held

In the constant speed control mode (\rightarrow P. 336), the set speed will be increased or decreased as follows:

Fine adjustment: By approximately 1.6 km/h (1 mph) each time the lever is operated

Large adjustment: The set speed can be increased or decreased continually until the lever is released.




Changing the vehicle-to-vehicle distance

Pressing the button changes the vehicle-to-vehicle distance as follows:

- (1) Long
- (2) Medium
- 3 Short

The vehicle-to-vehicle distance is set automatically to long mode when the engine switch is turned to IGNITION ON mode.

If a vehicle is running ahead of you, the preceding vehicle mark will also be displayed.



Vehicle-to-vehicle distance settings


Select a distance from the table below. Note that the distances shown correspond to a vehicle speed of 80 km/h (50 mph). Vehicle-to-vehicle distance increases/decreases in accordance with vehicle speed. When the vehicle is stopped by system control, the vehicle-to-vehicle distance will be about 3 m (10 ft.) to 5 m (16 ft.) regardless of the vehicle-to-vehicle distance setting.

Distance options	Vehicle-to-vehicle distance
Long	Approximately 50 m (160 ft.)
Medium	Approximately 40 m (130 ft.)
Short	Approximately 30 m (100 ft.)

Resuming follow-up cruising when the vehicle has been stopped by system control

After the vehicle ahead of you starts off, push the lever up.

Your vehicle will also resume followup cruising if the accelerator pedal is depressed after the vehicle ahead of you starts off.





تلفن شبانه روزی: ۱۵۸۰۲۹۸۸ - ۲۱

Canceling and resuming the speed control


1) Pulling the lever toward you cancels the cruise control.

The setting is also canceled when the brake pedal is depressed while driving.

(When the vehicle has been stopped by system control, applying the brakes does not cancel the setting.)

2 Pushing the lever up resumes the cruise control and returns vehicle speed to the set speed.

However, when a vehicle ahead is not detected in vehicle-to-vehicle distance control mode, cruise control does not resume when the actual vehicle speed is approximately 40 km/h (25 mph) or less. Also, when the vehicle is in constant speed control mode and the actual vehicle speed is approximately 40 km/h (25 mph) or less, cruise control does not resume as the set speed is cleared.






Driving in vehicle-to-vehicle distance control mode

This mode employs a radar sensor to detect the presence of vehicles up to approximately 120 m (400 ft.) ahead, determines the current vehicle-to-vehicle following distance, and operates to maintain a suitable following distance from the vehicle ahead.

Note that vehicle-to-vehicle distance will close in when traveling on long downhill slopes.



 $\begin{tabular}{ll} \hline (1) Example of constant speed cruising \\ \hline \end{tabular}$

When there are no vehicles ahead

The vehicle travels at the speed set by the driver. The desired vehicle-to-vehicle distance can also be set by operating the vehicle-to-vehicle distance control.

2 Example of deceleration cruising and follow-up cruising When the vehicle ahead is driving slower than the set speed

When a vehicle is detected running ahead of you, the system automatically decelerates your vehicle. When a greater reduction in vehicle speed is necessary, the system applies the brakes. The system will respond to changes in the speed of the vehicle ahead in order to maintain the vehicle-to-vehicle distance set by the driver. A warning tone warns you when the system cannot decelerate sufficiently to prevent your vehicle from closing in on the vehicle ahead. When the vehicle ahead of you stops, your vehicle will also stop. After the vehicle ahead starts off, pushing the cruise control lever up or depressing the accelerator pedal will resume follow-up cruising.

(3) Example of acceleration

When there are no longer any vehicles ahead driving slower than the set speed

The system accelerates until the set speed is reached. The system then returns to constant speed cruising.

Approach warning

When your vehicle is too close to a vehicle ahead, and sufficient automatic deceleration via the cruise control is not possible, the display will flash and the buzzer will sound to alert the driver. An example of this would be if another driver cuts in front of you while you are following a vehicle. Apply the brakes to ensure an appropriate vehicle-to-vehicle distance.

■ Warnings may not occur when

In the following instances, there is a possibility that the warnings will not occur:

- When the speed of the vehicle ahead matches or exceeds your vehicle speed
- When the vehicle ahead is traveling at an extremely slow speed
- Immediately after the cruise control speed was set
- At the instant the accelerator is applied

Selecting conventional constant speed control mode

When constant speed control mode is selected, your vehicle will maintain a set speed without controlling the vehicle-to-vehicle distance. Select this mode only when vehicle-to-vehicle distance control mode does not function correctly due to dirt etc.

1) Press the "ON•OFF" button to activate the cruise control.

Radar cruise control indicator will come on.

Press the button again to deactivate the cruise control.



(Push the lever forward and hold for approximately 1 second.)

Cruise control indicator will come on.


When in constant speed control متلفن شبانه روزی: mode, to return to vehicle-to-vehicle distance control mode, push the lever forward again and hold for approximately 1 second.

After the desired speed has been set, it is not possible to return to vehicle-to-vehicle distance control mode.

If the engine switch is turned off and then turned to IGNITION ON mode again, the vehicle will automatically return to vehicle-to-vehicle distance control mode.

Adjusting the speed setting: \rightarrow P. 330

Canceling and resuming the speed setting: \rightarrow P. 333



Dynamic radar cruise control with full-speed range can be set when

- The shift lever is in the D or range 4 or higher of S has been selected.
 (vehicles without paddle shift switches)
- The shift lever is in D. (vehicles with paddle shift switches)
- Range 4 or higher of D has been selected by using the paddle shift.
 (vehicles with paddle shift switches)
- Vehicle speed is above approximately 50 km/h (30 mph).

Accelerating after setting the vehicle speed

The vehicle can accelerate normally. After acceleration, the set speed resumes. However, during vehicle-to-vehicle distance control mode, the vehicle speed may decrease below the set speed in order to maintain the distance to the vehicle ahead.

Automatic cancelation of vehicle-to-vehicle distance control

Vehicle-to-vehicle distance control driving is automatically canceled in the following situations:

- Actual vehicle speed falls below approximately 40 km/h (25 mph) when there are no vehicle ahead.
- The preceding vehicle leaves the lane when your vehicle is following at a speed below 40 km/h (25 mph).
- VSC is activated.
- TRC is activated for a period of time.
- When the VSC or TRC system is turned off by pressing the VSC OFF switch.
- The sensor cannot operate correctly because it is covered in some way.
- The windshield wipers are operating at high speed (when the wiper switch is set to the "AUTO" mode or the high speed wiper operation position).
- When snow mode is set.
- The parking brake is operated.
- The vehicle is stopped by system control on a steep incline.
- Pre-crash brake assist is activated.
- The following are detected when the vehicle has been stopped by system control:
 - The driver is not wearing a seat belt.
 - The driver's door is opened.
 - The trunk or hood is opened.
 - The vehicle has been stopped for about 3 minutes.

If vehicle-to-vehicle distance control driving is automatically canceled for any other reason, there may be a malfunction in the system. Contact your Lexus dealer.

Automatic cancelation of constant speed control

The cruise control will stop maintaining the vehicle speed in the following situations:

- Actual vehicle speed is more than approximately 16 km/h (10 mph) below the set vehicle speed.
 - At this time, the memorized set speed is not retained.
- Actual vehicle speed falls below approximately 40 km/h (25 mph).
- VSC is activated.
- TRC is activated for a period of time.
- When the VSC or TRC system is turned off by pressing the VSC OFF switch.

■ When the LKA (Lane-Keeping Assist) will be activated (if equipped)

Using the radar cruise control in vehicle-to-vehicle distance control mode, lane keeping assistance control is activated.

■ Radar sensor and grille cover

Always keep the sensor and grille cover clean to ensure that the vehicle-to-vehicle distance control operates properly. (Some obstructions, such as snow, ice and plastic objects, cannot be detected by the obstruction sensor.)

Dynamic radar cruise control with full-speed range is canceled if an obstruction is detected.

- 1 Grille cover
- 2 Radar sensor







■ Warning messages and buzzers for dynamic radar cruise control with full-speed range

Warning messages and buzzers are used to indicate a system malfunction or to inform the driver of the need for caution while driving. $(\rightarrow P. 614)$

4

■ Certification for the dynamic radar cruise control with full-speed range

► For vehicles sold in the United Arab Emirates

NOTICE

This equipment has been registered with the Telecommunications Regulatory Authority for use in the UAE.

TRA

REGISTERED No: 0022262/10 DEALER No: 0019826/09 DENSO: DNMWR004

► For vehicles sold in Ukraine

MODEL: DNMWR004







■ Before using dynamic radar cruise control with full-speed range

Do not overly rely on vehicle-to-vehicle distance control.

Be aware of the set speed. If automatic deceleration/acceleration is not appropriate, adjust the vehicle speed, as well as the distance between your vehicle and vehicles ahead by applying the brakes etc.

Cautions regarding the driving assist systems

Observe the following precautions.

Failure to do so may cause an accident resulting in death or serious injury.

- Assisting the driver to measure following distance
 The dynamic radar cruise control with full-speed range is only intended to help
 the driver in determining the following distance between the driver's own vehicle
 and a designated vehicle traveling ahead. It is not a mechanism that allows careless or inattentive driving, and it is not a system that can assist the driver in low-visibility conditions. It is still necessary for driver to pay close attention to the
 vehicle's surroundings.
- Assisting the driver to judge proper following distance The dynamic radar cruise control with full-speed range determines whether the following distance between the driver's own vehicle and a designated vehicle traveling ahead is appropriate or not. It is not capable of making any other type of judgement. Therefore, it is absolutely necessary for the driver to remain vigilant and to determine whether or not there is a possibility of danger in any given situation.
- Assisting the driver to operate the vehicle The dynamic radar cruise control with full-speed range has no capability to prevent or avoid a collision with a vehicle traveling ahead. Therefore, if there is ever any danger, the driver must take immediate and direct control of the vehicle and act appropriately in order to ensure the safety of all involved.

To avoid inadvertent dynamic radar cruise control with full-speed range activation

Switch the cruise control off using the "ON•OFF" button when not in use.

■ Situations unsuitable for dynamic radar cruise control with full-speed range

Do not use dynamic radar cruise control with full-speed range in any of the following situations.

Doing so may result in inappropriate speed control and could cause an accident resulting in death or serious injury.

- In heavy traffic
- On roads with sharp bends
- On winding roads
- On slippery roads, such as those covered with rain, ice or snow
- On steep downhills, or where there are sudden changes between sharp up and down gradients
 Vehicle speed may exceed the set speed when driving down a steep hill.
- At entrances to expressways
- When weather conditions are bad enough that they may prevent the sensors from functioning correctly (fog. snow, sandstorm, heavy rain, etc.)
- When an approach warning buzzer is heard often

■ When the sensor may not be correctly detecting the vehicle ahead

Apply the brakes as necessary when any of the following types of vehicles are in front of you.

As the sensor may not be able to correctly detect these types of vehicles, the approach warning (\rightarrow P. 335) will not be activated, and a fatal or serious accident may result.

- Vehicles that cut in suddenly
- Vehicles traveling at low speeds
- Vehicles that are not moving
- Vehicles with small rear ends (trailers with no load on board etc.)
- Motorcycles traveling in the same lane
- Conditions under which the vehicle-to-vehicle distance control may not function correctly

Apply the brakes as necessary in the following conditions as the radar sensor may not be able to correctly detect vehicles ahead, and a fatal or serious accident may result:

- When water or snow thrown up by the surrounding vehicles hinders the functioning of the sensor
- When your vehicle is pointing upwards (caused by a heavy load in the trunk etc.)
- When the road curves or when the lanes are narrow
- When steering wheel operation or your position in the lane is unstable
- When the vehicle ahead of you decelerates suddenly

■ Handling the radar sensor

Observe the following to ensure the cruise control system can function effectively.

Otherwise, the system may not function correctly and could result in an accident.

- Keep the sensor and grille cover clean at all times.
 Clean the sensor and grille cover with a soft cloth so you do not mark or damage them.
- Do not subject the sensor or surrounding area to a strong impact. If the sensor moves even slightly off position, the system may malfunction. If the sensor or surrounding area is subject to a strong impact, always have the area inspected and adjusted by your Lexus dealer.
- Do not disassemble the sensor.
- Do not attach accessories or stickers to the sensor, grille cover or surrounding area.
- Do not modify or paint the sensor and grille cover.
- If the radar sensor needs to be replaced, contact your Lexus dealer.

تلفن شبانه روزی: ۱۳۸۸۸/۲۰۸۸ تلفن شبانه روزی:

$LKA (Lane-Keeping Assist)^*$

Summary of functions


While driving on a freeway or motor highway that has lane markers and no sharp curves, the system recognizes the lanes using a camera located above the inside rear view mirror as a sensor to assist the driver with staying in the lane. The LKA system has two functions.

Camera sensor



تلفن شبانه روزی: ۱۵۸۰۲۹۸۸ - ۲۱

Functions included in the LKA



1 Lane departure warning function

If the system judges that the vehicle may deviate from its lane, it alerts the driver using rapid beeping, indications on the multi-information display, and a sensory warning* given via the steering wheel.

- *: A slight steering torque is applied for a short period of time in the direction of the center of the lane.
- 2 Lane keeping assist function
 - This function will be active when the vehicle-to-vehicle distance control mode of the dynamic radar cruise control with full-speed range (→P. 328) is set with vehicle speed above approximately 72 km/h (45 mph) and while the lane departure warning function is active.
 - When the lane keeping assist function is active, a slight steering torque will be applied, to help the driver maintain the vehicle inside the lane.

The lane keeping assist function will be temporarily canceled if the steering wheel is not operated, or if you continue driving with your hands lightly touching the steering wheel. $(\rightarrow P. 349)$


Turning the LKA system on

Press the LKA switch to activate the system.

LKA indicator will come on.

Press the switch again to turn the LKA system off.

The LKA system will revert to off each time the engine switch is turned to IGNITION ON mode.





تلفن شبانه روزی: ۱۲۰۸۸۶۲۰۲۵ تلفن شبانه روزی:

Operating conditions for each function

■ Lane departure warning function

- When the vehicle speed is approximately 48 km/h (30 mph) or more
- When the lane width is more than approximately 3.0 m (9.8 ft.)
- When driving on a straight road or through a curve with a radius of more than approximately 120 m (394 ft.)

■ Lane keeping assist function

- When the vehicle speed is between approximately 72 and 180 km/h
 (45 and 112 mph)
- When the vehicle-to-vehicle distance mode of the dynamic radar cruise control with full-speed range is on, and the set vehicle speed is approximately 72 km/h (45 mph) or more (the function will not operate when the dynamic radar cruise control with full-speed range is in set speed mode)
- When the lane width is between approximately 3.0 and 4.0 m (9.8 and 13.1 ft.)
- When driving on a straight road or through a curve with a radius of more than approximately 200 m (656 ft.)

Indication on the multi-information display

When the LKA system is on, the lane line display and steering wheel display are shown.

1 Lane keeping assist function operation indication

Steering wheel displayed:

Indicates that the function is currently operating. (If the lane departure warning operates at this time, the steering wheel flashes orange.)

Steering wheel not displayed:


Indicates that the function is not currently operating. (When the lane keeping assist function is canceled, the buzzer will beep twice.)

- 2 Dynamic radar cruise control with full-speed range display
- 3 Lane departure warning function indication (when the inside of the white line is white):

The function has recognized lane markers. (If the lane departure warning operates at this time, the lines flash orange.)

4 Lane departure warning function indication (when the inside of the white line is black):

A lane marker is not recognized by the system, or the LKA system functions are temporarily canceled.



0S.com

■ Temporary cancelation of the LKA system functions

If any of the following occurs, the LKA system functions will be temporarily canceled. The functions will resume after the necessary operating conditions have returned.

- The steering wheel is turned as far as necessary to cause the vehicle to change lanes.
- When the system detects no-handed driving. (The lane keeping assist function will be temporarily canceled, but the lane departure warning function will continue.)
- The turn signal lever is operated.
- The vehicle speed deviates from the operating range of the LKA system functions. (The buzzer will beep twice when the lane keeping assist function is being canceled.)
- When the lane lines cannot be recognized while driving. (The buzzer will beep twice when the lane keeping assist function is being canceled.)
- When the wiper switch is in the high speed position or is set to "AUTO" mode with the wipers operating at high speed. (The lane keeping assist function will be temporarily canceled, but the lane departure warning function will continue.)
- If the vehicle crosses a line for approximately half a minute or more. (The lane keeping assist function will be temporarily canceled, but the lane departure warning function will continue.)
- When the lane departure warning function is activated.

 The lane departure warning function will not operate again for several seconds after it has been activated, even if the vehicle leaves the lane again.

■ The lane departure warning

It may be difficult to feel the sensory warning depending on the road conditions.

■ No-handed driving warning

If the steering wheel is not operated for approximately 15 seconds on a straight road or approximately 5 seconds on a curve, the buzzer will beep twice, indicators on the multi-information display will flash, and the lane keeping assist function will be temporarily canceled. If you drive the vehicle with your hands lightly touching the steering wheel, this may also be detected as no-handed driving.

After the vehicle has been parked in the sun

The LKA system functions may not be available and a warning message (\rightarrow P. 614) will be displayed for a while after driving has started. In such cases, turn the LKA system off and turn it on again after normal temperature returns. When the temperature in the cabin decreases and the temperature around the camera sensor (\rightarrow P. 344) becomes suitable for its operation, the functions will begin to operate.

■ If there are lane markers on only one side of the vehicle

The lane keeping assist function will not operate. Also, the lane departure warning will not operate for the side on which lane markers could not be recognized.

■ Conditions in which the function may not operate correctly

In the following conditions, the LKA system functions may not operate, or it may not be possible to ensure adequate performance. Also, the camera sensor may be unable to recognize lane lines causing the lane departure warning function to operate incorrectly, or the lane keeping assist function may not operate properly. However, this does not indicate a malfunction.

- When driving through an area with no lane markers, such as a tollbooth, a crossing or before a ticket checkpoint
- When driving on a sharp curve
- When lanes are extremely narrow or extremely wide
- When the vehicle leans to one side an unusual amount due to a heavy load or improper tire inflation pressure
- When the following distance between your vehicle and the vehicle ahead is extremely short
- When the lane markers are yellow (These may be more difficult for the system to recognize compared to white markers.)
- When the lane markers are broken, "Raised pavement marker" or stones
- When lane markers are obscured or partially obscured by sand, dirt, etc.
- When there are shadows on the road running parallel with lane markers, or if a shadow covers the lane markers
- When driving on a particularly bright road surface, such as concrete
- When driving on a road surface that is bright due to reflected light
- When driving in a location where the light level changes rapidly, such as the entrance to or exit from a tunnel
- When sunlight or the headlights of oncoming vehicles are shining directly into the camera lens
- When driving on roads that are branching or merging

- When driving on a road surface that is wet due to rain, previous rainfall, standing water, etc.
- When the vehicle experiences strong up-and-down motion such as when driving on an extremely rough road or on a seam in the pavement
- When headlight brightness at nighttime is reduced due to dirt on the lenses, or when the headlights are misaligned
- When driving with a strong crosswind
- When driving on winding roads or roads that are uneven
- When driving on rough or unpaved roads

■ When changing the tires

Depending on the tires used, such as snow tires, etc., sufficient performance may not be maintainable.

■ Warning messages for LKA

Warning messages are used to indicate a system malfunction or to inform the driver of the need for caution while driving. $(\rightarrow P. 614)$

A CAUTION

■ Before using the LKA system

Do not rely solely on the LKA system. The LKA system does not drive the vehicle automatically, nor does it reduce the amount of care you need to take. As such, the driver must always assume full responsibility for understanding his/her surroundings, for operating the steering wheel to correct the driving line, and for driving safely.

Inappropriate or negligent driving could lead to an accident.

■To avoid operating the LKA by mistake

Switch the LKA off using the LKA switch when not in use.

■ Situations unsuitable for LKA

Do not use LKA in any of the following situations.

Otherwise, the system may not function correctly and could result in an accident.

- When driving with tire chains or similar equipment
- When the tires have been excessively worn, or when the tire inflation pressure is low
- When there are objects or structures along the roadside that might be misinterpreted as lane markers (such as guardrails, curb, reflector posts, etc.)
- When driving on snowy roads
- When pavement lane markers are difficult to see due to rain, snow, fog, sand, dirt, etc.
- When there are visible lines on the pavement from road repairs, or if the remains
 of old lane markers are still visible on the road
- When driving on slippery roads, such as those covered with rain, ice or snow
- When driving in a lane other than the driving or passing lanes on a freeway or highway

↑ NOTICE

■ To prevent damage to or incorrect operation of the LKA system

- Do not modify the headlights or attach stickers to the surface of the lights.
- Do not modify the suspension.
 If any suspension parts need to be replaced, contact your Lexus dealer.
- Do not install or place anything on the hood or the grille. Also, do not install a grille guard (bull bars, kangaroo bar etc.).
- Do not modify the sun visor.If the sun visor needs to be replaced, contact your Lexus dealer.
- If the windshield needs to be replaced, contact your Lexus dealer.

↑ NOTICE

\blacksquare Camera sensor (\rightarrow P. 344)

Observe the following to ensure that the LKA system functions correctly.

- Keep the windshield clean at all times.
 Performance could be affected if the windshield is dirty, or if raindrops, condensation or ice are adhering to the windshield.
- Do not attach a sticker or other items to the windshield near the camera sensor.
- Do not install or place anything near the camera.



- Do not attach window tinting to the windshield.
- Do not install an antenna in front of the camera lens.
- If the windshield is fogged up, use the windshield defogger to remove fog from the windshield.


When it is cold, using the heater with air blowing to the feet may allow the upper part of the windshield to fog up. This will have a negative effect on the images.

- Do not place anything on the dashboard. تلفن شبانه روزی: The camera sensor may recognize the image reflected on the windshield as lane markers by mistake.
- Do not scratch the camera lens, or let it get dirty.
 When cleaning the inside of the windshield, be careful not to get any glass cleaner etc. on the lens. Also, do not touch the lens.
 For lens repair, contact your Lexus dealer.
- Do not change the installation position or direction of the camera sensor or remove it. The direction of the camera sensor is precisely adjusted.
- Do not subject the camera sensor to strong impact or force, and do not disassemble the camera sensor.

Driving mode select switch

The driving modes can be selected to suit driving condition.

▶ Vehicles without electronically modulated air suspension



1 Normal mode

تلفن شیانه روزی: ۲۰۸۵ + For normal driving

Press the switch to change the driving mode to normal mode when not in normal mode.

② Eco drive mode armaSOS.com

Use Eco drive mode to help achieve low fuel consumption during trips that involve frequent accelerating.

When not in Eco drive mode and the driving mode select switch is turned to the left, the "ECO MODE" indicator comes on and Eco Driving Indicator Zone Display and average fuel consumption is shown on the multi-information display. $(\rightarrow P. 132)$


Sport mode

Assists acceleration response by controlling the transmission and steering. Suitable for when precise handling is desirable, for example when driving on mountain roads.

When not in Sport mode and the driving mode select switch is turned to the right, the "SPORT" indicator comes on in the multi-information display.







1 Normal mode

For normal driving.

Press the switch to change the driving mode to normal mode when not in normal mode.

(2) Comfort mode

By controlling the suspension, riding comfort is further enhanced. Suitable for city driving.

When not in comfort mode and the driving mode select switch is turned to the left, the "COMFORT" indicator comes on in the multi-information display.

(3) Eco drive mode

Use Eco drive mode to help achieve low fuel consumption during trips that involve frequent accelerating.

When in comfort mode and the driving mode select switch is turned to the left, the "ECO MODE" indicator comes on and Eco Driving Indicator Zone Display and average fuel consumption is shown on the multi-information display. $(\rightarrow P. 132)$

Driving

(4) Sport mode

SPORTS mode

Assists acceleration response by controlling the transmission and the engine. Suitable for when powerful acceleration is desirable.

When not in SPORT S mode and the driving mode select switch is turned to the right, the "SPORT S" indicator comes on in the multi-information display.

SPORT S+ mode

Helps to ensure steering performance and driving stability by simultaneously controlling the steering and suspension in addition to the transmission. Suitable for sporty driving.

When in SPORT S mode and the driving mode select switch is turned to the right, the "SPORT S+" indicator comes on in the multi-information display.

Operation of the air conditioning system in Eco drive mode

Eco drive mode controls the heating/cooling operations and fan speed of the air conditioning system to enhance fuel efficiency $(\rightarrow P.418)$. To improve air conditioning performance, adjust the fan speed or turn off Eco drive mode.

تلفن شبانه روزی: ۵۰ Sport mode automatic deactivation Sport mode is automatically deactivated if the engine switch is turned off after driving in sport mode.

■ Driving mode pop-up display 2505 COM

When the driving mode is changed, the selected driving mode will be temporarily displayed on the side display. $(\rightarrow P. 415)$

Electronically modulated air suspension*


By independently controlling the damping force of the shock absorbers for each of the 4 wheels according to the road and driving conditions and the selected driving mode, this system achieves ride comfort with superior steering stability, and ensures good vehicle posture.

In addition, vehicle height can be selected according to road and driving conditions.

The vehicle height is maintained at the selected level regardless of the number of occupants and luggage weight.

Turns high mode on/off.

When on, the "HEIGHT HIGH" indicator will come on.



Operating sound of the air suspension compressor

When the vehicle height is lowered, such as when entering or loading the vehicle, or high mode is selected, the compressor may operate and a whirring sound may be heard. This does not indicate a malfunction.

- Be sure to stop the engine in the following situations in order to stop operation of the electronically modulated air suspension:
 - The vehicle is parked on a curb.
 - Any of the wheels is stuck in a ditch.
 - It is necessary to jack up the vehicle.
 - It is necessary to tow the vehicle with part of it lifted.

If the engine switch remains in IGNITION ON mode, the vehicle height may change, and you may catch part of your body in the vehicle, resulting in accidental damage.



تلفن شبانه روزی: ۱۵۸۰۲۹۸۸ - ۲۱

Driving assist systems

To help enhance driving safety and performance, the following systems operate automatically in response to various driving situations. Be aware, however, that these systems are supplementary and should not be relied upon too heavily when operating the vehicle.

ABS (Anti-lock Brake System)

Helps to prevent wheel lock when the brakes are applied suddenly, or if the brakes are applied while driving on a slippery road surface

Brake assist

Generates an increased level of braking force after the brake pedal is depressed when the system detects a panic stop situation

VSC (Vehicle Stability Control)

Helps the driver to control skidding when swerving suddenly or turning on slippery road surfaces ۱۹۰۸ ماله دوزې شانه دوزې د د

◆ TRC (Traction Control)

Helps to maintain drive power and prevent the drive wheels from spinning when starting the vehicle or accelerating on slippery roads

Hill-start assist control

Helps to prevent the vehicle from rolling backward when starting on an incline or slippery slope

VGRS (Variable Gear Ratio Steering) (if equipped)

Adjusts the wheel turning angle in accordance with the vehicle speed and steering wheel movement

EPS (Electric Power Steering)

Employs an electric motor to reduce the amount of effort needed to turn the steering wheel

VDIM (Vehicle Dynamics Integrated Management)

Provides integrated control of the ABS, brake assist, TRC, VSC, hill-start assist control, EPS and VGRS (if equipped) systems

Helps to maintain vehicle stability when swerving on slippery road surfaces by controlling the brakes, engine output, steering assist, and if equipped with VGRS, steering ratio

PCS (Pre-Crash Safety system) (if equipped)

→P.368

لفن شبانه روزي: (Emergency brake signal (if equipped وزي: (Emergency brake)

When the brakes are applied suddenly, the stop lights automatically flash to alert the vehicle behind

BSM (Blind Spot Monitor) (if equipped)

 \rightarrow P.381

When the TRC/VSC/ABS/hill-start assist control systems are operating

The slip indicator light will flash while the TRC/VSC/ABS/hill-start assist control systems are operating.

The stop lights and high mounted stoplight turn on when the hill-start assist control system is operating.




Disabling the TRC/VSC systems

If the vehicle gets stuck in fresh snow or mud, the TRC and VSC systems may reduce power from the engine to the wheels. Pressing VSC OFF switch to turn the system off may make it easier for you to rock the vehicle in order to free it.

■ Turning off the TRC system only

To turn the TRC-system off, المان شيانه روزی auickly press and release the switch.

The "TRC OFF" will be shown on the multi-information display. Press the switch again to turn the system back on.




■ Turning off both TRC and VSC systems

To turn the TRC and VSC systems off, press and hold the switch for more than 3 seconds while the vehicle is stopped.

The VSC OFF indicator light will come on and the "TRC OFF" will be shown on the multi-information display.*

Press the switch again to turn the systems back on.



*: On vehicles with pre-crash safety system, pre-crash alert braking, pre-crash brake assist and pre-crash braking will also be disabled. The pre-crash safety system warning light will come on and the "Pre-crash brakes are disabled because VSC is OFF" will be shown on the multi-information display.

(—)P. 368)

FarmaSOS.com

■ When the message is displayed on the multi-information display showing that TRC has been disabled even if the VSC OFF switch has not been pressed

TRC and hill-start assist control cannot be operated. Contact your Lexus dealer.

■ Hill-start assist control is operational when

- The system has detected that the vehicle is moving backward.
- Vehicles without paddle shift switches: The shift lever is in the D or S position.
 Vehicles with paddle shift switches: The shift lever is in the D or M position.
- The brake pedal is not depressed.

■ VGRS is disabled when

VGRS may stop operating in the following situations.

In this event, the steering wheel may move from its straight forward position, but it will return when the system restarts.

- When the steering wheel is operated for an extended period of time while the vehicle is stopped or is moving very slowly
- When the steering wheel has been held fully to the left or right
- When the battery is low or the voltage temporarily drops

The center position of the steering wheel may change when VGRS is disabled. However, the position will return to normal after VGRS is reactivated.

Sounds and vibrations caused by the ABS, brake assist, TRC, VSC, hill-start assist control and VGRS systems

- A sound may be heard from the engine compartment when the brake pedal is depressed repeatedly, when the engine is started or just after the vehicle begins to move. This sound does not indicate that a malfunction has occurred in any of these systems.
- Any of the following conditions may occur when the above systems are operating. None of these indicates that a malfunction has occurred.
 - Vibrations may be felt through the vehicle body and steering.
 - A motor sound may be heard after the vehicle comes to a stop.
- The steering wheel may be moved slightly or a sound may be heard when the engine is started or stopped. None of these indicate that a malfunction has occurred.

■ EPS operation sound

When the steering wheel is operated, a motor sound (whirring sound) may be heard. This does not indicate a malfunction.

■ Reactivation of the TRC/VSC systems

Even after the TRC/VSC systems have been turned off, turning the engine off and then on again will automatically reactivate the TRC/VSC systems.

■ Reactivation of the TRC system linked to vehicle speed

When only the TRC system is turned off, the TRC system will turn on when vehicle speed increases. However, when both TRC and VSC systems are turned off, the systems will not turn on even when vehicle speed increases.

■ Reduced effectiveness of the EPS system

The effectiveness of the EPS system is reduced to prevent the system from overheating when there is frequent steering input over an extended period of time. The steering wheel may feel heavy as a result.* Should this occur, refrain from excessive steering input or stop the vehicle and turn the engine off. The EPS system should return to normal within 10 minutes.

*: If the LKA (Lane-Keeping Assist) system cannot operate in this case, a warning message will be shown on the multi-information display.

Operating conditions of emergency brake signal

When the following three conditions are met, the emergency brake signal will operate:

- The emergency flashers are off.
- Actual vehicle speed is over 55 km/h (35 mph).
- The brake pedal is depressed in a manner that cause the system to judge from the vehicle deceleration that this is a sudden braking operation.

Automatic system cancelation of emergency brake signal (if equipped)

The emergency brake signal will turn off in any of the following situations:

- The emergency flashers are turned on.
- The brake pedal is released.
- The system judges from the vehicle deceleration that is not a sudden braking operation.

- The ABS does not operate effectively when
 - The limits of tire gripping performance have been exceeded (such as excessively worn tires on a snow covered road).
 - The vehicle hydroplanes while driving at high speed on wet or slick roads.
- Stopping distance when the ABS is operating may exceed that of normal conditions

The ABS is not designed to shorten the vehicle's stopping distance. Always maintain a safe distance from the vehicle in front of you, especially in the following situations:

- When driving on dirt, gravel or snow-covered roads
- When driving with tire chains
- When driving over bumps in the road
- When driving over roads with potholes or uneven surfaces
- TRC may not operate effectively when

Directional control and power may not be achievable while driving on slippery road surfaces, even if the TRC system is operating.

Do not drive the vehicle in conditions where stability and power may be lost.

■ Hill- start assist control does not operate effectively when

Do not overly rely on the hill-start assist control. The hill-start assist control may not operate effectively on steep inclines and roads covered with ice.

■When the VSC is activated masos com

The slip indicator light flashes. Always drive carefully. Reckless driving may cause an accident. Exercise particular care when the indicator light flashes.

■ When the TRC/VSC systems are turned off

Be especially careful and drive at a speed appropriate to the road conditions. As these are the systems to help ensure vehicle stability and driving force, do not turn the TRC/VSC systems off unless necessary.

■ Replacing tires

Make sure that all tires are of the specified size, brand, tread pattern and total load capacity. In addition, make sure that the tires are inflated to the recommended tire inflation pressure level.

The ABS, TRC and VSC systems will not function correctly if different tires are installed on the vehicle.

Contact your Lexus dealer for further information when replacing tires or wheels.

■ Handling of tires and the suspension

Using tires with any kind of problem or modifying the suspension will affect the driving assist systems, and may cause a system to malfunction.



تلفن شبانه روزی: ۱۵۸۰۲۹۸۸ - ۲۱

FarmaSOS.com


PCS (Pre-Crash Safety system)*

When the sensor detects that a frontal collision is highly likely or even unavoidable, safety systems such as the brakes and seat belts are automatically engaged to help avoid a collision or to lessen impact as well as vehicle damage.

Pre-crash warning

When a high possibility of a frontal collision is detected, the precrash safety system warning light flashes, a buzzer sounds and a message is shown on the multi-information display to urge the driver to take evasive action.

Pre-crash warning can be disabled using the pre-crash braking off switch.



Pre-crash seat belts (front seat only)

If the pre-crash sensor detects that a collision is unavoidable, the pre-crash safety system will retract the seat belt before the collision occurs. The same will happen if the driver makes an emergency braking or loses control of the vehicle. $(\rightarrow P.48)$

Pre-crash brake assist

When there is a high possibility of a frontal collision, the system applies greater braking force in relation to how strongly the brake pedal is depressed.

Pre-crash braking (if equipped)

When there is a high possibility of a frontal collision, the system warns the driver using a warning light, warning display and buzzer. If the system determines that a collision is unavoidable, the brakes are automatically applied to help avoid a collision or to reduce the collision speed.

When the vehicle is being stopped by pre-crash braking, the brake will be engaged for a maximum of 2 seconds and then released automatically. This pre-crash braking can be canceled by depressing the accelerator pedal or brake pedal.

Pre-crash braking can be disabled using the pre-crash braking off switch.

Suspension control

When there is a high possibility of a frontal collision, the operation of suspension control helps prevent the front of the vehicle from dropping when the brakes are applied suddenly.

Steering gear control (VGRS) (vehicles with camera sensors)

When the system determines that a collision is unavoidable, the steering gear ratio is changed to help improve the response to steering input.

Driver monitor system (if equipped) S. COM

When the system determines that there is a possibility of a collision, and either the driver is not facing forward or the driver's eyes are closed, pre-crash warnings are given in advance to warn the driver. If the system determines that the conditions to operate pre-crash alert braking have been met even when the possibility of a collision increases further, pre-crash alert braking will operate.


Pre-crash alert braking can be disabled using the pre-crash braking off switch.

Disabling pre-crash braking

Pre-crash warning, pre-crash braking (if equipped) and pre-crash alert braking (vehicles with driver monitor system) can be switched between enabled and disabled by pressing the pre-crash braking off switch.


- 1 Enabled
- (2) Disabled

The pre-crash safety system warning light comes on when the system is disabled.



Radar sensor

The radar sensor detects vehicles or other obstacles on or near the road ahead and determines whether a collision is imminent based on the position, speed, and heading of the obstacles.





Camera sensors (if equipped)

The camera sensors detect pedestrians and other three-dimensional objects on or near the road ahead together with the radar sensor while the vehicle is moving.

When the headlights are on, near-infrared rays are projected to ensure proper detection performance in the night time.

► Vehicles with discharge head- ► Vehicles with LED headlights lights






- (1) Camera sensors

Driver monitor sensor (vehicles with driver monitor system)

The driver monitor sensor detects the direction the driver is facing and whether the driver's eyes are open or closed.

The system determines whether the driver is facing forward and whether or not the driver's eyes are closed.



■ The pre-crash safety system is operational when

- Pre-crash warning:
 - ► Vehicles without camera sensors
 - The pre-crash braking off switch is not pressed.
 - Vehicle speed is greater than about 15 km/h (10 mph).
 - The speed at which your vehicle is approaching the obstacle or the vehicle running ahead of you is greater than about 15 km/h (10 mph).
 - ► Vehicles with camera sensors
 - The pre-crash braking off switch is not pressed.
 - Vehicle speed is greater than about 5 km/h (4 mph).
 - The speed at which your vehicle is approaching the obstacle or the vehicle running ahead of you is greater than about 5 km/h (4 mph).
- Pre-crash seat belts (operating conditions A):
 - Vehicle speed is greater than about 30 km/h (19 mph).
 - · The system detects sudden braking or skidding.
 - The front occupants are wearing a seat belt.
- Pre-crash seat belts (operating conditions B):
 - Vehicle speed is greater than about 5 km/h (4 mph).
 - The speed at which your vehicle is approaching the obstacle or the vehicle running ahead of you is greater than about 30 km/h (19 mph).
 - · The front occupants are wearing a seat belt. نلفن شبانهٔ روزی
- Pre-crash brake assist:
 - The VSC OFF switch is not pressed.
 - Vehicle speed is greater than about 30 km/h (19 mph).
 - The speed at which your vehicle is approaching the obstacle or the vehicle running ahead of you is greater than about 30 km/h (19 mph).
 - The brake pedal is depressed.

- Pre-crash braking (if equipped):
 - ▶ Vehicles without camera sensors
 - The pre-crash braking off switch is not pressed.
 - The VSC OFF switch is not pressed.
 - Vehicle speed is greater than about 15 km/h (10 mph).
 - The speed at which your vehicle is approaching the obstacle or the vehicle running ahead of you is greater than about 15 km/h (10 mph).
 - ▶ Vehicles with camera sensors
 - The pre-crash braking off switch is not pressed.
 - The VSC OFF switch is not pressed.
 - Vehicle speed is greater than about 5 km/h (4 mph).
 - The speed at which your vehicle is approaching the obstacle or the vehicle running ahead of you is greater than about 5 km/h (4 mph).
- Suspension control:
 - Vehicle speed is greater than about 5 km/h (4 mph).
 - The speed at which your vehicle is approaching the obstacle or the vehicle running ahead of you is greater than about 30 km/h (19 mph).
- Steering gear control (VGRS) (vehicles with camera sensors):
 - Vehicle speed is greater than about 30 km/h (19 mph).
 - The speed at which your vehicle is approaching the obstacle or the vehicle running ahead of you is greater than about 30 km/h (19 mph).
- Pre-crash alert braking (vehicles with driver monitor system):
 - The pre-crash braking off switch is not pressed.
 - The VSC OFF switch is not pressed.
 - The system determines that the driver is not facing forward, or that the driver's eyes are closed.
 - Vehicle speed is greater than about 40 km/h (25 mph).
 - The speed at which your vehicle is approaching the vehicle running ahead of you is greater than about 40 km/h (25 mph).
 - The steering is not being turned.

Conditions that may trigger the system even if there is no danger of a collision

In any of the following situations where the frontal area of the radar sensor is interrupted, the radar sensor may detect possibility of a frontal collision and the system may be activated.

- When passing by an oncoming vehicle in a curve or a turn to the right or the left.
- When rapidly approaching an obstacle ahead (e.g. preceding vehicle, toll gate barrier, etc.)
- When there is a structural object (billboard, low ceiling, fluorescent light, etc.)
 above the uphill road ahead
- When driving on a narrow road or through under a low overhead structure (bridge, tunnel, fly-under, etc.)
- When driving on an uneven road surface
- When there is a metal object, bump, or protrusion on the road surface
- When vehicle front part is raised or lowered depending on loading conditions
- When the direction of radar sensor is misaligned by strong impact applied on an area around the radar sensor, etc.
- When there is an obstacle (guard rail, etc.) by the roadside at the entrance to a curve
- When driving through an area filled with steam or smoke

When the system is activated in the situations described above, there is also a possibility that the seat belts will retract quickly and the brakes may be applied with a force greater than normal. When the seat belt is locked in the retracted position, stop the vehicle in a safe place, release the seat belt and refasten it.

Obstacles not detected

The radar sensor cannot detect plastic obstacles such as traffic cones. There may also be occasions when the sensor cannot detect pedestrians, animals, bicycles, motorcycles, trees, or snowdrifts.

■ A camera sensor cannot detect obstacles in the following situations:

- A camera sensor is directly receiving intense light, such as sunlight.
- Visibility is poor because of bad weather or other reasons.
- The sensor temperature is extremely high.
- The headlights are not turned on in darkness such as at night or in a tunnel.

Driving

■ Situations in which the pre-crash safety system does not function properly

The system may not function effectively in situations such as the following:

- On roads with sharp bends or uneven surfaces
- If a vehicle suddenly moves in front of your vehicle, such as at an intersection
- If a vehicle suddenly cuts in front of your vehicle, such as when overtaking
- In inclement weather such as heavy rain, fog, snow or sand storms
- If the vehicle is skidding when VSC is not operating
- When an extreme change in vehicle height occurs
- When only part of your vehicle's front end collides with, or contacts, a vehicle or object in a frontal collision
- When the radar sensor moves off position due to its surrounding area being subjected to a strong impact
- If an obstacle in front of the vehicle is small
- When the system judges that the driver performed a collision avoidance operation via the accelerator pedal, brake pedal, or steering wheel

■ Automatic cancelation of the pre-crash safety system

When a malfunction occurs due to sensor contamination, etc. that results in the sensors being unable to detect obstacles, the pre-crash safety system will be automatically disabled. In this case, the system will not activate even if there is a collision possibility.

■ When there is a malfunction in the system

The pre-crash safety system warning light will flash and warning messages will be displayed. $(\rightarrow P. 607, 614)$

■ Certification for the pre-crash safety system

► For vehicles sold in Jordan

TRC approval's number: TRC/LPD/2008/85

► For vehicles sold in the United Arab Emirates

NOTICE

This equipment has been registered with the Telecommunications Regulatory Authority for use in the UAE.

TRA

REGISTERED No: 0022262/10 DEALER No: 0019826/09 DENSO: DNMWR004

► For vehicles sold in Taiwan

經型式認證合格之低功率射頻電機,非經許可,公司、商號或使用者均不得 擅自變更頻率、加大功率或變更原設計之特性及功能。

低功率射頻電機之使用不得影響飛航安全及干擾合法通信;經發現有干擾現象時,應立即停用,並改善至無干擾時方得繼續使用。 前項合法通信,指依電信法規定作業之無線電通信。 低功率射頻電機須忍受合法通信或工業、科學及醫療用電波輻射性電機設備 之干擾。

For vehicles sold in Thailand ♦ ٢٠٨٨ : روزي: منانه روزي:



A57002: Registration No.

08 : Year of issuance 0016 : Supplier Code

To avoid hazard that may happen from electromagnetic wave, please keep the distance more than 45 cm from pre-crash sensor when it is being operated.

This telecommunication equipment conforms to technical standard NTC TS 1011-2549.

► For vehicles sold in Ukraine

MODEL DNMWR004



A CAUTION

■ Limitations of the pre-crash safety system

The driver is solely responsible for safe driving. Always drive safely, taking care to observe your surroundings.

Do not use the pre-crash safety system instead of normal braking operations under any circumstances. This system will not prevent collisions or lessen damage or injuries in all cases. Do not overly rely on this system. Failure to do so may cause an accident, resulting in death or serious injury.

This system has been designed to help avoid and reduce the impact of collisions. However, the system operates differently depending on the situation (\rightarrow P. 372, 374). As a result, the same level of performance may not be expected in all cases. Also, the pre-crash safety brakes may not operate if the driver is depressing the brake pedal or turning the steering wheel, as the system will determine such conditions as collision avoidance operations.

■ Handling the radar sensor

Observe the following to ensure the pre-crash safety system can function effectively. Otherwise, the system may not function correctly and could result in an accident.

- Keep the sensor and grille cover clean at all times.
 Clean the sensor and grille cover with a soft cloth so you do not mark or damage them.
- Do not subject the sensor or surrounding area to a strong impact.
 If the sensor moves even slightly off position, the system may malfunction. If the sensor or surrounding area is subject to a strong impact, always have the area inspected and adjusted by your Lexus dealer.
- Do not disassemble the sensor.
- Do not attach accessories or stickers to the sensor, grille cover or surrounding area.
- Do not modify or paint the sensor and grille cover.
- If the radar sensor needs to be replaced, contact your Lexus dealer.

■ Handling the camera sensors (if equipped)

Observe the following to ensure that the PCS functions effectively:

- Keep the windshield clean at all times.
 PCS effectiveness may be reduced due to the presence of raindrops, condensation, ice or snow on the windshield.
- Do not subject the camera sensor to a strong impact or force, and do not disassemble the camera sensor.
- Do not change the installation position of the camera sensor, or remove and reinstall it. The direction of the camera sensor is precisely adjusted.
- When the windshield fogs up, use the windshield defogger to dry the windshield.
 During cold weather, using the heater with air blowing to the feet may allow the upper part of the windshield to fog up, having a negative effect on the images.
- Do not place anything on the dashboard.
 Images reflected on the windshield may reduce the effectiveness of the camera sensor.
- Do not scratch the camera lens, or let it get dirty.
- Do not attach a sticker or other items to the windshield near the camera sensor.
- Headlights (vehicles with camera sensors)
 - Observe the following to ensure proper near-infrared ray projection:
 - Keep the headlights clean at all times.
 - The detection performance may deteriorate if the high beams are misaligned or inoperative.
 - The near-infrared ray transmitters project strong energy that is not visible.
 Although the transmitters normally turn off when the vehicle is stopped, never look into the headlights for your safety.

Determining the direction the driver is facing and whether the driver's eyes are open or closed (vehicles with driver monitor system)

The direction the driver is facing and whether the driver's eyes are open or closed may not be determined correctly if the following conditions exist:

- There is an object between the driver monitor sensor and the driver's face, such as when the sensor is blocked.
- A part of the driver's face is covered.
- The sensor or the driver's face is exposed to intense light such as sunlight.
- The driving posture is improper.
- The vehicle is parked.
- Handling the driver monitor sensor (vehicles with driver monitor system)

Observe the following to ensure the driver monitor sensor can function effectively.

Failure to do so may result in a malfunction or may prevent the system from correctly determining the direction the driver is facing and whether the driver's eyes are open or closed, resulting in an unexpected accident.

- Do not disassemble, damage, lift or pull on the sensor.
- Do not touch the sensor while driving.
- Do not wet or spill water on the sensor. تلفن شبانه روزی:
- Do not drop anything on or allow anything to hit against the sensor. Do not subject the sensor to an impact.
- Make sure that there are no scratches, dirt or stickers on the side of the sensor that faces the driver.
- Do not place any objects in front of the side of the sensor that faces the driver or cover the sensor.

■ Cautions regarding the assist contents of the system

By means of alarms and brake control, the pre-crash safety system is intended to assist the driver in avoiding collisions through the process of LOOK-JUDGE-ACT. There are limits to the degree of assistance the system can provide, so please keep in mind the following important points.

- Assisting the driver in watching the road The pre-crash safety system is only able to detect obstacles directly in front of the vehicle, and only within a limited range. It is not a mechanism that allows careless or inattentive driving, and it is not a system that can assist the driver in low-visibility conditions. It is still necessary for the driver to pay close attention to the vehicle's surroundings.
- Assisting the driver in making correct judgment When attempting to estimate the likelihood of a collision, the only data available to the pre-crash safety system is that from obstacles it has detected directly in front of the vehicle. Therefore, it is absolutely necessary for the driver to remain vigilant and to determine whether or not there is a possibility of collision in any given situation.
- Assisting the driver in taking action
 The pre-crash safety system's braking assist feature is designed to help reduce
 the severity of a collision, and so only acts when the system has judged that a collision is unavoidable. This system is not capable of automatically avoiding a collision or bringing the vehicle to a stop safely without appropriate operations
 performed by the driver. For this reason, when encountering a dangerous situation the driver must take direct and immediate action in order to ensure the safety
 of all involved.

♠ NOTICE

- Precautions for cleaning the driver monitor sensor (vehicles with driver monitor system)
 - Gently wipe the sensor with a soft cloth to prevent damage.
 - Wipe any excess dirt with a cloth dampened with neutral detergent, all liquids having been wringed out of the cloth. After that, wipe again with a dry cloth.
 - Do not use benzene, thinner, glass cleaners, wax, etc.

BSM (Blind Spot Monitor)*

Summary of the Blind Spot Monitor


The Blind Spot Monitor is a system that has 2 functions;

- The Blind Spot Monitor function
 Assists the driver in making the decision when changing lanes
- The RCTA (Rear Cross Traffic Alert*1/Rear Crossing Traffic Alert*2) function (if equipped)

Assists the driver when backing up

- *1: Except for Russia, Ukraine and Kazakhstan
- *2: For Russia, Ukraine and Kazakhstan

These functions use same sensors.



1 BSM main switch

Pressing the switch turns the system on or off. When the switch is set to on, the switch's indicator illuminates and the buzzer sounds. Common switch for Blind Spot Monitor function and RCTA function.

(2) Outside rear view mirror indicators

Blind Spot Monitor function:

When a vehicle is detected in the blind spot, the outside rear view mirror indicator comes on while the turn signal lever is not operated. If the turn signal lever is operated toward the detected side, the outside rear view mirror indicator flashes.

RCTA function:

When a vehicle approaching from the right or left rear of the vehicle is detected, the outside rear view mirror indicators flash.

(3) RCTA buzzer (RCTA function only)

When a vehicle approaching from the right or left rear of the vehicle is detected, a buzzer sounds from behind the rear seat.

■ The outside rear view mirror indicators visibility

When under strong sunlight, the outside rear view mirror indicator may be difficult to see.

■ RCTA buzzer hearing

RCTA function may be difficult to hear over loud noises such as high audio volume.

■ When there is a malfunction in the Blind Spot Monitor

If a system malfunction is detected due to any of the following reasons, warning messages will be displayed: $(\rightarrow P. 614)$

- There is a malfunction with the sensors
- The sensors have become dirty
- The outside temperature is extremely high or low
- The sensor voltage has become abnormal

4

■ Certification for the Blind Spot Monitor

► For vehicles sold in Ukraine

type approval number: 10094.000966-13



155

► For vehicles sold in South Africa radio equipment type approval number : TA-2011/1350



تلفن شبانه روزی: ۱۵۸۰۲۹۸۸ - ۲۱

FarmaSOS.com

► For vehicles sold in Jordan

TRC's type approval certificate number: TRC/LPD/2012/1

► For vehicles sold in Lebanon

From the Lebanese Telecommunications Ministry:

Type Approval Number: 8341/O&M/2011

► For vehicles sold in Bahrain

The Equipment Identified hereon is approved for use under the following rules

- 1- This equipment must not cause harmful interference to other service.
- 2- This equipment is subject to harmful interference, and the owner of this equipment must not claim for protection.
- ▶ For vehicles sold in the United Arab Emirates

TRA

REGISTERED No:

ER35312/14

DEALER No:

DA0041485/10

► For vehicles sold in Qatar

ictQATAR

Type approval reg No: ICTQATAR/RT/2013/R-2555

Importer No:

FT-2222

► For vehicles sold in Korea



상호 또는 성명 기기 명칭 기본모델명 제조자/제조국가 CONTINENTAL AUTOMOTIVE GMBH 물체감지센서용 꾸선기기(24GHz 주파수대를 사용하는 기기) SRR2-A CONTINENTAL AUTOMOTIVE GMBH / 독일

KCC-CRM-TAL-SRR2A

► For vehicles sold in Indonesia

27069/SDPPI/2012 2130

► For vehicles sold in Singapore


Complies with IDA Standards DA102263

► For vehicles sold in the Philippines



Type Approved

No.: ESD:1206783C \ - \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ الكرام المالية والمالية والمالية والمالية والمالية المالية المالية والمالية المالية ► For vehicles sold in Vietnam



aSOS.com

► For vehicles sold in Republic of El Salvador

FCCID: OAYSRR2A

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Warning

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

A CAUTION

■ Handling the radar sensor

One Blind Spot Monitor sensor is installed inside the left and right side of the vehicle rear bumper respectively. Observe the following to ensure the Blind Spot Monitor can function correctly.

 Keep the sensor and its surrounding area on the bumper clean at all times.



FarmaSC

- Do not subject the sensor or surrounding area on the bumper to a strong impact. If the sensor moves even slightly off position, the system may malfunction and vehicles that enter the detection area may not be detected. If the sensor or surrounding area is subject to a strong impact, always have the area inspected by your Lexus dealer.
- Do not disassemble the sensor.
- Do not attach accessories or stickers to the sensor or surrounding area on the bumper.
- Do not modify the sensor or surrounding area on the bumper.
- Do not paint the rear bumper any color other than an official Lexus color.

The Blind Spot Monitor function


The Blind Spot Monitor function uses radar sensors to detect vehicles that are traveling in an adjacent lane in the area that is not reflected in the outside rear view mirror (the blind spot), and advises the driver of the vehicles existence via the outside rear view mirror indicator.

The Blind Spot Monitor function detection areas

The areas that vehicles can be detected in are outlined below.

The range of the detection area extends to:

- 1 Approximately 3.5 m (11.5 ft.) from the side of the vehicle The first 0.5 m (1.6 ft.) from the side of the vehicle is not in the detection area
- 2 Approximately 3 m (9.8 ft.) from the rear bumper
- 3 Approximately 1 m (3.3 ft.) forward of the rear bumper



■ Cautions regarding the use of the system

The driver is solely responsible for safe driving. Always drive safely, taking care to observe your surroundings.

The Blind Spot Monitor function is a supplementary function which alerts the driver that a vehicle is present in the blind spot. Do not overly rely on the Blind Spot Monitor function. The function cannot judge if it is safe to change lanes, therefore over reliance could cause an accident resulting in death or serious injury.

According to conditions, the system may not function correctly. Therefore the driver's own visual confirmation of safety is necessary.

■ The Blind Spot Monitor function is operational when


- The BSM main switch is set to on.
- Vehicle speed is greater than approximately 16 km/h (10 mph).
- The Blind Spot Monitor function will detect a vehicle when
 - A vehicle in an adjacent lane overtakes your vehicle.
 - Another vehicle enters the detection area when it changes lanes.
- Conditions under which the Blind Spot Monitor function will not detect a vehicle

 The Blind Spot Monitor function is not designed to detect the following types of vehicle
 - The Blind Spot Monitor function is not designed to detect the following types of vehicles and/or objects:
 - Small motorcycles, bicycles, pedestrians etc.*
 - Vehicles traveling in the opposite direction
 - Guardrails, walls, signs, parked vehicles and similar stationary objects*
 - Following vehicles that are in the same lane*
 - Vehicles driving 2 lanes across from your vehicle*
 - *: Depending on conditions, detection of a vehicle and/or object may occur.

- Conditions under which the Blind Spot Monitor function may not function correctly
 - The Blind Spot Monitor function may not detect vehicles correctly in the following conditions:
 - · During bad weather such as heavy rain, fog, snow etc.
 - When ice or mud etc. is attached to the rear bumper
 - When driving on a road surface that is wet due to rain, standing water etc.
 - When there is a significant difference in speed between your vehicle and the vehicle that enters the detection area
 - When a vehicle is in the detection area from a stop and remains in the detection area as your vehicle accelerates
 - When driving up or down consecutive steep inclines, such as hills, a dip in the road etc.
 - · When multiple vehicles approach with only a small gap between each vehicle
 - When vehicle lanes are wide, and the vehicle in the next lane is too far away from your vehicle
 - When the vehicle that enters the detection area is traveling at about the same speed as your vehicle
 - When there is a significant difference in height between your vehicle and the vehicle that enters the detection area
 - Directly after the BSM main switch is set to on
 - Instances of the Blind Spot Monitor function unnecessarily detecting a vehicle and/ or object may increase under the following conditions:
 - When there is only a short distance between your vehicle and a guardrail, wall etc.
 - When there is only a short distance between your vehicle and a following vehicle
 - When vehicle lanes are narrow and a vehicle driving 2 lanes across from your vehicle enters the detection area
 - · When items such as a bicycle carrier are installed on the rear of the vehicle

The RCTA function (if equipped)

RCTA functions when your vehicle is in reverse. It can detect other vehicles approaching from the right or left rear of the vehicle. It uses radar sensors to alert the driver of the other vehicle's existence through flashing the outside rear view mirror indicators and sounding a buzzer.



1 Approaching vehicles

Detection areas

A CAUTION

■ Cautions regarding the use of the system


The driver is solely responsible for safe driving. Always drive safely, taking care to observe your surroundings.

The RCTA function is only an assist and is not a replacement for careful driving. Driver must be careful when backing up, even when using RCTA function. The driver's own visual confirmation of behind you and your vehicle is necessary and be sure there are no pedestrians, other vehicles etc. before backing up. Failure to do so could cause death or serious injury.

According to conditions, the system may not function correctly. Therefore the driver's own visual confirmation of safety is necessary.

The RCTA function detection areas

The areas that vehicles can be detected in are outlined below.



To give the driver a more consistent time to react, the buzzer can alert for faster vehicles from farther away.

Example:

Approaching vehicle	Speed	Approximate alert distance
Fast	28 km/h (18 mph)	20 m (65 ft.)
Slow	8 km/h (5 mph)	5.5 m (18 ft.)

■ The RCTA function is operational when

- The BSM main switch is set to on.
- The shift lever is in R.
- Vehicle speed is less than approximately 8 km/h (5 mph).
- \bullet Approaching vehicle speed is between approximately 8 km/h (5 mph) and 28 km/h (18 mph).

Conditions under which the RCTA function will not detect a vehicle


The RCTA function is not designed to detect the following types of vehicles and/or objects.

- Small motorcycles, bicycles, pedestrians etc.*
- Vehicles approaching from directly behind
- Guardrails, walls, signs, parked vehicles and similar stationary objects*
- Vehicles moving away from your vehicle
- Vehicles approaching from the parking spaces next to your vehicle*
- Vehicles backing up in the parking space next to your vehicle
- *: Depending on conditions, detection of a vehicle and/or object may occur.

■ Conditions under which the RCTA function may not function correctly

The RCTA function may not detect vehicles correctly in the following conditions:

- During bad weather such as heavy rain, fog, snow etc.
- When ice or mud etc. is attached to the rear bumper
- When multiple vehicles approach continuously
- Shallow angle parking
- When a vehicle is approaching at high speed
- When parking on a steep incline such as hills, a dip in the road etc.
- Directly after the BSM main switch is set to on
- Directly after the engine is started with the BSM main switch on
- Vehicles that the sensors cannot detect because of obstacles



Lexus night view*

Lexus night view is a system which assists with nighttime driving.

Near-infrared rays are irradiated forward and an image converted from the irradiated light is shown on the Remote Touch screen. The image shows pedestrians, obstacles, and road conditions ahead of the vehicle, which are difficult to see at nighttime with the naked eye.

Displaying the Lexus night view

- 1 Turn the engine switch to IGNITION ON mode.
- **2** Turn the headlights on.
- Press the Lexus night view switch.

 The Lexus night view is displayed on the Remote Touch screen.

To return the screen to its previous state, press the switch again.

When the light sensor (\rightarrow P. 288) determines that it is currently night time from the brightness of the surrounding area, the Lexus night view can be operated by pressing the Lexus night view switch while the headlights are on.



The Lexus night view display

■ When displaying on the main display (\rightarrow P. 414)



- 1) Lexus night view screen
- (2) Brightness adjustment button

The brightness of the display can be adjusted by selecting this button using Remote Touch.

- "-": Darker
- "+": Brighter FarmaS



■ When displaying on the side display

When another screen is displayed on the main display while the Lexus night view is being shown on the main display, the Lexus night view screen will be displayed on the side display.

- (1) Lexus night view screen
- 2 Main display switching button Switches the Lexus night view from the side display to the main display.



■ Imaging range

The image is shown ranging from the tip of the low beam to the high beam.

■ If the vehicle speed is less than approximately 15 km/h (9 mph) when the Lexus night view is operating

An image will be displayed on the Lexus night view screen, but both the range and the distance of the projection will be limited as near-infrared rays are not being radiated outward.

■ When the Lexus night view switch is pressed while the Lexus night view cannot be operated

Advice information will be displayed on the Lexus night view screen. Follow the displayed advice.

■ If the Lexus night view switch is pressed at a time when the Lexus night view operation is not possible

Follow the advice displayed on the Remote Touch screen.

■ When the shift lever is shifted to R while the Lexus night view is operating

The Lexus night view screen switches as follows.

Main display: Switches to the Lexus parking assist monitor screen.

Side display: The display blacks out and no image is displayed.

■ Before using the Lexus night view

Never depend on this system only.

Lexus night view is intended as a supplemental aid to help you see pedestrians and road conditions ahead of the vehicle. As there are limits to the system, do not rely solely on the system while in use, and drive safely while observing the following precautions.

■ When using the Lexus night view

Observe the following precautions.

Failure to do so may cause an accident resulting in death or serious injury.

- Never drive while looking at the Lexus night view screen only.
- Do not look continuously at the Lexus night view screen while driving. Pedestrians, objects etc. ahead of the vehicle may be overlooked by the system. The system should always be used as a supplemental aid only.
- Lexus night view is designed to help you see objects better when driving in darkness on a road with few curves. Do not use the Lexus night view in well-lit areas or on roads with many curves or slopes. There may be areas that cannot be displayed by the system due to the road conditions (curve size, gradient, etc.)
- Lexus night view may be unable to project some features at an appropriate level of brightness. Some or all parts of certain features may be dark or difficult to see. Do not rely solely on the Lexus night view, and drive carefully while checking the surroundings for safety, as you would with a normal vehicle. Also, the following features and conditions may not be displayed clearly.

Features that are difficult to display:

- Clothing of a pedestrian made of a certain kind of material (ex. leather jackets)
- The characters on signs and billboards
- The information on road signs

Conditions in which display is difficult:

- Unfavorable weather conditions such as rain, fog, snowfall, snow storms etc.
- There are large puddles of water on the road surface following rainfall
- The area of the windshield in front of the camera is fogged up, dirty or icy
- The areas around the headlights are covered with ice, snow, mud etc.
- The battery voltage is remarkably low
- There are bright lights ahead of the vehicle

A CAUTION

■The near-infrared light

Follow these precautions to avoid damage to or incorrect operation of the Lexus night view system.

- System performance may deteriorate if the areas around the headlights are dirty. Clean the vehicle if it is dirty.
- Vehicles with discharge headlights: The near-infrared ray transmitter bulbs are also used as the high beam bulbs and may burn out. If a bulb burns out, the high beams will also not be able to used. Therefore, replace a bulb if it burns out.
- The near-infrared ray transmitters irradiate strong energy not visible to the eyes. Do not stare at the light at close range for a long time.

► Vehicles with discharge headlights



► Vehicles with LED headlights




تاف: شیانه روزی یا ۵۸۰۲۶۸۸ – ۲۱

♠ NOTICE

■ The near-infrared camera

Follow these precautions to avoid damage to or incorrect operation of the Lexus night view.



- Make sure the windshield is kept clean.
- System performance may deteriorate if rain water, condensation or ice adheres
 to the camera. If you notice the inner lens of the camera is dirty, the garnish will
 have to be replaced. Consult your Lexus dealer.
- Do not subject the camera to strong impacts, or disassemble the camera.
- As the alignment of the camera has been very finely adjusted, do not change or remove the mounting.
- If the windshield fogs up, defog the windshield using the front defroster.
- Do not dirty or scratch the camera lens.
- Night view may not function properly if an object is placed on the sensor, or anything that blocks the sensor is affixed to the windshield.

Winter driving tips

Carry out the necessary preparations and inspections before driving the vehicle in winter. Always drive the vehicle in a manner appropriate to the prevailing weather conditions.

Preparation for winter

- Use fluids that are appropriate to the prevailing outside temperatures.
 - Engine oil
 - · Engine coolant
 - Washer fluid
- Have a service technician inspect the condition of the battery.
- Have the vehicle fitted with four snow tires or purchase a set of tire chains for the rear tires.

Ensure that all tires are the specified size and brand, and that chains match the size of the tires.



Before driving the vehicle

Perform the following according to the driving conditions:

- Do not try to forcibly open a window or move a wiper that is frozen.
 Pour warm water over the frozen area to melt the ice. Wipe away the water immediately to prevent it from freezing.
- To ensure proper operation of the climate control system fan, remove any snow that has accumulated on the air inlet vents in front of the windshield.
- Check for and remove any excess ice or snow that may have accumulated on the exterior lights, vehicle's roof, chassis, around the tires or on the brakes.
- Remove any snow or mud from the bottom of your shoes before getting in the vehicle.

When driving the vehicle

Accelerate the vehicle slowly, keep a safe distance between you and the vehicle ahead, and drive at a reduced speed suitable to road conditions.

When parking the vehicle


- Park the vehicle and move the shift lever to P without setting the parking brake. The parking brake may freeze up, preventing it from being released. If the vehicle is parked without setting the parking brake, make sure to block the wheels.
 - Failure to do so may be dangerous because it may cause the vehicle to move unexpectedly, possibly leading to an accident.
- If the vehicle is parked without setting the parking brake, confirm that the shift lever cannot be moved out of P*.
 - *: The shift lever will be locked if it is attempted to be shifted from P to any other position without depressing the brake pedal. If the shift lever can be shifted from P, there may be a problem with the shift lock system. Have the vehicle inspected by your Lexus dealer immediately.

Selecting tire chains

Use the correct tire chain size when mounting the tire chains.

Chain size is regulated for each tire size.

- 1 Side chain (3 mm [0.12 in.] in diameter)
- (2) Cross chain (4 mm [0.16 in.] in diameter)



Regulations on the use of tire chains

Regulations regarding the use of tire chains vary depending on location and type of road. Always check local regulations before installing chains.

■ Tire chain installation

Observe the following precautions when installing and removing chains:

- Install and remove tire chains in a safe location.
- Install tire chains on the rear tires. Do not install tire chains on the front tires.
- Install tire chains on rear tires as tightly as possible. Retighten chains after driving 0.5 — 1.0 km (1/4 — 1/2 mile).
- Install tire chains following the instructions provided with the tire chains.

A CAUTION

■ Driving with snow tires

Observe the following precautions to reduce the risk of accidents.

Failure to do so may result in a loss of vehicle control and cause death or serious injury.

- Use tires of the specified size.
- Maintain the recommended level of air pressure.
- Do not drive at speeds in excess of the speed limit or the speed limit specified for the snow tires being used.
- Use snow tires on all, not just some wheels.

■ Driving with tire chains

Observe the following precautions to reduce the risk of accidents.

Failure to do so may result in the vehicle being unable to be driven safely, and may cause death or serious injury.

- Do not drive in excess of the speed limit specified for the tire chains being used, or 50 km/h (30 mph), whichever is lower.
- Avoid driving on bumpy road surfaces or over potholes.
- Avoid sudden acceleration, abrupt steering, sudden braking and shifting operations that cause sudden engine braking.
- Slow down sufficiently before entering a curve to ensure that vehicle control is maintained.
- Do not use LKA (Lane-Keeping Assist) system. (if equipped)

↑ NOTICE

■ Repairing or replacing snow tires

Request repairs or replacement of snow tires from Lexus dealers or legitimate tire retailers.

This is because the removal and attachment of snow tires affects the operation of the tire pressure warning valves and transmitters.

Fitting tire chains

The tire pressure warning valves and transmitters may not function correctly when tire chains are fitted.

Eco-friendly driving tips

For improved fuel economy and reduced CO_2 emissions, pay attention to the following points:

Using Eco drive mode

When using Eco drive mode, the torque corresponding to the accelerator pedal depression amount can be generated more smoothly than it is in normal conditions. In addition, the operation of the air conditioning system (heating/cooling) will be minimized, improving the fuel economy. (\rightarrow P. 354)

Use of Eco Driving Indicator

The Eco-friendly driving is possible by keeping the bar display of the Eco Driving Indicator shown in the multi-information display within the Zone of Eco driving. $(\rightarrow P.132)$

Accelerator pedal/brake pedal operation

Drive your vehicle smoothly. Avoid abrupt acceleration and deceleration. Gradual acceleration and deceleration will help reduce excessive fuel consumption.

When braking

Observe conditions in front of and around the vehicle, and estimate your stopping position. Release the accelerator pedal early and continue coasting. Use the brake pedal to adjust your stopping position. Make sure to operate the brake pedal gently.

Delays

Repeated acceleration and deceleration, as well as long waits at traffic lights, will lead to bad fuel economy. Check traffic reports before leaving and avoid delays as much as possible.

Highway driving

Control and maintain the vehicle at a constant speed. Before stopping at a toll booth or similar, allow plenty of time to release the accelerator pedal and gently apply the brakes.

Air conditioning

Use the air conditioning only when necessary. Doing so can help reduce excessive fuel consumption.

In summer: When the ambient temperature is high, use the recirculated air mode. Doing so will help to reduce the burden on the air conditioning system and reduce fuel consumption as well.

In winter: Turn the A/C switch on only when both heating and dehumidifying are needed, and if only heating is needed, turn the A/C switch off. Turning the A/C switch on when unnecessary leads to excessive fuel consumption.

Performing idling stops

- Avoid unnecessary idling. Stop the engine when parking the vehicle to reduce excessive fuel consumption, even it is only for a short period of time.
- Except in severe environment, such as when the outside temperature is extremely low, warming up the engine before driving is unnecessary. Rather than idling, it is more efficient to drive the vehicle gently to warm up each part while avoiding increasing the engine revolutions unnecessarily and accelerating or decelerating suddenly.

Luggage

Carrying heavy luggage will lead to poor fuel economy. Avoid carrying unnecessary luggage. Installing a large roof rack will also cause poor fuel economy.

◆ Regular maintenance masos.com

- Make sure to check the tire inflation pressure frequently. Improper tire inflation pressure can cause poor fuel economy. Also, as snow tires can cause large amounts of friction, their use on dry roads can lead to poor fuel economy. Use tires that are appropriate for the season and road conditions.
- Use oil and fluid of the recommended quality, which affect fuel consumption and the life of the vehicle. Also, check oil and fluid periodically.
 (→P. 520)

Interior features

5-1.	Remote Touch screen		5-6.	Other interior features	
	Remote Touch	.406		Sun visors and vanity	
	12.3-inch display	413		mirrors	467
5-2.	Lexus Climate Concierge			Clock	469
	Lexus Climate			Ashtrays	470
	Concierge	417		Cigarette lighters	471
5-3.	Using the air conditioning			Power outlets	473
	system and defogger			Heated steering wheel	476
	Front automatic air conditioning system	418		Climate control seats/seat heaters	478
	Rear air conditioning	A A	2	Armrest	483
		438	7	Retractable table	
	Rear window and outside			Rear sunshade	
	rear view mirror	4.45		Rear door sunshades	490
	defoggers		۱۸.	Trunk storage extension	
	Windshield wiper de-icer	.440	τω .,		
5-4.	Using the interior lights			Assist grips	
	Interior lights list		79	Garage door opener	
	Interior lights			ERA-GLONASS	
	Personal lights	.449		LIVI OLOTVI (33	
5-5.	Using the storage features				
	List of storage features	451			
	• Glove box	.453			
	• Coin holder	.454			
	Door pockets	.454			
	• Cup holders	.455			
	Console box	.457			
	Cool box/auxiliary box	.459			
	Auxiliary boxes	.462			
	Trunk features				


Remote Touch

The Remote Touch can be used to operate the Remote Touch screens.

For details, refer to "Navigation and Multimedia System Owner's Manual" or "Navigation System Owner's Manual".

The illustrations below are for left-hand drive vehicles.

► Except for Korea



1 "MAP" button FarmaSOS.com

Press this button to display the current position, cancel the screen scroll, start guidance, and repeat a voice guidance.

- (2) "∧•∨" button
 - ▶ Vehicles with a navigation system

Press this button to scroll the list screen and to change the scale of the map.

▶ Vehicles without a navigation system

Press this button to scroll the list screen.

3 Back button

Press this button to display the previous screen.

(4) "MENU" button

Press this button to display the "Menu" screen. $(\rightarrow P.410)$

(5) Remote Touch knob

Move in the desired direction to select a function, letter and screen button.

Press this button the knob to enter the selected function, letter or screen button.

6 "ENTER" button

Press this button to enter the selected function, letter or screen button.


(7) "HOME" button

Press this button to display the compass mode screen.



تلفن شبانه روزی: ۱۲۰۸۸۶۲۰۲۰ تلفن شبانه روزی: ۱۲۰۸۸۸۶۲۰۲۰

▶ For Korea



1 "MAP" button

Press this button to display the current position.

2 "∧•∨" button

Press this button to scroll the list screen.

(3) Back button

Press this button to display the previous screen. وزيعت مبانه روزي

4 "MENU" button

Press this button to display the $\Box\Box$ screen. (\rightarrow P. 410)

(5) Remote Touch knob

Move in the desired direction to select a function, letter and screen button. Press the knob to enter the selected function, letter or screen button.


6 "ENTER" button

Press this button to enter the selected function, letter or screen button.

Interior features

Remote Touch operation

- 1) Select: Move the Remote Touch knob in the desired direction.
- 2 Enter: Push the Remote Touch knob or an "FNTFR" button.



■ Screen display during low temperatures

When the ambient temperature is extremely low, screen response may be delayed even if the Remote Touch is operated.

A CAUTION

■ When using the Remote Touch

- Do not allow fingers, fingernails or hair to become caught in the Remote Touch as this may cause an injury.
- Be careful when touching the Remote Touch in extreme temperatures as it may become very hot or cold due to the temperature inside the vehicle.

♠ NOTICE

■ To prevent damage to the Remote Touch

- Do not allow the Remote Touch to come into contact with food, liquid, stickers or lit cigarettes as doing so may cause it to change color, emit a strange odor or stop functioning.
- Do not subject the Remote Touch to excessive pressure or strong impact as the knob may bend or break off.
- Do not allow coins, contact lenses or other such items to become caught in the Remote Touch as this may cause it to stop functioning.
- Items of clothing may rip if they become caught on the Remote Touch knob.
- If your hand or any object is on the Remote Touch knob when the engine switch is turned to ACCESSORY mode, the Remote Touch knob may not operate properly.

"Menu" screen

Press the "MENU" button on the Remote Touch to display the "Menu" screen.

The display may differ depending on the type of the system.

When the split-screen display is selected, the "Menu" screen will be displayed on the main display.

 $(\to P.414)$





تلفن شبانه روزی: ۱۵۸۰۲۹۸۸۸–۲۲۰

► Except for Korea

Switch	Function
*1	Select to display the map screen or the navigation menu screen.*2
(1) (1) (1) (1) (1) (1) (1)	Select to display the radio control screen.*2
	Select to display the media control screen.*2
6	Select to display the hands-free operation screen.*2
*1	Select to display the fuel consumption screen. $(\rightarrow P. 139, 140)$
(i)	Select to display the "Information" screen or the fuel consumption screen.* 2 (\rightarrow P. 139, 140)
72	Select to display the air conditioning control screen. (\rightarrow P. 420)
	Select to display the "Setup" screen or the "Setting and editing" screen.*2
"Display"	Select to adjust the contrast and brightness of the screens, turn the screen off, etc.*2
Q *1	Select to display the "Dest" screen.*2

^{*1:} If equipped

^{*2:} For details, refer to "Navigation and Multimedia System Owner's Manual" or "Navigation System Owner's Manual".

▶ For Korea

Switch	Function
	Select to display the destination screen.*
i	Select to display the fuel consumption screen. (\rightarrow P. 139, 140)
	Select to display the 설정/편집 screen.*
(1 Lo)	Select to display the radio control screen.*
	Select to display the media control screen.*
-	Select to display the air conditioning control screen. $(\rightarrow P. 420)$
	Select to display the phone top screen.*
화질	Select to adjust the contrast and brightness of the screens, turn the screen off, etc.*

^{*:} For details, refer to "Navigation and Multimedia System Owner's Manual" or "Navigation System Owner's Manual".

12.3-inch display

12.3-inch display operation

■ Full screen display

The following functions can be displayed full screen:

- Initial screen
- "Menu" screen (→P. 410)
- Map screen*1
- Audio screen*1,2
- Fuel consumption screen* $^{2}(\rightarrow P.138)$
- Air conditioning control screen^{*2} (→P. 418)
- *1: For details, refer to "Navigation and Multimedia System Owner's Manual" or "Navigation System Owner's Manual".
- *2: Except for Hong Kong and Macau



■ Split-screen display

Different information can be displayed on the left and right of the screen. For example, audio screen can be displayed and operated while the fuel consumption information screen is being displayed.

The large screen on the left of the display is called the main display, and the small screen to the right is called the side display.



تلفن شبانه روزی: ۱۵۸۸۶۲۰۸۵ تلفن شبانه روزی

Split-screen display operation

Selecting the operation screen

When selecting the main display, move the Remote Touch knob to the left. When selecting the side display, move the Remote Touch knob to the right.

■ Main display

For details about the functions and operation of the main display, refer to the respective section and "Navigation and Multimedia System Owner's Manual" or "Navigation System Owner's Manual".

■ Side display

Basic screens

To change the screen displayed on the side display, use the screen buttons on the right side of the display.


- 1 Navigation system*1
- 2 Audio*1
- 3 Phone*1
- Vehicle information
 (→P 142)
 —
- ⑤ Air conditioning system(→P. 423)
- 6 Select to hide the side display. If the item displayed on the main display is full screen display compatible (→P. 413), it will be displayed full screen.*2



▶ Interruption screens


Each of the following screens is displayed automatically in accordance with conditions.

- · Lexus parking assist-sensor
- Phone*1
- Driving mode
- Lexus night view (if equipped) $(\rightarrow P.395)$
- *1: For details, refer to "Navigation and Multimedia System Owner's Manual" or "Navigation System Owner's Manual".
- *2: Except for Hong Kong and Macau



Lexus Climate Concierge

The climate control seats/seat heater* on each seat and heated steering wheel* are automatically controlled according to the set temperature of the air conditioning system, outside temperature, cabin temperature, etc. Lexus Climate Concierge allows a comfortable condition to be maintained without adjusting each system.



1 Automatic air conditioning system (\rightarrow P. 424, 439)

Set the air conditioning system to automatic mode.

The temperature for the driver's seat, front passenger's seat and both rear seats* can be adjusted individually.

② Climate control seats/seat heaters* (\rightarrow P. 478, 479)

Select "AUTO" mode on each seat.

Seat heater, off, ventilation* or seat cooler* is automatically selected according to the set temperature of the air conditioning system, outside temperature, etc.

 \bigcirc Heated steering wheel* (\rightarrow P. 476)

Turned on automatically according to the outside temperature and cabin temperature.

Operates for a maximum of 30 minutes.

Front automatic air conditioning system

Air outlets and fan speed are automatically adjusted according to the temperature setting.

Press the "MENU" button on the Remote Touch, and then select to display the air conditioning operation screen.



The air conditioning system can be displayed and operated on the side display. $(\rightarrow P.414)$

The illustrations below are for left-hand drive vehicles.

The button positions and shapes will differ for right-hand drive vehicles. Also, the display and button positions will differ depending on the type of the system. 6169199141


تلفن شيانه روزي: ۵۸+۲۸۸۸ تلفن شيانه روزي:

■ Control panel

▶ Type A



▶ Type B



- 1 Left-hand front seat side temperature control
- 2 Left-hand front seat side temperature display
- 3 Right-hand front seat side temperature display
- 4 Right-hand front seat side temperature control

- (5) Outside/recirculated air mode
- 6 Windshield defogger
- 7 Air outlet selector
- 8 Fan speed control
- 9 Off
- (10) Automatic mode

- Operation screen (Main display)
 - ▶ Without rear air conditioning system



▶ With rear air conditioning system



- 1 Left-hand front seat side temperature control
- 2 Fan speed control
- 3 Air flows to the feet and the windshield defogger operates
- 4 Right-hand front seat side temperature control
- (5) Option control screen
- (6) Automatic mode
- 7 Select to set cooling and dehumidification function on/off

- (8) DUAL/4-ZONE mode on/off
- (9) Eco mode on/off
- (10) Front seat air outlet selector
- Right-hand front seat side air outlet selector
- 12 Left-hand front seat side air outlet selector
- Rear air conditioning operation screen



تلفن شبانه روزی: ۱۵۸۰۲۹۸۸–۲۲

■ Option control screen

- ► Without rear air conditioning system
- ▶ With rear air conditioning system





- 1 Pollen removal mode on/off
- 2 nanoeTM on/off
- $\begin{tabular}{ll} \hline \end{tabular} Air purifier and rear air conditioning function on/off \\ \hline \end{tabular}$

تلفن شبانه روزی: ۱-۸۸۸۶۲ ۲۸

5

■ Operation screen (Side display)

- ► Without rear air conditioning system
- ▶ With rear air conditioning system





- 1) Front seat air outlet selector
- 2 Left-hand front seat side temperature control
- 3 Fan speed control
- 4 Right-hand front seat side temperature control
- (5) Automatic mode
- 6 Cooling and dehumidification function on/off
- 7) DUAL/4-ZONE mode on/off
- 8 Left-hand front seat side air outlet selector
- 9 Right-hand front seat side air outlet selector

Using the automatic air conditioning system

- \blacksquare Press the "AUTO" switch or select "AUTO" on the operation screen.
 - The dehumidification function begins to operate. Air outlets and fan speed are automatically adjusted according to the temperature setting and humidity.
- 2 Press to switch to automatic air intake mode. (type B)

The air conditioning system automatically switches between outside air and recirculated air modes.

- 3 Press or select on the operation screen to increase the temperature and or on the operation screen to decrease the temperature.
 - ► Without rear air conditioning system

When "DUAL" is selected (the indicator will be on) or the passenger's side temperature control button is pressed, the temperature for the driver and passenger seats can be adjusted separately.

Air outlets for the driver and passenger seats may be adjusted separately depending on the temperature setting. تلفن شيانه روزي:

When the climate control seats are set to "AUTO" mode, the system is operated automatically according to the set temperature, outside temperature, etc.

► With rear air conditioning system

When "4-ZONE" is selected (the indicator will be on) or the passenger's side temperature control button is pressed, the temperature for the driver's, front passenger's and rear seats (\rightarrow P. 438) can be adjusted separately.

Air outlets for the driver and passenger seats may be adjusted separately depending on the temperature setting.

When the climate control seats are set to "AUTO" mode, the system is operated automatically according to the set temperature, outside temperature, etc.

■ Automatic mode indicator

If the fan speed setting or air flow modes are operated, the automatic mode indicator goes off. However, automatic mode for functions other than that operated is maintained.

Adjusting the settings manually

- ▶ Without rear air conditioning system
- 1 To adjust the fan speed, press or select on the operation screen to increase the fan speed and or on the operation screen to decrease the fan speed.

Press to turn the fan off.

2 To adjust the temperature setting, press or select on the operation screen to increase the temperature and or on the operation screen to decrease the temperature.

The air conditioning system switches between individual and simultaneous modes each time "DUAL" is selected.

When "DUAL" is selected (the indicator will be on) or the passenger's side temperature control button is pressed, the temperature for the driver and passenger seats can be adjusted separately.

When the climate control seats are set to "AUTO" mode, the system is operated automatically according to the set temperature, outside temperature, etc.

To change the air outlets, press or select an air outlet switch.



- ▶ With rear air conditioning system
- 1 To adjust the fan speed, press or select on the operation screen to increase the fan speed and or on the operation screen to decrease the fan speed.

Press to turn the fan off.

2 To adjust the temperature setting, press or select on the operation screen to increase the temperature and or on the operation screen to decrease the temperature.

The air conditioning system switches between individual and simultaneous modes each time "4-ZONE" is selected.

When "4-ZONE" is selected (the indicator will be on) or the passenger's side temperature control button is pressed, the temperature for the driver's, front passenger's and rear seats (\rightarrow P. 438) can be adjusted separately.

When the climate control seats are set to "AUTO" mode, the system is operated automatically according to the set temperature, outside temperature, etc.

- To change the air outlets, press or select an air outlet switch.
 - 1 Left-hand front seat

(2) Right-hand front seat

Different air outlets for the driver and front passenger seats can be chosen.



Interior features

Defogging the windshield


Press or .

The dehumidification function operates and fan speed increases.

Set the outside/recirculated air mode button to outside air mode if the recirculated air mode is used. (It may switch automatically.)


To defog the windshield and the side windows early, turn the air flow and temperature up.

To return to the previous mode, press or again when the windshield is defogged.




Air outlets and air flow


Upper body




Upper body and feet



Feet



Feet and windshield



Switching between outside air and recirculated air modes

▶ Type A

تلفن شبانه روزی: ۱۸۶۲۰۸۵ Press 👼

The mode switches between 😂 (recirculated air mode) and 😂 (outside air mode) modes each time the button is pressed.

▶ Type B

Press Sauro

The mode switches among (recirculated air mode), automatic and (outside air mode) modes each time the button is pressed.

When the system is switched to automatic mode, the air conditioning system operates automatically.

Interior features

Turning the air purifier off (with rear air conditioning system)

- 1 Select on the operation screen.
- 2 Select "Air Purifier".

The air purifier will turn off when the indicator on the switch goes off. Air will not flow from the roof vents.

To turn the air purifier on, select "Air Purifier" again.

Changing the rear seat settings (with rear air conditioning system)

- Using the automatic mode
 - 1 Select on the operation screen.
 - 2 Select "REAR AUTO".

The air conditioning system and air purifier will operate, and air outlets and speed will be set automatically.

The rear climate control seats are operated automatically according to the set temperature and the outside temperature. $(\rightarrow P.478)$



3 Select to increase the temperature and to decrease the temperature on the operation screen.

Air outlets for the right-hand and left-hand seats may be set separately depending on the temperature setting.

When the rear climate control seats are set to "AUTO" mode, the system is operated automatically according to the set temperature, outside temperature, etc.

■ Adjusting the temperature setting

- 1 Select on the operation screen.
- 2 Select (increase) or (decrease).

Operating the switch will enter individual mode.

- 1 Left-hand rear seat
- (2) Right-hand rear seat



The air conditioning system switches between individual and simultaneous modes each time "4-ZONE" is selected.

When the rear climate control seats are set to "AUTO" mode, the system is operated automatically according to the set temperature, outside temperature, etc.

■ Adjusting the fan speed (air purifier and cool air from the roof vents)

- 1 Select on the operation screen.
- 2 To adjust the fan speed, select to increase the fan speed and
 - to decrease the fan speed.

According to the air outlets currently selected, the fan speed of either the cool air from the roof vents or air purifier will be adjusted. $(\rightarrow P. 442)$

■ Turning the rear air conditioning system off

- 1 Select on the operation screen.
- 2 Select REAR OFF on the operation screen.

The air purifier and the rear climate control seats also turn off.

■ Disabling the switches on the rear controller

1 Select in the operation screen.

2 Select **>>>**

Rear climate control seats buttons are also locked.



Pollen removal mode button

- 1 Select on the operation screen.
- 2 Select .

Outside air mode switches to (recirculated air) mode. Pollen is removed from the air and the air flows to the upper part of the body.


Usually the system will turn off automatically after approximately 1 to 3 minutes.



Adjusting the position of and opening and closing the air outlets

■ Front center outlets and front side outlets

- 1) Direct air flow to the left or right, up or down.
- 2) Turn the knob to open or close the vent.





درو فارما

تلفن شبانه روزی: \$ Rear center outlets - ۱۹۸۸۶۲ + ۱۸۵۸ استانه

Without rear console display

► With rear console display





- 1) Direct air flow to the left or right, up or down.
- 2 Turn the knob to open or close the vent.

Interior features


■ Rear side outlets

- 1) Direct air flow to the left or right, up or down.
- 2) Turn the knob to open or close the vent.



■ Roof side outlets (with rear air conditioning system)

Direct air flow to the left or right, up or down.



تلفن شبانه روزی: ۵۸۰۲۹۸۸۸–۲۱

Operation of the air conditioning system in Eco drive mode

- In the Eco drive mode, the air conditioning system is controlled as follows to prioritize fuel efficiency
 - Engine speed and compressor operation controlled to restrict heating/cooling capacity
 - Fan speed restricted when automatic mode is selected
- To improve air conditioning performance, perform the following operations
 - · Adjust the fan speed
 - Turn off Eco drive mode

■ Using the automatic mode

Fan speed is adjusted automatically in accordance with the temperature setting and ambient conditions. As a result, the following may occur:

- Immediately after the "AUTO" switch is pressed, the fan may stop for a while until warm or cool air is ready to flow.
- Cool air may flow to the area around the upper body when the heater is on.

■ Fogging up of the windows

- The windows will easily fog up when the humidity in the vehicle is high. Selecting "A/C" on will dehumidify the air from the outlets and defog the windshield effectively.
- If you turn "A/C" off, the windows may fog up more easily.
- The windows may fog up if the recirculated air mode is used.

Outside/recirculated air mode

- When driving on dusty roads such as tunnels or in heavy traffic, set the outside/ recirculated air mode button to the recirculated air mode. This is effective in preventing outside air from entering the vehicle interior. During cooling operation, setting the recirculated air mode will also cool the vehicle interior effectively.
- Outside/recirculated air mode may automatically switch depending on the temperature setting or the inside temperature.

Interior teatures

■ Automatic mode for air intake control (type B)

In automatic mode, the system detects exhaust gas and other pollutants and automatically switches between outside air and recirculated air modes.

When the dehumidification function is off, and the fan is operating, turning automatic mode on will activate the dehumidification function.

■ Pollen removal mode

- In order to prevent the windshield from fogging up when the outside air is cold, the following may occur:
 - Outside air mode does not switch to (recirculated air) mode.
 - The dehumidification function operates.
 - The operation cancels after approximately 1 minute.
- In rainy weather, the windows may fog up. Press or
- In extremely humid weather, the windows may fog up.
- The pollens are filtered out even if the pollen removal mode is turned off.
- Air purifier (with rear air conditioning system)

The air purifier will turn on when turning the rear air conditioning system on.

■ When the outside temperature falls to nearly 0°C (32°F)

The dehumidification function may not operate even when "A/C" is selected.



■ Ventilation and air conditioning odors

- To let fresh air in, set the air conditioning system to the outside air mode.
- During use, various odors from inside and outside the vehicle may enter into and accumulate in the air conditioning system. This may then cause odor to be emitted from the vents.
- To reduce potential odors from occurring:
 - It is recommended that the air conditioning system be set to outside air mode prior to turning the vehicle off.
 - The start timing of the blower may be delayed for a short period of time immediately after the air conditioning system is started in automatic mode.

■ nanoe[™] *1

The air conditioning system adopts nanoeTM technology. This helps to fill the cabin with refreshing air by emitting slightly acidic nanoeTM ions coated with water particles through the front center vent on driver's side *2 .

- lacktriangle When the fan is turned on and "nanoe" on the option control screen is selected, the nanoeTM is activated.
- When the fan is operated in the following conditions, system performance will be maximized. If the following conditions are not met, the nanoe™ may not operate at full capacity.
 - The جمع or air outlets are being used. تلفن شبان
 - The front center vent on driver's side is open.
- When nanoe™ is generated, a small amount of ozone is emitted and may be faintly smelled in some situations. However, this is approximately the same as the amount that already exists in nature, such as in forests, and it has no affect on the human body.
- A slight noise may be heard during operation. This is not a malfunction.
- *1: nanoeTM and the nanoeTM mark are trademarks of Panasonic Corporation.
- *2: According to temperature and humidity conditions, fan speed and direction of the air flow, the nanoe™ may not operate at full capacity.

■ Air conditioning filter

 \rightarrow P. 572

■ Customization

Some functions can be customized. (Customizable features \rightarrow P. 667)



■ To prevent the windshield from fogging up

Do not use or during cool air operation in extremely humid weather. The difference between the temperature of the outside air and that of the windshield can cause the outer surface of the windshield to fog up, blocking your vision.

■ nanoe[™]

Do not disassemble or repair the generator because it contains high voltage parts. Contact your Lexus dealer if the generator needs repair.

↑ NOTICE

■ To prevent battery discharge


Do not leave the air conditioning system on longer than necessary when the engine is stopped.

■To prevent damage to the nanoe™

Do not insert anything into the driver's side vent, attach anything to it, or use sprays around the driver's side vent. These things may cause the generator not to work properly.

Rear air conditioning system*

Air outlets and fan speed are automatically adjusted according to the temperature setting.



- 1 Left-hand rear seat side temperature control _______
- 2 Left-hand rear seat side air out- 9 Right-hand rear seat side air let selector
- 3 Automatic mode
- (4) Off
- (5) Fan speed control
- (6) Right-hand rear seat side air outlet selector
- 7) Right-hand rear seat side temperature control

- (8) Right-hand rear seat side temperature display
- flow display
- (10) Fan speed display
- (1) Left-hand rear seat side air flow display
- (1) Left-hand rear seat side temperature display
- (13) Button lock display

Using automatic air conditioning system

1 Press the "AUTO" button.

The air conditioning system will operate, and air outlets and fan speed will be adjusted automatically.

"AUTO" will be displayed on the control panel.

2 Press " \wedge " on "TEMP" to increase the temperature and " \vee " to decrease the temperature.

The temperature for the right-hand and left-hand seats can be adjusted separately.

Air outlets for the right-hand and left-hand seats may be set separately depending on the temperature setting.

When the rear climate control seats are set to "AUTO" mode, the system is operated automatically according to the set temperature, outside temperature, etc.

Adjusting the settings manually

Adjusting the temperature setting

Press " \wedge " on "TEMP" to increase the temperature and " \vee " to decrease the temperature.

The temperature for the right-hand and left-hand seats can be adjusted separately.

When the rear climate control seats are set to "AUTO" mode, the system is operated automatically according to the set temperature, outside temperature, etc.

■ Changing the air outlets

Press '~



The air outlets change as follows each time 🥻 is pressed.


Different air outlets for the right-hand and left-hand rear seats can be chosen.

Air flows as shown below according to the mode selected.

▶ When the indicator on "Air Purifier" (on the option control screen) is on

Upper body





When the indicator on "Air Purifier" (on the option control screen) is off

Upper body





5

Interior features

Upper body and feet



Feet



تلفن شبانه روزی: ۱۲۰۸۸۶۲۰۲۵ تلفن شبانه روزی:


■ Adjusting the air volume

The volume of cool air or air from the air purifier can be adjusted according to the mode selected.

Press * (increase) or * (decrease) on * * .


▶ When the selected air outlets mode is 💃

Cool air flows from roof vents.



 \blacktriangleright When the selected air outlets mode is $\ref{eq:continuous}$, $\ref{eq:continuous}$ or $\ref{eq:continuous}$

Air from the air purifier.




Press the "OFF" button to turn the fan off.

The air purifier also turn off.


Adjusting the position of and opening and closing the air outlets

■ Rear center outlets

► Without rear console display



▶ With rear console display



- 1) Direct air flow to the left or right, up or down.
- 2 Turn the knob to open or close the vent.

■ Rear side outlets


- 1) Direct air flow to the left or right, up or down.
- 2) Turn the knob to open or close the vent.



FarmaS

■ Roof side outlets

Direct air flow to the left or right, up or down.



■ Button lock function

To prevent inadvertent operation, the buttons on the rear controller for the air conditioning system, rear sunshade, rear door sunshades, and audio system can be locked.

Press and hold the "MODE" switch until you hear a beep to lock the buttons. Pressing the "MODE" switch again until you hear a beep will release the lock.

An indicator appears on the display when the buttons are locked.



The rear controller can be locked from the air conditioning operation screen. $(\rightarrow P. 431)$

■ Rear control panel illumination off function

Control panel illumination on the rear controller can be turned off.

Press and hold the "PWR" switch until you hear a beep to turn the illumination off. Pressing the "PWR" switch again until you hear a beep will turn the illumination on.



Replacing the rear air conditioning filter

Replacing the air conditioning filter when using rear air conditioning or air purifier reduces air flow or deodorizing performance. $(\rightarrow P. 572)$



■To prevent battery discharge


Do not leave the air conditioning system on longer than necessary when the engine is off.

Rear window and outside rear view mirror defoggers

These features are used to defog the rear window, and to remove raindrops, dew and frost from the outside rear view mirrors.

On/off

The defoggers will automatically turn off after approximately 15 minutes.



■ Operating conditions

The engine switch must be in the IGNITION ON mode.



■ When the outside rear view mirror defoggers are on

Do not touch the rear view mirror surfaces, as they can become very hot and burn you.

№ NOTICE

■To prevent battery discharge

Turn the defoggers off when the engine is off.

Windshield wiper de-icer*

This feature is used to prevent ice from building up on the windshield and wiper blades.

- 1 Press the "MENU" button on the Remote Touch. $(\rightarrow P. 406)$
- 2 Select on the "Menu" screen.
- 3 Select on the "Climate" screen.
- 4 Operates the windshield wiper de-icer on/off.

Select on the option control screen to turn on the windshield wiper de-icer, then the indicator will be on. The windshield wiper de-icer will automatically turn off after approximately 15 minutes, then the indicator will be off. Selecting on the option control screen again also turns the de-icer off.



تلفن شبانه روزی: Δ

FarmaSOS.com

Operating conditions


The engine switch must be in the IGNITION ON mode.

A CAUTION

■ When the windshield wiper de-icer is on

Do not touch the glass at the lower part of the windshield or to the side of the front pillars as the surfaces can become very hot and burn you.

Interior lights list



1) Shift lever lights


- 7) Rear interior light $(\rightarrow P.448)$
- 2) Front personal lights $(\rightarrow P.449)$
 - (8) Door courtesy lights
- \bigcirc Front interior lights $(\rightarrow P.448)$
- (9) Seat belt buckle lights
- panel ornament (1) Footwell lights (4) Instrument lights

(12) Clock light

- (5) Inside door handle lights
- (11) Engine switch light
- 6 Rear personal lights (\rightarrow P. 449)
- (13) Outer foot lights

Interior lights


- ▶ Front
- (1) "OFF"
- 2 Door position on/off
- (3) "ON"



▶ Rear

On/off

If door position on is selected for the front interior light, the rear interior light is also turned on/off by the opening and closing of a door.






Personal lights


▶ Front

On/off



▶ Rear

On/off



■ Illuminated entry system

The lights automatically turn on/off according to engine switch mode, the presence of the electronic key, whether the doors are locked/unlocked, and whether the doors are opened/closed.

■ To prevent the battery from being discharged

If the following lights remain on when the engine switch is turned off, the lights will go off automatically after 20 minutes:

- Interior lights
- Door courtesy lights
- Personal lights
- Inside door handle lights
- Seat belt buckle lights
- Footwell lights
- Engine switch light

■ Customization

Settings (e.g. The time elapsed before lights turn off) can be changed. (Customizable features →P. 667)


↑ NOTICE

■To prevent battery discharge

Do not leave the lights on longer than necessary when the engine is not running.

List of storage features

▶ 5-seat models



- (1) Glove box
- $(\rightarrow P.453)$ 6 Cool box/auxiliary box
- (2) Auxiliary boxes (if equipped)
- $(\rightarrow P.459)$ (if equipped) 7 Console box $(\rightarrow P.457)$


- (3) Cup holders
- $(\to P.455)$
- (8) Coin holder
- $(\rightarrow P.454)$

- (4) Door pockets
- $(\to P.454)$
- (5) Auxiliary boxes (if equipped)
 - $(\rightarrow P.462)$

Ashtrays (if equipped)

 $(\rightarrow P.470)$

▶ 4-seat models



- $(\rightarrow P.459)$ $(\rightarrow P.462)$
- (2) Auxiliary boxes
- 3 Cup holders $(\rightarrow P.455)$ Console box $(\rightarrow P.457)$ $(\rightarrow P.454)$ 8 Coin holder $(\rightarrow P.454)$ (4) Door pockets
- (5) Auxiliary boxes (if equipped) $(\to P.462)$

Ashtrays (if equipped)

 $(\rightarrow P.470)$

A CAUTION


■ Items that should not be left in the storage spaces

Do not leave glasses, lighters or spray cans in the storage spaces, as this may cause the following when cabin temperature becomes high:

- Glasses may be deformed by heat or cracked if they come into contact with other stored items.
- Lighters or spray cans may explode. If they come into contact with other stored items, the lighter may catch fire or the spray can may release gas, causing a fire hazard.

Glove box

- 1 Open (push button)
- (2) Unlock with the mechanical key
- (3) Lock with the mechanical key



■ Glove box light

The glove box light turns on when the tail lights are on.

■ Trunk opener main switch

The trunk opener main switch is located in the glove box. $(\rightarrow P. 192)$

■ Removing the partition

The partition inside the glove box can be removed

Lift the front side of the partition and pull it out at an angle.



FarmaS₀


A CAUTION

Caution while driving

Keep the glove box closed. In the event of sudden braking or sudden swerving, an accident may occur due to an occupant being struck by the open glove box or the items stored inside.

Coin holder

Press in the button.



A CAUTION

■ Caution while driving

Keep the coin holder closed. Injuries may result in the event of an accident or sudden braking.

Door pockets (front)

The front door pockets can be opened and closed.





A CAUTION

■ Caution while driving


Keep the door pockets closed.

Injuries may result in the event of an accident or sudden braking.

Cup holders


▶ Front


Press in and release the button.



► Rear (5-seat models)


Press in and release the cup holder.





► Rear (4-seat models)

Press in and release the button.



■ When stowing the rear cup holders (5-seat models)

Stow the cup holder with the armrest down. The cup holder cannot be stowed if the armrest is not down.

A CAUTION

■ Items unsuitable for the cup holder

Do not place anything other than cups or aluminum cans in the cup holders. Other items may be thrown out of the holders in the event of an accident or sudden braking and cause injury. If possible, cover hot drinks to prevent burns.

- To avoid burns or fires (vehicles with a cigarette lighter)
 - Do not touch the metal parts of the cigarette lighter in the front cup holder.
 - Do not hold the cigarette lighter in the front cup holder down. It could overheat and cause a fire.
- When not in use

Close the lid of the power outlet in the cup holder when the power outlet is not in use. Foreign objects or liquids that enter the power outlet may cause a short circuit.

↑ NOTICE

■ To prevent damage to the rear cup holder


Stow the cup holder before stowing the armrest.

■ To avoid damaging the power outlet (vehicles with a power outlet)


Close the lid of the power outlet in the front cup holder when the power outlet is not in use. Foreign objects or liquids that enter the power outlet may cause a short circuit.

Console box

- ▶ 4-seat models or 5-seat models without rear seat entertainment system
- 1) Slide the armrest while pressing the button.
- 2 Lift the armrest.




- ▶ 5-seat models with rear seat entertainment system
- 1 Press the button.
- 2 Lift the armrest.



■ Tray in the console box (4-seat models or 5-seat models without rear seat entertainment system)

The tray can be raised backward.



Opening and closing assist function (4-seat models or 5-seat models without rear seat entertainment system)

When the console box is opened or closed partway, this function will apply force in the appropriate direction, helping open or close the console box.

■ Console box light

The console box light turns on when the tail lights are on.



A CAUTION

■ Caution while driving

Keep the console box closed.

Injuries may result in the event of an accident or sudden braking.

♠ NOTICE

■ Tray (4-seat models or 5-seat models without rear seat entertainment system)

Do not insert items exceeding the height of the tray. Doing so may prevent opening and closing of the lid.



Cool box/auxiliary box (if equipped)


- ▶ 5-seat models
- ightharpoonup Pull down the armrest. (\rightarrow P. 483)
- 2 Pull the lever.




3 Open the cool air intake lid.



- ▶ 4-seat models
- 1 Pull up the lever to release the lock and lift the lid.




2 Open the cool air intake lid.



- ■Cool box operating conditions ۱۶۲۰۸۵ :تلفن شبانه روزی:
 - ▶ 5-seat models
 - The rear air conditioning system is on.
 - is displayed on the rear control panel.



- ▶ 4-seat models
- The rear air conditioning system is on.
- 🕏 is displayed on the rear control panel.



■ Items unsuitable for the cool box

- Drinks in unsealed containers
- Fragile items, perishables or anything with strong odor

■ Using a cool box as an auxiliary box


▶ 5-seat models

Close the cool air intake lid to turn off the cool box system.



▶ 4-seat models

Close the cool air intake lid to turn off the cool box system.





Caution while driving TM a SUS. COM


Always keep the cool box/auxiliary box closed to reduce the chance of injury in case of an accident or sudden stop.

Auxiliary boxes

Overhead

Press in the button.

This box is useful for temporarily storing sunglasses and similar small items.




► Rear door (if equipped)

Open the lid.




- ► Rear seat (5-seat models)
- 1 Pull down the armrest. $(\rightarrow P. 483)$
- 2 Press the button and lift the lid.



► Rear seat (4-seat models)

Press in the lid.

This box is useful for storing DVD discs and headphones.



► Rear console (vehicles with rear console display)

Press in the lid.



■ Tray in the rear console

The tray can be removed.



A CAUTION

■ Using the auxiliary boxes (rear door)

Do not use the auxiliary boxes as an ashtray.

Doing so may cause a fire.

■ Caution while driving

Do not leave the auxiliary box open while driving.

Items may fall out and cause death or serious injury in case of an accident or sudden stop.

■ Items unsuitable for storing (overhead)

Do not store items heavier than 0.2 kg (0.4 lb.).

Doing so may cause the auxiliary box to open and the items inside may fall out, resulting in an accident.

امداد حودرو فارما


تلفن شبانه روزی: ۱۹۰۱۹۸۸ ۲۱ ۲۸


Trunk features

Cargo net


The cargo net is provided for securing loose items on the floor or items inside the trunk.

Raise the cargo hooks on the floor. Hook the net on the cargo hooks.






Shopping bag hooks




Luggage mat

1 Hold the hook and lift up the luggage mat.




2 Secure the luggage mat using the hook.





First-aid kit storage belt ASY - A

- 1 Loosen
- (2) Tighten



A CAUTION


■ When the cargo net is not in use

To avoid injury, always return the cargo hooks on the floor to their stowed positions.

Sun visors and vanity mirrors

Sun visors

- 1) To set the visor in the forward position, flip it down.
- To set the visor in the side position, flip down, unhook, and swing it to the side.
- 3 To use the side extender, place the visor in the side position, then slide it backward.




Vanity mirrors

▶ Front

Slide the cover to open.

The vanity light turns on.




FarmaS

▶ Rear

Press the button to open.

The vanity light turns on.



■ To prevent battery discharge

If the vanity lights remain on when the engine switch is turned off, the lights will go off automatically after 20 minutes.



■ When not in use

Keep the rear vanity mirror closed.

■ To prevent the battery from being discharged

Do not leave the vanity lights on for extended periods while the engine is stopped.



تلفن شبانه روزى: ۵۸ + ۲۹۸۸۸-۲۲ •

Clock

The GPS clock's time is automatically adjusted by utilizing GPS time information. (For details, refer to "Navigation and Multimedia System Owner's Manual" or "Navigation System Owner's Manual".)






تلفن شبانه روزی: ۱۵۸۰۲۹۸۸ - ۲۱

$\overline{\mathsf{Ash}}\mathsf{trays}^*$

Open the ashtray lid.

To remove the ashtray, pull the ashtray lid upwards.



A CAUTION

■ When not in use

Keep the ashtray closed. In the event of sudden braking or sudden swerving, an accident may occur due to an occupant being struck by the open ashtray or ash flying out.

■To prevent fire


- Fully extinguish matches and cigarettes before putting them in the ashtray, then
 make sure the ashtray is fully closed.
- Do not place paper or any other type of flammable object in the ashtray.

Cigarette lighters*

▶ Front

Push the back part of the lid to open, and push the cigarette lighter down.

The cigarette lighter will pop up when it is ready for use.



▶ Rear (5-seat models without rear seat entertainment system)

Push the cigarette lighter.

The cigarette lighter will pop out when it is ready for use.






▶ Rear (5-seat models with overhead display)

Push the cigarette lighter.

The cigarette lighter will pop out when it is ready for use.



► Rear (4-seat models)

Open the auxiliary box and push the cigarette lighter.

The cigarette lighter will pop out when it is ready for use.



■ The cigarette lighter can be used when

The engine switch is in ACCESSORY or IGNITION ON mode.

A CAUTION

- To avoid burns or fires
 - Do not touch the metal parts of the cigarette lighter.
 - Do not hold the cigarette lighter down. It could overheat and cause a fire.
 - Do not insert anything other than the cigarette lighter into the outlet.
- When not in use

Keep the ashtray closed.


Injuries may result in the event of an accident or sudden braking.

Power outlets

The power outlet can be used for $12\ V$ accessories that run on less than $10\ A$.

▶ Front*

Push the back part of the lid to open, and open the lid.




▶ Console box

Open the console box and open the lid.




▶ Rear (5-seat models without rear seat entertainment system)*

Open the lid.



► Rear (5-seat models with overhead display)*


Open the lid.



► Rear (5-seat models with rear console display)

Push the cover to open, and open the lid.





► Rear (4-seat models)* ۱۹۹۲ + ۱۸۵ خوزی: ۵۰۲ + ۱۹۹۲ تلفن شبانه روزی:

Open the auxiliary box and open the lid.





^{*:} If equipped

■ The power outlet can be used when

The engine switch is in ACCESSORY or IGNITION ON mode.



■ To avoid damaging the power outlet

Close the power outlet lid when the power outlet is not in use.

Foreign objects or liquids that enter the power outlet may cause a short circuit.

■ To prevent the fuse from being blown

Do not use an accessory that uses more than $12\ V\ 10\ A$.

■ To prevent the battery from being discharged

Do not use the power outlet longer than necessary when the engine is not running.




تلفن شبانه روزی: ۱۲۰۸۸۶۲۰۸۸ ۲۱۰

Heated steering wheel*

The left and right grip portions of the steering wheel can be heated.

Automatic operation

Operates automatically according to the outside and cabin temperature when the engine switch is turned to IGNITION ON mode. Automatic operation can be turned off using the switch.



The indicator light comes on when the heater is operating.

▶ Manual operation

Turns the heated steering wheel on/off.

The indicator light comes on when the \\ الفن شبانه روزى. ها heater is operating.

■Operating condition armaSOS.com

The engine switch is in IGNITION ON mode.

■ Timer function

Manual operation: Turns off after approximately 30 minutes.

Automatic operation: Operates for a maximum of 30 minutes. (Turns off according to outside and cabin temperature.)

■ If the indicator light does not come on

If the indicator light does not come on when the switch is pressed, a malfunction may have occurred in the system. Have the vehicle inspected by your Lexus dealer.

■ Customization

The automatic turning on/off of the heated steering wheel can be customized. (Customizable features \rightarrow P. 667)



■ Burns

Only appropriately qualified and capable non-impaired persons should operate the vehicle. However, care should be taken to prevent injury if anyone in the following categories comes into contact with the steering wheel when the heated steering wheel is on:

- Babies, small children, the elderly, the sick and the disabled
- Persons with sensitive skin.
- Persons who are fatigued
- Persons who have taken alcohol or drugs that induce sleep (sleeping drugs, cold remedies, etc.)

↑ NOTICE

■ To prevent the battery from being discharged

Turn the switch off when the engine is not running.




Climate control seats/seat heaters*

The seats can be heated or cooled. When set to "AUTO" mode, the climate control seats/seat heaters are linked to the air conditioning settings and automatically adjusted.

Front climate control seats


1 Press the knob to release the lock.

Press the knob to lock it when not in use.




- ▶ AUTO setting
- Turn the knob to the "AUTO" position.

When set to "AUTO" mode, seat heater, off, ventilation or seat cooler is automatically selected according to the set temperature of the air conditioning system, outside temperature, etc.




- ► Manual setting
- 2 Set the temperature by turning the knob to the left or right.
 - (1) Off
 - (2) Seat heater
 - (3) Ventilation
 - (4) Seat cooler



Rear climate control seats (if equipped)/seat heaters (if equipped)

▶ 5-seat models



▶ 4-seat models




■ AUTO setting

The switch turned on/off.

When set to "AUTO" mode, the indicator illuminates.

When set to "AUTO" mode, seat heater, off, ventilation* or seat cooler* is automatically selected according to the set temperature of the air conditioning system, outside temperature, etc.





■ Manual setting

The strength of the seat heater and seat cooler can be adjusted to 3 levels each.

Seat heater *1 : When the system is off, pressing " \blacktriangle " turns the seat heater on.

Pressing "▲" increases the level and pressing "▼" lowers the level.

Seat cooler $^{*2, 3}$: When the system is off, pressing " $\mathbf{\nabla}$ " turns the seat cooler on.

Pressing "▼" increases the level and pressing "▲" lowers the level.



Seat heater*1 Seat cooler*2,3

- (1) Low
- Mid
- (3) Hi

- (4) Low
- (5) Mid
- 6 Hi

^{*1:} The indicator illuminates in amber.

^{*2:} The indicator illuminates in blue.

^{*3:} Vehicles with climate control seats

■ Operating condition

The engine switch is in IGNITION ON mode.

■ Climate control seat/seat heater operation

Depending on the outside temperature and the temperature of the seat surface, there are cases when heating operation is stronger than usual.

- Operating the rear climate control seats from the front seats
 - \rightarrow P. 429
- Disabling the switches on the rear controller
 - \rightarrow P. 431
- Replacing the air filters

Filters are installed in the climate control seats. For replacement of the filters, contact your Lexus dealer.

■ Customization

Automatic operation settings can be customized. (Customizable features \rightarrow P. 667)



A CAUTION

■Burns/excessive cooling

- Use caution when seating the following persons in a seat to avoid the possibility of burns or excessive cooling:
 - Babies, small children, elderly persons, sick persons and persons with a physical disability
 - · Persons who have sensitive skin
 - · Persons who are fatigued
 - Persons who have taken alcohol or drugs which induce sleep, such as sleeping drugs and cold remedies
- Do not cover the seat with anything when using the climate control seat or seat heater. Using the climate control seat or seat heater with a blanket or cushion may increase or decrease the temperature of the seat, resulting in overheating or overcooling.
- Do not use the climate control seat or seat heater more than necessary. Doing so may cool the occupants excessively or may cause minor burns or overheating.

♠ NOTICE

■ To prevent damage to the climate control seat and seat heater


Do not put heavy objects that have an uneven surface on the seat and do not stick sharp objects, such as needles and nails, into the seat.

■ To prevent the battery from being discharged

Do not leave the system on longer than necessary when the engine is off.

Armrest (5-seat models)

Pull the armrest down for use.






■To prevent damage to the armrest

Do not place too much strain on the armrest.



Retractable table (4-seat models)

1 Slide the lever to raise the table.




2 Pull the table up and pull down the table.




The position of the table can be changed. Before using the table, make sure that the table is securely locked.

When the table is in use, the front seats will stop if they are going to contact the table. $(\rightarrow P. 202, 222)$

When returning the table, pull it up while pulling the lock release lever.







■ When not in use

To avoid injury, return the table.

■ Caution while driving

Keep the table stowed properly in its place. In the event of an accident, contact with the table may result in death or serious injury.

■ When using the table

Observe the following precautions. Failure to do so may result in death or serious injury.

- Make sure the table is securely locked.
- Do not lean on the table.
- Do not put anything heavier than 10 kg (22 lb.) on the table.



■To prevent damage to the table

Do not place too much strain on the table.

تلفن شبانه روزی: ۵۸+۲۹۸۸-۲۲


Rear sunshade

The rear sunshade can be raised and lowered by operating any of the buttons shown below.

■ From front seat

▶ Vehicles without power rear seat

Extend/retract




▶ Vehicles with power rear seat

Extend/retract



▶ Vehicles with relaxation seat


Extend/retract



■ From rear seat


▶ 5-seat models (vehicles without power rear seat)

Extend/retract




▶ 5-seat models (vehicles with power rear seat)

Extend/retract



▶ 4-seat models

Extend/retract_



■ The rear sunshade can be used when

The engine switch is in IGNITION ON mode.

Operating the rear sunshade after turning the engine switch off

The rear sunshade can be operated for approximately 60 seconds even after the engine switch is switched to ACCESSORY mode or turned off.

■ Reverse operation feature

To ensure adequate rear visibility, the rear sunshade automatically lowers when the shift lever is shifted to R.

However, the rear sunshade is raised again if any of the following occurs:

- The button is pressed again.
- The shift lever is shifted to P.
- The shift lever is shifted out of P and R, and the vehicle reaches a speed of 15 km/h (9 mph).

If the engine is turned off when the rear sunshade has been lowered due to the reverse operation feature, it will not be raised even when the engine is turned on again and the vehicle reaches a speed of 15 km/h (9 mph). To raise the sunshade again, press the button.

■ Button lock function

To prevent inadvertent operation, some buttons on the rear controller can be locked. $(\rightarrow P.444)$



■ When the rear sunshade is being raised or lowered

Do not place fingers or other objects in the shade mechanism or in the opening as injury may result.

⚠ NOTICE

■ To prevent the battery from being discharged

Do not operate the rear sunshade when the engine is not running.

■ To ensure normal operation of the sunshade

Observe the following precautions:

- Do not place excessive load on the motor or other components.
- Do not place objects where they may hinder opening and closing operations.
- Do not attach items to the rear sunshade.
- Keep the opening clean and clear of obstructions.
- Do not operate the rear sunshade continuously for long periods of time.




Rear door sunshades*

The rear door sunshades can be extended and retracted by operating any of the buttons shown below.

■ From front seat


▶ Vehicles with power rear seat

Extend/retract



▶ Vehicles with relaxation seat


Extend/retract



■ From rear seat


▶ 5-seat models

Extend/retract



▶ 4-seat models

Extend/retract



■ Operating conditions

- The engine switch is in IGNITION ON mode.
- The rear windows are fully closed.
 The rear door sunshades automatically retract when the rear windows are opened.

Operating the rear door sunshades after turning the engine switch off

The rear door sunshades can be operated for approximately 60 seconds even after the engine switch is switched to ACCESSORY mode or turned off.

■ Jam protection function

If an object becomes caught between a rear door sunshade and the window frame, the jam protection function will cause the sunshade to detach from its drive mechanism and retract.

▶ If the jam protection function operates when extending the rear door sunshades
Pressing the button will reconnect the sunshade.

Pressing the button again will allow the sunshades to be operated.

If the sunshade does not operate after the button is pressed, press the button again.

▶ If the jam protection function operates when retracting the rear door sunshades

Press and hold the button to re-extend the rear door sunshades, and continue pressing for more than 5 seconds after the sunshades have fully extended and stopped.

■Button lock function ۲۱ – ۱۹۸۸۶۲۰۸۵ تلفن شبانه روزی:

To prevent inadvertent operation, some buttons on the rear controller can be locked. $(\rightarrow P. 444)$

■ When reconnecting the battery

The rear door sunshades will always be retracted the first time the button is pressed.

A CAUTION

■ When the rear door sunshades are being extended or retracted

Do not place fingers or other objects in the shade mechanism or in the opening as injury may result.

■ Jam protection function

Never use any part of your body to intentionally activate the jam protection function.



■ To prevent the battery from being discharged

Do not operate the rear door sunshades when the engine is not running.

■ To ensure normal operation of the sunshades

Observe the following precautions:

- Do not place excessive load on the motor or other components.
- Do not place objects where they may hinder opening and closing operations.
- Do not attach items to the rear door sunshades.
- Keep the opening clean and clear of obstructions.
- Do not operate the rear door sunshades continuously for long periods of time.


Trunk storage extension*

Long objects can be loaded in the vehicle by utilizing the trunk space and rear seat area.

- 1 Pull down the armrest. $(\rightarrow P. 483)$
- 2 Open the armrest door.

The armrest door can be locked and unlocked using the mechanical key.

- 1 Unlock
- (2) Lock
- ► Opening from the cabin
- 3 Open the inside trunk door from the cabin, and load baggage or روزی: ۵۸۰۲۶۸۸۱ ۲۰ other items.





- ▶ Opening from the trunk 3 Open the inside trunk door from
- the trunk, and load baggage or other items.





A CAUTION

■ When not in use

Ensure that the inside trunk door is closed.

In the event of sudden braking, items stored in the trunk may be thrown forward into the cabin, resulting in injury.




تلفن شبانه روزی: ۱۲۰۸۸۶۲۰۲۵ تلفن شبانه روزی: ۱۲۰۸۸۸۶۲۰۲۰

Coat hooks


▶ Vehicles without rear air conditioning system

To use the coat hook, push it on.



▶ Vehicles with rear air conditioning system

To use the coat hook, push it on.



A CAUTION

■ Items that must not be hung on the hook

Do not hang a coat hanger or other hard or sharp object on the hook. If the SRS curtain shield airbags deploy, these items may become projectiles that cause death or serious injury.

Assist grips

An assist grip installed on the ceiling can be used to support your body while sitting on the seat.



A CAUTION

■ Assist grip

Do not use the assist grip when getting in or out of the vehicle or rising from your seat.

Doing so could damage the assist grip, or could cause you to injure yourself by falling over.

NOTICE

■To prevent damage to the assist grip

Do not hang any heavy object or put a heavy load on the assist grip.

Garage door opener*

The garage door opener can be programmed to operate garage doors, gates, entry doors, door locks, home lighting systems, and security systems, and other devices.

The garage door opener (HomeLink $^{\circledR}$ Universal Transceiver) is manufactured under license from HomeLink $^{\circledR}$.

Indicator and buttons

The HomeLink[®] compatible transceiver in your vehicle has 3 buttons which can be programmed to operate 3 different devices. Refer to the programming method below appropriate for the device.

- 1 Indicator
- 2 Buttons




FarmaSOS.com

Programming the HomeLink® (garage door type A)

Point the remote control transmitter for the device 25 to 75 mm (1 to 3 in.) from the Home-Link[®] control buttons.


Keep the HomeLink $^{\circledR}$ indicator light in view while programming.



2 Press and hold one of the Home-Link® buttons and the transmitter button. When the HomeLink® indicator light changes from a slow to a rapid flash, you can release both buttons.

If the HomeLink® indicator light comes on but does not flash, the HomeLink[®] button is already programmed. Use the other buttons or follow the "Reprogramming a Home-Link[®] button" instructions. $(\rightarrow P. 502)$

The remote control transmitter is of the rolling code type if the Home-Link® indicator light flashes rapidly for 2 seconds and then remains lit. If your transmitter is of the rolling code type. proceed to the heading "Programming a rolling code system" مح۲۰۸۵ :تلفن شبانه روزی:






3 Test the HomeLink[®] operation by pressing the newly programmed button.

If a HomeLink® button has been programmed for a garage door, check to see if the garage door opens and closes. If the garage door does not operate, see if your remote control transmitter is of the rolling code type. Press and hold the programmed HomeLink® button. The remote control transmitter is of the rolling code type if the HomeLink® indicator light flashes rapidly for 2 seconds and then remains lit. If your transmitter is of the rolling code type, proceed to the heading "Programming a rolling code system"





Repeat the steps above to program another device for each of the remaining HomeLink® buttons.

■ Programming a Rolling Code system

If your device is Rolling Code equipped, follow the steps under the heading "Programming the HomeLink®" before proceeding with the steps listed below.

1 Locate the learn button on the ceiling mounted garage door opener motor. The exact location and color of the button may vary by brand of garage door opener motor.

Refer to the operation manual supplied with the garage door opener for the location of the learn button.

2 Press the learn button.

Following this step, you have 30 seconds in which to initiate step 3 below.

3 Press and hold the vehicle's programmed HomeLink[®] button for 2 seconds and release it. Repeat this step once again. The garage door may open.

If the garage door opens, the programming process is complete. If the door does not open, press and release the button a third time. This third press and release will complete the programming process by opening the garage door.

The ceiling mounted garage door opener motor should now recognize the HomeLink[®] signal and operate the garage door.

4 Repeat the steps above to program another rolling code system for any of the remaining HomeLink[®] buttons.

Programming the HomeLink® (garage door type B) or entry gate

- - Keep the $\mathsf{HomeLink}^{\mathbb{B}}$ indicator light in view while programming.
- Repeatedly press and release (cycle) the device's remote control button for two seconds each until step 4 is completed.
- 4 When the indicator light on the HomeLink® compatible transceiver starts to flash rapidly, release the buttons.
- **5** Test the operation of the HomeLink[®] by pressing the newly programmed button. Check to see if the gate/device operates correctly.
- 6 Repeat the steps above to program another device for each of the remaining HomeLink[®] buttons.

Programming other devices

To program other devices such as home security systems, home door locks or lighting, contact your Lexus dealer for assistance.

Operating HomeLink®

Press the appropriate $\mathsf{HomeLink}^{\circledR}$ button. The $\mathsf{HomeLink}^{\circledR}$ indicator light should turn on.

The HomeLink[®] compatible transceiver in your vehicle continues to send a signal for up to 20 seconds as long as the button is pressed.


Reprogramming a HomeLink® button

The individual HomeLink[®] buttons cannot be erased but can be reprogrammed. To reprogram, press and hold the desired HomeLink[®] button. After 20 seconds, the HomeLink[®] indicator light will start flashing slowly. Next, while still pressing and holding the HomeLink[®] button, press and hold the button on the transmitter until the HomeLink[®] indicator light changes from a slow to a rapid flash.

Erasing the entire HomeLink® memory (all three programs)

Press and hold the 2 outside buttons for 10 seconds until the indicator light flashes.

If you sell your vehicle, be sure to erase the programs stored in the $\mathsf{HomeLink}^{\mathbb{B}}$ memory.



■ Before programming

- Install a new battery in the remote control transmitter.
- ullet The battery side of the remote control transmitter must be pointed away from the HomeLink $^{\hbox{\scriptsize (B)}}$ button.

A CAUTION

■ When programming a garage door or other remote control device

The garage door on other device may operate, so ensure people and objects are out of danger to prevent potential harm.



تلفن شبانه روزی: ۱۵۸۰۲۹۸۸ - ۲۱

ERA-GLONASS*

ERA-GLONASS is a telematics service that uses Global Navigation Satellite System (GLONASS) data and embedded cellular technology to enable the following emergency calls to be made: Automatic emergency calls (Automatic Collision Notification) and manual emergency calls (by pressing the "SOS" button). This service is required by Eurasian Customs Union Regulations.

System components



Emergency Notification Services

■ Automatic Collision Notification

If any airbag deploys, the system is designed to automatically call the Public Safety Answering Point (PSAP).* The responding agent receives the vehicle's location and attempts to speak with the vehicle occupants to assess the level of emergency. If the occupants are unable to communicate, the agent automatically treats the call as an emergency, contacts the nearest emergency services provider to describe the situation, and requests that assistance be sent to the location.

^{*:} In some cases, the call cannot be made. $(\rightarrow P. 506)$

■ Emergency Assistance Button ("SOS")

In the event of an emergency, push the "SOS" button to reach the Public Safety Answering Point (PSAP). The answering agent will determine your vehicle's location, assess the emergency, and dispatch the necessary assistance required.

If you accidentally press the "SOS" button, tell the agent that you are not experiencing an emergency.

Indicator lights

When the engine switch is turned to IGNITION ON mode, the red indicator light will illuminate for 10 seconds and then the green indicator light will illuminate for 2 seconds, indicating that the system is enabled. The indicator lights indicate the following:

- If the green indicator light illuminates and stays on, the system is enabled.
- If the green indicator light flashes, an emergency call is being made (either automatically or manually).
- If no indicator lights illuminate, the system is not enabled.
- If the red indicator light illuminates any time other than immediately
 after the engine switch is turned to IGNITION ON mode, the system
 may be malfunctioning or the backup battery may be depleted. Contact your Lexus dealer.

The service life of the backup battery is 3 years or more.

A CAUTION

■ When the Emergency Call may not be made

- Any of the followings may occur. In such cases, report to the Public Safety Answering Point (PSAP) by other means such as nearby public phones.
 - It may sometimes be difficult to connect to the Public Safety Answering Point (PSAP) even in the reception area of the cellular phone due to the reception level, or if the line is busy.
 - In such cases, you may not be able to connect to the Public Safety Answering Point (PSAP) and thus will not be able to make emergency calls and report to the emergency departments even though the system tries to connect to the Public Safety Answering Point (PSAP).
 - When the vehicle is out of the cellular phone service area, the Emergency Call cannot be made.
 - When any related equipment (such as the "SOS" button panel, indicators, microphone, speaker, DCM, antenna, or any wires connecting the equipment.) has an abnormality, is damaged or broken, the Emergency Call cannot be made.
 - During the Emergency Call, the system makes repeated attempts to connect
 to the Public Safety Answering Point (PSAP). However, if it cannot connect to
 the Public Safety Answering Point (PSAP) due to poor radio wave reception,
 the system may not be able to connect to the cellular network and the call may
 finish without connecting. The red indicator light will blink for approximately
 30 seconds to indicate this disconnection.
 - This device may not function if a shock is applied to it.
- If the battery's voltage decreases or there is a disconnection, the system may not be able to access the Public Safety Answering Point (PSAP).

■ When replacing DCM to a new one

ERA-GLONASS have to be activated. Contact your Lexus dealer.

A CAUTION

■ For your safety

- Please drive safely.
 - The function of this system is to assist you in making the Emergency Call in case of accidents as traffic accidents or sudden medical emergencies, and it does not protect the driver or the passengers in any way. Please drive safely and fasten your seatbelts at all times for your safety.
- In case of an emergency, make lives the top priority.
- If you smell anything burning or another unusual smell, do not stay inside the vehicle and evacuate to a safe area immediately.
- Since the system detects shocks, the automatic reporting may not always occur synchronized with the operation of the airbag system. (If the vehicle is bumped from behind, etc.)
- The airbag may not inflate even in case of an accident, if it does not involve high impact. In such cases, the system may not make emergency calls automatically. The system may also not make automatic emergency calls even if the airbag has been inflated. If any of these should occur, please report to the Public Safety Answering Point (PSAP) by operating the "SOS" button panel button.
- For safety, do not make the Emergency Call while driving.

 Making calls during driving may cause mishandling of the steering wheel, which may lead to unexpected accidents.

 Stop the vehicle and confirm the safety of the area before making the Emergency
- When changing fuses, please use fuses that correspond to the described standard. If you use fuses other than those described, it may cause ignition or smoke in the circuit and may lead to a fire.
- Using the system while there is smoke or an unusual smell may cause a fire. Stop using the system immediately and consult your Lexus dealer.



■To prevent damage

Do not pour any liquid on to the "SOS" button panel etc. and make any impact to it.

■ If the "SOS" button panel malfunctions

It may not be able to make the Emergency Call or inform you of the correct condition of the system. If the "SOS" button panel has been broken, please consult your Lexus dealer.

■ If there is any malfunction of the speaker or the microphone during the Emergency Call or the Manual Maintenance Check

You will not be able to communicate with the Public Safety Answering Point (PSAP) operator.

If any of this equipment has been broken, please consult your Lexus dealer.

امداد حودرو فارما

تلفن شبانه روزی: ۱۵۸۰۲۹۸۸ - ۲۱

FarmaSOS.com

6-1.	Maintenance and care
	Cleaning and protecting the vehicle exterior
	Cleaning and protecting the vehicle interior 514
6-2.	Maintenance
	Maintenance requirements517
•	$Scheduled\ maintenance520$
6-3.	Do-it-yourself maintenance
10 9,39	Do-it-yourself service precautions533
	Hood536
	Positioning a floor jack537
· ۲۱-۸۸۸۶۲ • ۸۵ :	Engine compartment539 تلفن شبانه روزع Tires556
	$Tire\ inflation\ pressure\568$
FarmaSOS	Wheels570
armaooc	Air conditioning filter572
	Electronic key battery575
	Checking and replacing fuses579
	Light bulbs584

Cleaning and protecting the vehicle exterior

Perform the following to protect the vehicle and maintain it in prime condition:

- Working from top to bottom, liberally apply water to the vehicle body, wheel wells and underside of the vehicle to remove any dirt and dust.
- Wash the vehicle body using a sponge or soft cloth, such as a chamois.
- For hard-to-remove marks, use car wash soap and rinse thoroughly with water.
- Wipe away any water.
- Wax the vehicle when the waterproof coating deteriorates.
 If water does not bead on a clean surface, apply wax when the vehicle body is cool.

■ Self-restoring coat

The vehicle body has a self-restoring coating that is resistant to small surface scratches caused in a car wash etc.

- ullet The coating lasts for 5 to 8 years from when the vehicle is delivered from the plant.
- The restoration time differs depending on the depth of the scratch and outside temperature.

The restoration time may become shorter when the coating is warmed by applying warm water.

- Deep scratches caused by keys, coins, etc. cannot be restored.
- Do not use wax that contain abrasives.

Automatic car washes

- Fold the mirrors before washing the vehicle. Start washing from the front of the vehicle. Make sure to extend the mirrors before driving.
- Brushes used in automatic car washes may scratch the vehicle surface and harm your vehicle's paint.

■ High pressure car washes

- Do not allow the nozzles of the car wash to come within close proximity of the windows and the air suspension unit (if equipped).
- Before using the car wash, check that the fuel filler door on your vehicle is closed properly.

■ Aluminum wheels

- Remove any dirt immediately by using a neutral detergent. Do not use hard brushes or abrasive cleaners. Do not use strong or harsh chemical cleaners.
 Use the same mild detergent and wax as used on the paint.
- Do not use detergent on the wheels when they are hot, for example after driving for long distance in the hot weather.
- Wash detergent from the wheels immediately after use.

■ Bumpers and side moldings

Do not scrub with abrasive cleaners.

تلفر شانه روزی: Front side windows water-repellent coating

- The following precautions can extend the effectiveness of the water-repellent coating.
 - Remove any dirt, etc. from the front side windows regularly.
 - Do not allow dirt and dust to accumulate on the windows for a long period.
 Clean the windows with a soft, damp cloth as soon as possible.
 - Do not use wax or glass cleaners that contain abrasives when cleaning the windows.
 - Do not use any metallic objects to remove condensation build up.
- When the water-repellent performance has become insufficient, the coating can be repaired. Contact your Lexus dealer.

A CAUTION


■ When washing the vehicle

Do not apply water to the inside of the engine compartment. Doing so may cause the electrical components etc. to catch fire.

■ When cleaning the windshield

Set the wiper switch to off.

If the wiper switch is in "AUTO", the wipers may operate unexpectedly in the following situations, and may result in hands being caught or other serious injuries and cause damage to the wiper blades.



- When the upper part of the windshield where the raindrop sensor is located is touched by hand
- When a wet rag or similar is held close to the raindrop sensor
- If something bumps against the windshield
- If you directly touch the raindrop sensor body or if something bumps into the raindrop sensor
- Precautions regarding the exhaust pipes and rear bumper diffusers

Exhaust gases cause the exhaust pipes and rear bumper diffusers to become quite hot.

When washing the vehicle, be careful not to touch the pipes and diffusers until they have cooled sufficiently, as touching hot exhaust pipes and rear bumper diffusers can cause burns.

■ Precaution regarding the rear bumper with Blind Spot Monitor (if equipped)

If the paint of the rear bumper is chipped or scratched, the system may malfunction. If this occurs, consult your Lexus dealer.

↑ NOTICE

- To prevent paint deterioration and corrosion on the body and components (aluminum wheels etc.)
 - Wash the vehicle immediately in the following cases:
 - · After driving near the sea coast
 - After driving on salted roads
 - If coal tar or tree sap is present on the paint surface
 - If dead insects, insect droppings or bird droppings are present on the paint surface
 - After driving in an area contaminated with soot, oily smoke, mine dust, iron powder or chemical substances
 - If the vehicle becomes heavily soiled with dust or mud
 - If liquids such as benzene and gasoline are spilled on the paint surface
 - If the paint is chipped or scratched, have it repaired immediately.
 - To prevent the wheels from corroding, remove any dirt and store in a place with low humidity when storing the wheels.

■ Cleaning the exterior lights

- Wash carefully. Do not use organic substances or scrub with a hard brush.
 This may damage the surfaces of the lights.
- Do not apply wax to the surfaces of the lights.
 Wax may cause damage to the lenses.

■ When using an automatic car wash

Set the wiper switch to the off position.

If the wiper switch is in "AUTO", the wipers may operate and the wiper blades may be damaged.

■ When using a high pressure car wash

- When washing the vehicle, do not spray the camera or its surrounding area directly with a high pressure washer. Shock applied from high pressure water may cause the device to not operate normally.
- Do not bring the nozzle tip close to boots (rubber or resin manufactured cover), connectors or the following parts. The parts may be damaged if they come into contact with high-pressure water.
 - Traction related parts
 - Steering parts

- · Suspension parts
- Brake parts

Cleaning and protecting the vehicle interior

The following procedures will help protect your vehicle's interior and keep it in top condition:

Protecting the vehicle interior

- Remove dirt and dust using a vacuum cleaner. Wipe dirty surfaces with a cloth dampened with lukewarm water.
- If dirt cannot be removed, wipe it off with a soft cloth dampened with neutral detergent diluted to approximately 1%.
 Wring out any excess water from the cloth and thoroughly wipe off remaining traces of detergent and water.

Cleaning the leather areas

- Remove dirt and dust using a vacuum cleaner.
- Wipe off any excess dirt and dust with a soft cloth dampened with diluted detergent.
 - Use a diluted water solution of approximately 5% neutral wool detergent.
- Wring out any excess water from the cloth and thoroughly wipe off all remaining traces of detergent.
- Wipe the surface with a dry, soft cloth to remove any remaining moisture. Allow the leather to dry in a shaded and ventilated area.

Cleaning the synthetic leather areas

- Remove dirt and dust using a vacuum cleaner.
- Wipe it off with a soft cloth dampened with neutral detergent diluted to approximately 1%.
- Wring out any excess water from the cloth and thoroughly wipe off remaining traces of detergent and water.

■ Caring for leather areas

Lexus recommends cleaning the interior of the vehicle at least twice a year to maintain the quality of the vehicle's interior.

■ Shampooing the carpets

There are several commercial foaming-type cleaners available. Use a sponge or brush to apply the foam. Rub in overlapping circles. Do not use water. Wipe dirty surfaces and let them dry. Excellent results are obtained by keeping the carpet as dry as possible.

■ Seat belts

Clean with mild soap and lukewarm water using a cloth or sponge. Also check the belts periodically for excessive wear, fraying or cuts.

A CAUTION

■ Water in the vehicle

- Do not splash or spill liquid in the vehicle.
 Doing so may cause electrical components etc. to malfunction or catch fire.
- \bullet Do not get any of the SRS components or wiring in the vehicle interior wet. $(\rightarrow P. 53)$

An electrical malfunction may cause the airbags to deploy or not function properly, resulting in death or serious injury.

■ Cleaning the interior (especially instrument panel)

Do not use polish wax or polish cleaner. The instrument panel may reflect off the windshield, obstructing the driver's view and leading to an accident, resulting in death or serious injury.

■ Cleaning the leather areas of the instrument panel

Do not use any protective agents (coatings etc). Doing so may cause the instrument panel to reflect onto the windshield, obstructing the front view and possibly causing an accident.

♦ NOTICE

■ Cleaning detergents

- Do not use the following types of detergent, as they may discolor the vehicle interior or cause streaks or damage to painted surfaces:
 - Non-seat portions: Organic substances such as benzene or gasoline, alkaline or acidic solutions, dye, and bleach
 - · Seats: Alkaline or acidic solutions, such as thinner, benzene, and alcohol
- Do not use polish wax or polish cleaner. The instrument panel's or other interior part's painted surface may be damaged.

■ Preventing damage to leather surfaces

Observe the following precautions to avoid damage to and deterioration of leather surfaces:

- Remove any dust or dirt from leather surfaces immediately.
- Do not expose the vehicle to direct sunlight for extended periods of time. Park the vehicle in the shade, especially during summer.
- Do not place items made of vinyl, plastic, or containing wax on the upholstery, as they may stick to the leather surface if the vehicle interior heats up significantly.

■ Water on the floor

Do not wash the vehicle floor with water.

Vehicle systems such as the audio system may be damaged if water comes into contact with electrical components such as the audio system above or under the floor of the vehicle. Water may also cause the body to rust.

When cleaning the inside of the windshield (vehicles with LKA [Lane-Keeping Assist])

Be careful not to touch the camera sensor (\rightarrow P. 344).

If the camera is accidentally scratched or hit, LKA may not operate properly or may cause a malfunction.

■ Cleaning the inside of the rear window

- Do not use glass cleaner to clean the rear window, as this may cause damage to the rear window defogger heater wires or antenna. Use a cloth dampened with lukewarm water to gently wipe the window clean. Wipe the window in strokes running parallel to the heater wires or antenna.
- Be careful not to scratch or damage the heater wires or antenna.

Maintenance requirements

To ensure safe and economical driving, day-to-day care and regular maintenance are essential. Lexus recommends the following maintenance:

Scheduled maintenance

• Scheduled maintenance should be performed at specified intervals according to the maintenance schedule.

The interval for scheduled maintenance is determined by the odometer reading or the time interval, whichever comes first, shown in the schedule.

Maintenance beyond the last period should be performed at the same intervals.

• Where to go for maintenance service?

It makes good sense to take your vehicle to your local Lexus dealer for maintenance service as well as other inspections and repairs.

Lexus technicians are well-trained specialists receiving the latest service information through technical bulletins, service tips and in-dealership training programs. They learn to work on Lexus before they work on your vehicle, rather than while they are working on it. Doesn't that seem like the best way?

Your Lexus dealer has invested a lot of money in special Lexus tools and service equipment. It helps them to do the job better and at less cost.

Your Lexus dealer's service department will perform all of the scheduled maintenance on your vehicle reliably and economically.

Rubber hoses (for cooling and heater system, brake system and fuel system) should be inspected by a qualified technician according to the Lexus maintenance schedule.

Rubber hoses are particularly important maintenance items. Have any deteriorated or damaged hoses replaced immediately. Note that rubber hoses will deteriorate with age, resulting in swelling, chafing or cracking.

Do-it-yourself maintenance

What about do-it-yourself maintenance?

Many of the maintenance items are easy to do yourself if you have a little mechanical ability and a few basic automotive tools. Simple instructions for how to perform them are presented in this section.

Note, however, that some maintenance tasks require special tools and skills. These are best performed by qualified technicians. Even if you are an experienced do-it-yourself mechanic, we recommend that repairs and maintenance be conducted by your Lexus dealer who will keep a record of maintenance on your vehicle. This record could be helpful should you ever require Warranty Service.

■ Does your vehicle need repairs?

Be on the alert for changes in performance and sounds, and visual tip-offs that indicate service is needed. Some important clues are:

- Engine missing, stumbling or pinging
- Appreciable loss of power
- Strange engine noises
- A fluid leak under the vehicle (However, water dripping from the air conditioning system after use is normal.)
- Change in exhaust sound (This may indicate a dangerous carbon monoxide leak. Drive with the windows open and have the exhaust system checked immediately.)
- Flat-looking tires, excessive tire squeal when cornering, uneven tire wear
- Vehicle pulls to one side when driven straight on a level road
- Strange noises related to suspension movement
- Loss of brake effectiveness, spongy feeling brake pedal, pedal almost touches the floor, vehicle pulls to one side when braking
- Engine coolant temperature continually higher than normal $(\rightarrow P. 125)$

If you notice any of these clues, take your vehicle to your Lexus dealer as soon as possible. Your vehicle may need adjustment or repair.



A CAUTION

■ If your vehicle is not properly maintained

Improper maintenance could result in serious damage to the vehicle and possible death or serious injury.

■ Handling of the battery

Battery posts, terminals and related accessories contain lead and lead compounds which are known to cause brain damage. Wash your hands after handling. $(\rightarrow P.549)$



تلفن شبانه روزي: ۱۵۸۰۲۹۸۸ - ۲۱

FarmaSOS.com

Scheduled maintenance

Perform maintenance by the schedule as follows:

Maintenance schedule requirements

Your vehicle needs to be serviced according to the normal maintenance schedule. (See "Maintenance schedule".)



If you mainly operate your vehicle under one or more of the special operating conditions below, some of the maintenance schedule items need to be serviced more frequently in order to keep your vehicle in good condition. (See "Additional maintenance schedule".)

A. Road Conditions

- Operating on rough or muddy roads, or roads with melted snow
- 2. Operating on dusty roads (Roads in areas where their pavement rate is low, or a cloud of dust often arises and the air is dry)

B. Driving Conditions

- 1. Heavily loaded vehicle (For example, using a car top carrier and so forth.)
 - 2. Repeated short trips less than 8 km (5 miles) and outside temperatures remain below freezing (Engine temperature will not reach to normal temperature)
 - Extensive idling and/or low speed driving for a long distance such as police, taxi or door-to-door delivery use
 - 4. Continuous high speed driving (80% or more of maximum vehicle speed) for over 2 hours

Maintenance schedule (except for South Africa)

Maintenance operations: I = Inspect

R = Replace, change or lubricate

	RVICE TERVAL:	ODOMETER	RE	ADII	NG						
	dometer ading or	x1000 km	10	20	30	40	50	60	70	80	MONTHS
mo wh	onths, nichever mes first.)	x1000 miles	6	12	18	24	30	36	42	48	
BA	ASIC ENGINE	COMPONENT	ΓS								
1	Drive belts			Ι,		1		1		1	24
2	Engine oil		R	R	R	R	R	R	R	R	12
3	Engine oil filte	er	R	R	R	R	R	R	R	R	12
4	Cooling and h			7		ا/	A			I	24
5	Engine coolar					I				I	-
6	Exhaust pipe ings	s and mount-	۲+,	۸۵	زی:	ه ارو	, شبا	تلفز		I	12
IG	NITION SYSTE	EM									
7	Spark plugs	arma	Re (6	eplac 000	e e	every iles)		000	00	km	-
8	Battery									-	12
FL	JEL AND EMIS	SION CONTR	OL S	SYS	ГЕМ	S					
9	Fuel filter < <see 3<="" notes="" td=""><td>and 4.>></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td>R</td><td>96</td></see>	and 4.>>								R	96
10	Air cleaner fil	ter		I		R		-		R	I: 24 R: 48
11		fuel lines, confuel vapor conee note 1.>>				I				I	24
12	Charcoal can (except Korea					I				I	24

Maintenance operations:

I = Inspect

R = Replace, change or lubricate

	RVICE TERVAL:	ODOMETER	ODOMETER READING								
	dometer ading or	x1000 km	10	20	30	40	50	60	70	80	MONTHS
mc wh	onths, nichever mes first.)	x1000 miles	6	12	18	24	30	36	42	48	
CH	HASSIS AND B	ODY									
13	Brake pedal <	<see 5.="" note="">></see>	ı	1	1	ı	1	1	I	1	6
14	Brake linings	and drums		1		-		-		-	12
15	Brake pads ar	nd discs		1	I	1			-	1	6
16	Brake fluid		I	ı	ı	R	I	I	1	R	l: 6 R: 24
17	Brake pipes a	nd hoses	•					1		1	12
18	Steering whe steering gear	el, linkage and box	//	1		1	7			I	12
19	Drive shaft bo	ots				ı				1	24
20	Suspension dust cover	oall joint and	۲+,	٨۵	زى:	ه ارو	، شبا	تلفز		I	12
21	Automatic tra	nsmission fluid				ı				1	24
22	Transfer oil (A	(WD models)	S	d:	S.	R	10	\mathbf{H}		R	I:12 R:48
23	Front differer models)	ntial oil (AWD		Ι		R		I		R	I: 12 R: 48
24	Rear different	ial oil		1		R		I		R	I: 12 R: 48
25	Front and rea			I		I		I		I	12
26	Tires and infla	tion pressure				1				1	6
27	Lights, horns washers	s, wipers and	Ι	1	I	I	1	I	I	I	6
28	Air conditioni	ng filter	di	splay	, in	dica	ige o tes ce th	tha	t m		nformation enance is
	frigerant amour ner	nt for air condi-		I		I		I		I	12

NOTE:

- 1. After 80000 km (48000 miles) or 48 months inspection, inspect every 20000 km (12000 miles) or 12 months.
- 2. First replace at $160000 \, \text{km}$ ($100000 \, \text{miles}$), then replace every $80000 \, \text{km}$ ($48000 \, \text{miles}$).
- 3. Including the filter in fuel tank.
- 4. Replace every 60000 km (36000 miles) or 72 months in Brazil.
- 5. Parking brake inspection is not necessary.
- 6. 2WD models: Replacement of air suspension pneumatic cylinder assemblies. For Singapore: Replace every 7 years. For Thailand, Malaysia, Indonesia, Brunei, Philippines, Dominican Republic, Republic of Panama, Aruba, Colombia, G.C.C. countries*, Jordan, Lebanon, and Curacao: Replace every 6 years.
- *: Saudi Arabia, Sultanate of Oman, Bahrain, United Arab Emirates, Qatar, Kuwait

تلفن شبانه روزی: ۱۵۸۰۲۹۸۸ - ۲۱

FarmaSOS.com

Additional maintenance schedule (except for South Africa)

Refer to the following table for normal maintenance schedule items requiring more frequent service specific to the type of severe conditions. (For outline, see "Maintenance schedule requirements".)

A-1: Operating on rough or muddy roads, or roads with melted snow						
☐ Inspection of brake linings and drums	Every 10000 km (6000 miles) or 6 months					
☐ Inspection of brake pads and discs	Every 5000 km (3000 miles) or 3 months					
☐ Inspection of brake pipes and hoses	Every 10000 km (6000 miles) or 6 months					
☐ Inspection of suspension ball joint and dust cover	Every 10000 km (6000 miles) or 6 months					
☐ Inspection of drive shaft boots	Every 10000 km (6000 miles) or 12 months					
Replacement of transfer oil (AWD models)	Every 20000 km (12000 miles) or 24 months					
☐ Inspection of steering wheel, linkage and steering gear box	Every 5000 km (3000 miles) or 3 months					
☐ Inspection of front and rear suspension < <see 1.="" note="">></see>	Every 10000 km (6000 miles) or 6 months					
☐ Tightening of bolts and nuts on chassis and body < <see 2.="" note="">></see>	Every 10000 km (6000 miles) or 6 months					

A-2: Operating on dusty roads (Roads in areas where their pavement rate is low, or a cloud of dust often arises and the air is dry)						
Replacement of engine oil	Every 5000 km (3000 miles) or 6 months					
☐ Replacement of engine oil filter	Every 5000 km (3000 miles) or 6 months					
☐ Inspection or replacement of air cleaner filter	I: Every 2500 km (1500 miles) or 3 months R: Every 40000 km (24000 miles) or 48 months					
☐ Inspection of brake linings and drums	Every 10000 km (6000 miles) or 6 months					
☐ Inspection of brake pads and discs	Every 5000 km (3000 miles) or 3 months					
Replacement of transfer oil (AWD models)	Every 20000 km (12000 miles) or 24 months					



FarmaSOS.com

B-1: Heavily loaded vehicle (For example, using a car top carrier and so forth.)						
☐ Replacement of engine oil	Every 5000 km (3000 miles) or 6 months					
☐ Replacement of engine oil filter	Every 5000 km (3000 miles) or 6 months					
☐ Inspection of brake linings and drums	Every 10000 km (6000 miles) or 6 months					
☐ Inspection of brake pads and discs	Every 5000 km (3000 miles) or 3 months					
□ Inspection or replacement of automatic transmission fluid	l: Every 40000 km (24000 miles) or 24 months R: Every 80000 km (48000 miles) or 48 months					
Replacement of transfer oil (AWD models)	Every 20000 km (12000 miles) or 24 months					
☐ Inspection of front and rear suspension < <see 1.="" note="">></see>	Every 10000 km (6000 miles) or 6 months					
☐ Tightening of bolts and nuts on chassis and body << See note 2.>>	Every 10000 km (6000 miles) or 6 months تلفن شبانه					

FarmaSOS.com

B-2: Repeated short trips less than 8 km (5 miles) and outside temperatures remain below freezing (Engine temperature will not reach to normal temperature)							
☐ Replacement of engine oil	Every 5000 km (3000 miles) or 6 months						
☐ Replacement of engine oil filter	Every 5000 km (3000 miles) or 6 months						
B-3: Extensive idling and/or low speed driving for a long distance such as police, taxi or door-to-door delivery use							
☐ Replacement of engine oil	Every 5000 km (3000 miles) or 6 months						
☐ Replacement of engine oil filter	Every 5000 km (3000 miles) or 6 months						
☐ Inspection of brake linings and drums	Every 10000 km (6000 miles) or 6 months						
☐ Inspection of brake pads and discs	Every 5000 km (3000 miles) or 3 months						
B-4: Continuous high speed driving (80% or more of maximum vehicle speed) for over 2 hours _\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\\							
□ Inspection or replacement of automatic transmission fluid	l: Every 40000 km (24000 miles) or 24 months R: Every 80000 km (48000 miles) or 48 months						
☐ Replacement of transfer oil (AWD models)	Every 20000 km (12000 miles) or 24 months						

NOTE:

- Replacement of air suspension pneumatic cylinder assemblies.
 For Singapore: Replace every 7 years.
 For Thailand, Malaysia, Indonesia, Brunei, Philippines, Dominican Republic, Republic of Panama, Aruba, Colombia, G.C.C. countries*, Jordan, Lebanon, and Curacao: Replace every 6 years.
- 2. For seat mounting bolts, front and rear suspension member retaining bolts.
 - *: Saudi Arabia, Sultanate of Oman, Bahrain, United Arab Emirates, Qatar, Kuwait

Maintenance schedule (for South Africa)

Maintenance operations: I = Inspect

R = Replace, change or lubricate

SE	RVICE INTERVAL:	VICE INTERVAL: ODOMETER READING								
	dometer reading or	x1000 km	15	30	45	60	75	90		
	onths, whichever mes first.)	x1000 miles	9	18	27	36	45	54	MONTHS	
ВА	SIC ENGINE COMPON	NENTS								
1	Drive belts		1	1		1	I	1	12	
2	Engine oil		R	R	R	R	R	R	12	
3	Engine oil filter		R	R	R	R	R	R	12	
4	Cooling and heater syste	em 💧 💪		L.	,	ı		-	24	
5	Engine coolant << See no	ote 1.>>//		717	A	1		-	-	
6	Exhaust pipes and moun	tings	I	1	I	1		1	12	
IGNITION SYSTEM										
7	7 Spark plugs < <see 2.="" note="">></see>				A A	. 11-		R	-	
8				اروا	Till (مهر	1	-	12	
FU	EL AND EMISSION CO	NTROL SYST	EM	S						
9	Fuel filter << See note 3.>	2020	2			~	R		96	
10	Air cleaner filter	iaou	5.)		R	I	I	l: 24 R: 48	
11	Fuel tank cap, fuel lines, connections and fuel vapor control valve			1		I		Ι	24	
12	2 Charcoal canister				-			-	24	
CH	CHASSIS AND BODY									
13	Brake pedal < <see 4.="" note="">></see>			-		-		-	24	
14	Brake linings and drums			1		1		I	24	
15	Brake pads and discs		ı	1	I	I	I	I	12	
16	Brake fluid		I	R	I	R	I	R	I: 12 R: 24	

Maintenance operations:

I = Inspect

R = Replace, change or lubricate

SE	SERVICE INTERVAL: ODOMETER READING								
	(Odometer reading or x100		15	30	45	60	75	90	NACNITUS
	onths, whichever mes first.)	x1000 miles	9	18	27	36	45	54	MONTHS
Cł	HASSIS AND BODY								
17	Brake pipes and hoses		I	-	ı	I	ı	I	12
18	Steering wheel, linkage and steering gear box		I	Ι	I	I	I	I	12
19	Drive shaft boots		l I	-	1	1	1	1	24
20	Suspension ball joint and dust cover			-	-	1	-	1	12
21	Automatic transmission fluid		7		-	1		1	36
22	Rear differential oil		را	R		R	I	R	I: 12 R: 48
23	Front and rear suspension	n	I	1	I	I	I	I	12
24	Tires and inflation pressu	ıre	1	-	-	1	-	1	12
25	Lights, horns, wipers and washers		:[5	ه اروز	, ثلبا:	تالفى	-	1	12
26	26 Air conditioning filter FarmaSOS		in m	form	atior enan	n dis	splay	ind	the multi- icates that ed, replace
Re	frigerant amount for air co	nditioner	-	-	-	-	-	-	12

NOTE:

- 1. First replace at 160000 km (100000 miles), then replace every 80000 km (48000 miles).
- 2. It is possible to replace every $100000\,km$ (60000 miles).
- 3. Including the filter in fuel tank.
- 4. Parking brake inspection is not necessary.

Additional maintenance schedule (for South Africa)

Refer to the following table for normal maintenance schedule items requiring more frequent service specific to the type of severe conditions. (For outline, see "Maintenance schedule requirements".)

A-1: Operating on rough or muddy roads, or roads with melted snow						
☐ Inspection of brake linings and drums	Every 15000 km (9000 miles) or 12 months					
☐ Inspection of brake pads and discs	Every 7500 km (4500 miles) or 6 months					
☐ Inspection of brake pipes and hoses	Every 7500 km (4500 miles) or 6 months					
☐ Inspection of suspension ball joint and dust cover	Every 7500 km (4500 miles) or 6 months					
☐ Inspection of drive shaft boots	Every 7500 km (4500 miles) or 12 months					
☐ Inspection of steering wheel, linkage and steering gear box	Every 7500 km (4500 miles) or 6 months					
☐ Inspection of front and rear suspension	Every 7500 km (4500 miles) or 6 months					
☐ Tightening of bolts and nuts on chassis and body < <see note.="">></see>	Every 15000 km (9000 miles) or 12 months					

A-2: Operating on dusty roads (Roads in areas where their pavement rate is low, or a cloud of dust often arises and the air is dry)						
☐ Replacement of engine oil	Every 7500 km (4500 miles) or 6 months					
☐ Replacement of engine oil filter	Every 7500 km (4500 miles) or 6 months					
☐ Inspection or replacement of air cleaner filter	I: Every 7500 km (4500 miles) or 12 months R: Every 60000 km (36000 miles) or 48 months					
☐ Inspection of brake linings and drums	Every 15000 km (9000 miles) or 12 months					
☐ Inspection of brake pads and discs	Every 7500 km (4500 miles) or 6 months					
B-1: Heavily loaded vehicle (For example, using a car top carrier and so forth.)						
☐ Replacement of engine oil	Every 7500 km (4500 miles) or 6 months					
Replacement of engine oil filter	Every 7500 km (4500 miles) or 6 months تلفن شبانه روز					
☐ Inspection of brake linings and drums	Every 15000 km (9000 miles) or 12 months					
☐ Inspection of brake pads and discs	Every 7500 km (4500 miles) or 6 months					
☐ Inspection or replacement of automatic transmission fluid	I: Every 45000 km (27000 miles) or 36 months R: Every 90000 km (54000 miles) or 72 months					
☐ Inspection of front and rear suspension	Every 7500 km (4500 miles) or 6 months					
☐ Tightening of bolts and nuts on chassis and body < <see note.="">></see>	Every 15000 km (9000 miles) or 12 months					

532

B-2: Repeated short trips less than 8 km (5 miles) and outside temperatures remain below freezing (Engine temperature will not reach to normal temperature)							
☐ Replacement of engine oil	Every 7500 km (4500 miles) or 6 months						
☐ Replacement of engine oil filter	Every 7500 km (4500 miles) or 6 months						
B-3: Extensive idling and/or low speed driving for a long distance such as police, taxi or door-to-door delivery use							
☐ Replacement of engine oil	Every 7500 km (4500 miles) or 6 months						
☐ Replacement of engine oil filter	Every 7500 km (4500 miles) or 6 months						
☐ Inspection of brake linings and drums	Every 15000 km (9000 miles) or 12 months						
☐ Inspection of brake pads and discs	Every 7500 km (4500 miles) or 6 months						
B-4: Continuous high speed driving (80% or more of maximum vehicle speed) for over 2 hours _\(\lambda\lambda\) + \(\lambda\lambda\) is the continuous high speed driving (80% or more of maximum vehicle speed)							
□ Inspection or replacement of automatic transmission fluid	l: Every 45000 km (27000 miles) or 36 months R: Every 90000 km (54000 miles) or 72 months						

NOTE:

For seat mounting bolts, front and rear suspension member retaining bolts.

Do-it-yourself service precautions

If you perform maintenance by yourself, be sure to follow the correct procedure as given in these sections.

ltems		Parts and tools
Battery condition	(→P. 549)	 Warm water Baking soda Grease Conventional wrench (for terminal clamp bolts) Distilled water
Engine coolant level	(→P. 547)	 "Toyota Super Long Life Coolant" or a similar high quality ethylene glycolbased non-silicate, non-amine, non-nitrite and non-borate coolant with long-life hybrid organic acid technology "Toyota Super Long Life Coolant" is pre-mixed with 50% coolant and 50% deionized water. Funnel (used only for adding coolant)
	maS ((→P. 544)	 "Toyota Genuine Motor Oil" or equivalent Rag or paper towel Funnel (used only for adding engine oil)
Fuses	(→P. 579)	Fuse with same amperage rating as original
Light bulbs	(→P.584)	 Bulb with same number and wattage rating as original Phillips-head screwdriver Flathead screwdriver Wrench
Radiator and condenser	(→P. 549)	_

Items		Parts and tools
Tire inflation pressure	(→P. 568)	Tire pressure gaugeCompressed air source
Washer fluid	(→P. 553)	 Water or washer fluid containing anti- freeze (for winter use) Funnel (used only for adding water or washer fluid)

A CAUTION

The engine compartment contains many mechanisms and fluids that may move suddenly, become hot, or become electrically energized. To avoid death or serious injury, observe the following precautions.

■ When working on the engine compartment <

- Keep hands, clothing and tools away from the moving fan and engine drive belt.
- Be careful not to touch the engine, radiator, exhaust manifold, etc. right after driving as they may be hot. Oil and other fluids may also be hot.
- Do not leave anything that may burn easily, such as paper and rags, in the engine compartment.
- Do not smoke, cause sparks or expose an open flame to fuel or the battery. Fuel and battery fumes are flammable.
- Be extremely cautious when working on the battery. It contains poisonous and corrosive sulfuric acid.
- Take care because brake fluid can harm your hands or eyes and damage painted surfaces. If fluid gets on your hands or in your eyes, flush the affected area with clean water immediately.

If you still experience discomfort, consult a doctor.

■ When working near the electric cooling fans or radiator grille

Be sure the engine switch is off.

With the engine switch in IGNITION ON mode, the electric cooling fans may automatically start to run if the air conditioning is on and/or the coolant temperature is high. $(\rightarrow P. 549)$

■ Safety glasses

Wear safety glasses to prevent flying or falling material, fluid spray, etc. from getting in your eyes.



■ If you remove the air cleaner filter

Driving with the air cleaner filter removed may cause excessive engine wear due to dirt in the air.

■ If the fluid level is low or high

It is normal for the brake fluid level to go down slightly as the brake pads wear or when the fluid level in the accumulator is high.

If the reservoir needs frequent refilling, it may indicate a serious problem.




تلفن شبانه روزی: ۱۵۸۰۲۹۸۸ - ۲۱

FarmaSOS.com


Hood

Release the lock from the inside of the vehicle to open the hood.

1 Pull the hood lock release lever.
The hood will pop up slightly.



2 Pull up the auxiliary catch lever and lift the hood.



A CAUTION

■ Pre-driving check

Check that the hood is fully closed and locked.


If the hood is not locked properly, it may open while the vehicle is in motion and cause an accident, which may result in death or serious injury.

Positioning a floor jack


When raising your vehicle with a floor jack, position the jack correctly. Improper placement may damage your vehicle or cause injury.

Front


▶ 2WD models



▶ AWD models



Rear



A CAUTION

■ When raising your vehicle

Make sure to observe the following precautions to reduce the possibility of death or serious injury:


• Lift up the vehicle using a floor jack such as the one shown in the illustration.



- When using a floor jack, follow the instructions of the manual provided with the jack.
- Do not use the jack that was supplied with your vehicle.
- Do not put any part of your body underneath the vehicle when it is supported only by the floor jack.
- Always use floor jack and/or automotive jack stands on a solid, flat, level surface.
- Do not start the engine while the vehicle is supported by the floor jack.
- Stop the vehicle on level, firm ground, firmly set the parking brake and shift the shift lever to P.
- Make sure to set the floor jack properly at the jack point.
 Raising the vehicle with an improperly positioned floor jack will damage the vehicle and may cause the vehicle to fall off the floor jack.
- Do not raise the vehicle while someone is in the vehicle.
- When raising the vehicle, do not place any object on top of or underneath the floor jack.
- Vehicles with electronically modulated air suspension:
 Be sure to turn off the height control and stop the engine. Otherwise, the vehicle height may change in the automatic leveling function. (→P. 358)

Engine compartment

▶ 2WD models



- 1 Battery
- $(\to P.549)$
- 6 Electric cooling fans
- 2 Engine oil level dipstick
- \bigcirc Condenser

(8) Radiator

 $(\rightarrow P.549)$ $(\rightarrow P.549)$

- (3) Air cleaners
- (→P. 544) (→P. 554)
 - 9 Engine coolant reservoir
- (4) Engine oil filler cap (\rightarrow P. 545)


 $(\to P.547)$

- (5) Washer fluid tank (\rightarrow P. 553)
- (10) Fuse boxes
- $(\rightarrow P.579)$

For right-hand drive vehicles:

The battery and the fuse box in front of the battery are located on the opposite side of the engine compartment.

▶ AWD models



- (1) Battery
- $(\to P.549)$
- 6 Electric cooling fans
- 2 Engine oil level dipstick
- 7 Condenser

S.com

- (3) Air cleaners
- (→P. 544) 8 Radiator (→P. 554) Project coolant
 - (→P. 549)(⊕ Engine coolant reservoir
- 4 Engine oil filler cap $(\rightarrow P. 545)$

(→P. 547)

 $(\rightarrow P.549)$


- (5) Washer fluid tank (\rightarrow P. 553)
- 10 Fuse boxes
- (→P. 579)

Engine compartment cover

- Removing the engine compartment cover
 - ▶ Outside



▶ Front




▶ V-bank cover armaSOS.com



■ Installing the clips

- 1) Push up center portion
- (2) Insert
- 3 Press



↑ NOTICE

■ Checking the engine compartment cover after installation

Make sure that the cover is securely installed in its original position.


امداد خودرو فارما

تلفن شبانه روزی: ۱۵۸۰۲۹۸۸۸–۲۲۰

FarmaSOS.com

Battery cover


■ Removing the battery cover



■ Installing the clips

▶ Type A







- 1) Push up center portion as OS.com
- 2 Insert
- (3) Press

№ NOTICE

\blacksquare When installing the battery cover

Securely install the cover over the battery. Failure to do so may cause water to enter the engine compartment when it rains or the vehicle is washed, resulting in a malfunction.


Engine oil


With the engine at operating temperature and turned off, check the oil level on the dipstick.

■ Checking the engine oil

- 1 Park the vehicle on level ground. After warming up the engine and turning it off, wait more than 5 minutes for the oil to drain back into the bottom of the engine.
- 2 Holding a rag under the end, pull the dipstick out.
- ▶ 2WD models

► AWD models






- **3** Wipe the dipstick clean.
- 4 Reinsert the dipstick fully.
- **5** Holding a rag under the end, pull the dipstick out and check the oil level.
 - 1 Low
 - (2) Normal
 - (3) Excessive


The shape of the dipstick may differ depending on the type of vehicle or engine.

6 Wipe the dipstick and reinsert it fully.



■ Adding engine oil

If the oil level is below or near the low level mark, add engine oil of the same type as that already in the engine.



Make sure to check the oil type and prepare the items needed before adding oil.

Engine oil selection	تلفن شبانه روزی: P.653 ۱ ° ۸۵ -
Oil quantity (Low → Full)	1.5 L (1.6 qt., 1.3 lmp. qt.)
Items	Clean funnel

- 1 Remove the oil filler cap by turning it counterclockwise.
- **2** Add engine oil slowly, checking the dipstick.
- 3 Install the oil filler cap by turning it clockwise.

■ Engine oil consumption

A certain amount of engine oil will be consumed while driving. In the following situations, oil consumption may increase, and engine oil may need to be refilled in between oil maintenance intervals.

- When the engine is new, for example directly after purchasing the vehicle or after replacing the engine
- If low quality oil or oil of an inappropriate viscosity is used
- When driving at high engine speeds or with a heavy load, or when driving while accelerating or decelerating frequently
- When leaving the engine idling for a long time, or when driving frequently through heavy traffic

A CAUTION

■Used engine oil

- Used engine oil contains potentially harmful contaminants which may cause skin disorders such as inflammation and skin cancer, so care should be taken to avoid prolonged and repeated contact. To remove used engine oil from your skin, wash thoroughly with soap and water.
- Dispose of used oil and filters only in a safe and acceptable manner. Do not dispose of used oil and filters in household trash, in sewers or onto the ground.
 Call your Lexus dealer, service station or auto parts store for information concerning recycling or disposal.
- Do not leave used engine oil within the reach of children.

♠ NOTICE

■To prevent serious engine damage

Check the oil level on a regular basis.

■ When replacing the engine oil


- Be careful not to spill engine oil on the vehicle components.
- Avoid overfilling, or the engine could be damaged.
- Check the oil level on the dipstick every time you refill the vehicle.
- Be sure the engine oil filler cap is properly tightened.

Engine coolant

The coolant level is satisfactory if it is between the "FULL" and "LOW" lines on the reservoir when the engine is cold.

- (1) Reservoir cap
- (2) "FULL" line
- (3) "LOW" line

If the level is on or below the "LOW" line, add coolant up to the "FULL" line. $(\rightarrow P.641)$



FarmaSOS.com

■ Coolant selection

Only use "Toyota Super Long Life Coolant" or a similar high quality ethylene glycol based non-silicate, non-amine, non-nitrite, and non-borate coolant with long-life hybrid organic acid technology.

"Toyota Super Long Life Coolant" is a mixture of 50% coolant and 50% deionized water. (Minimum temperature: -35°C [-31°F])

For more details about engine coolant, contact your Lexus dealer.

■ If the coolant level drops within a short time of replenishing

Visually check the radiator, hoses, engine coolant reservoir caps, drain cock and water pump.

If you cannot find a leak, have your Lexus dealer test the cap and check for leaks in the cooling system.



■ When the engine is hot

Do not remove the engine coolant reservoir cap. $(\rightarrow P.644)$

The cooling system may be under pressure and may spray hot coolant if the cap is removed, causing serious injuries, such as burns.

⚠ NOTICE

■ When adding coolant

Coolant is neither plain water nor straight antifreeze. The correct mixture of water and antifreeze must be used to provide proper lubrication, corrosion protection and cooling. Be sure to read the antifreeze or coolant label.

■ If you spill coolant

Be sure to wash it off with water to prevent it from damaging parts or paint.

Radiator and condenser

Check the radiator and condenser and clear away any foreign objects. If either of the above parts is extremely dirty or you are not sure of their condition, have your vehicle inspected by your Lexus dealer.



■ When the engine is hot

Do not touch the radiator or condenser as they may be hot and cause serious injuries, such as burns.

Battery

Check the battery as follows.

- Removing the battery cover
- \rightarrow P.543

■ Caution symbols


The meanings of each caution symbol on the top of the battery are as follows:

	No smoking, no naked flames, no sparks	Battery acid
6	Shield eyes	Note operating instructions
(A)	Keep away from children	Explosive gas

■ Battery exterior

Make sure that the battery terminals are not corroded and that there are no loose connections, cracks, or loose clamps.

- (1) Terminals
- 2 Hold-down clamp




■ Checking battery fluid

Check that the level is between the "UPPER LEVEL" and "LOWER LEVEL" lines.

- 1) "UPPER LEVEL" line
- (2) "LOWER LEVEL" line

If the fluid level is at or below the "LOWER LEVEL" line, add distilled water.


FarmaS



■ Adding distilled water

- 1 Remove the vent plug.
- 2 Add distilled water.

If the "UPPER LEVEL" line cannot be seen, check the fluid level by looking directly at the cell.



3 Put the vent plug back on and close it securely.

■ Before recharging

When recharging, the battery produces hydrogen gas which is flammable and explosive. Therefore, observe the following before recharging:

- If recharging with the battery installed on the vehicle, be sure to disconnect the ground cable.
- Make sure the power switch on the charger is off when connecting and disconnecting the charger cables to the battery.

■ After recharging/reconnecting the battery

The engine may not start. Follow the procedure below to initialize the system.

- 1 Shift the shift lever to P.
- 2 Open and close any of the doors.
- Restart the engine. (If the engine does not start first time, repeat the procedure.)

 If the engine will not start even after multiple attempts at the above method, contact your Lexus dealer.

A CAUTION

■ Chemicals in the battery

Batteries contain poisonous and corrosive sulfuric acid and may produce hydrogen gas which is flammable and explosive. To reduce the risk of death or serious injury, take the following precautions while working on or near the battery:

- Do not cause sparks by touching the battery terminals with tools.
- Do not smoke or light a match near the battery.
- Avoid contact with eyes, skin and clothes.
- Never inhale or swallow electrolyte.
- Wear protective safety glasses when working near the battery.
- Keep children away from the battery.

■ Where to safely charge the battery

Always charge the battery in an open area. Do not charge the battery in a garage or closed room where there is insufficient ventilation.

A CAUTION

■ Emergency measures regarding electrolyte

- If electrolyte gets in your eyes

 Flush your eyes with clean water for at least 15 minutes and get immediate medical attention. If possible, continue to apply water with a sponge or cloth while traveling to the nearest medical facility.
- If electrolyte gets on your skin
 Wash the affected area thoroughly. If you feel pain or burning, get medical attention immediately.
- If electrolyte gets on your clothes
 It can soak through clothing on to your skin. Immediately take off the clothing and follow the procedure above if necessary.
- If you accidentally swallow electrolyte
 Drink a large quantity of water or milk. Get emergency medical attention immediately.

№ NOTICE

■ When recharging the battery

Never recharge the battery while the engine is operating. Also, be sure all accessories are turned off.

■ When adding distilled water

Avoid overfilling. Water spilled during battery recharging may cause corrosion.

■ When replacing the battery


Replace the battery with a battery of the same size.

Installing a battery of a different size will prevent the cover from being properly installed over the battery. This may cause water to enter the engine compartment when it rains or the vehicle is washed, resulting in a malfunction.

For more information about replacing the battery, contact your Lexus dealer.

Washer fluid

If any washer does not work or the warning message appears on the multi-information display. washer tank may be empty. Add washer fluid.





A CAUTION

■ When adding washer fluid

Do not add washer fluid when the engine is hot or running as washer fluid contains alcohol and may catch fire if spilled on the engine etc.

↑ NOTICE

Do not use any fluid other than washer fluid

Do not use soapy water or engine antifreeze instead of washer fluid.

Doing so may cause streaking on the vehicle's painted surfaces.

■ Diluting washer fluid


Dilute washer fluid with water as necessary.

Refer to the freezing temperatures listed on the label of the washer fluid bottle.

Air cleaner filter

Check the air cleaner filter as follows:

- 1 Remove the V-bank cover $(\rightarrow P. 541)$
- **2** Release the clips.




3 Lift the cover and take out the air cleaner filter.

Inspect the outer surface of the filter, and replace the filter if it is extremely dirty. If the filter is only moderately dusty, use compressed air to blow dust out of the filter.

Clean or replace the both left and right side filters at the same time.

4 Fully engage the claws and then secure the upper cover of the air cleaner case using the latches.







A CAUTION

■To prevent inhaling dust

Wear a respirator when using compressed air to clean the air cleaner filter.



♠ NOTICE

■ To prevent damaging the engine

Do not drive with the air cleaner filter removed. Doing so causes excessive engine wear.



تلفن شبانه روزی: ۱۹۸۸۸۶۲۰۸۵ تلفن شبانه روزی:

FarmaSOS.com


Tires

Replace or rotate tires in accordance with maintenance schedules and treadwear.

Checking tires

Check if the treadwear indicators are showing on the tires. Also check the tires for uneven wear, such as excessive wear on one side of the tread.

Check the spare tire condition and pressure if not rotated.



- لفن شبانه روزی: ۱ New tread * ۲ ۱ ۱ ۱ ۸ ۸ ۲ ۲ ۸ ۸ ۸ ۱ کاله
- (2) Worn tread
- ③ Treadwear indicator maSOS.com

The location of treadwear indicators is shown by a "TWI" or " Δ " mark, etc., molded into the sidewall of each tire.


Replace the tires if the treadwear indicators are showing on a tire.

Tire rotation

Rotate the tires in the order shown.

To equalize tire wear and help extend tire life, Lexus recommends that tire rotation is carried out approximately every 10000 km (6000 miles) for 2WD models or 5000 km (3000 miles) for AWD models.

Vehicle with the tire pressure warning system: Do not fail to initialize the tire pressure warning system after tire rotation.





تلفن شبانه روزی: ۱۵۸۰۲۹۸۸ - ۲۱

FarmaSOS.com

Tire pressure warning system (if equipped)

Your vehicle is equipped with a tire pressure warning system that uses tire pressure warning valves and transmitters to detect low tire inflation pressure before serious problems arise.

- If the tire pressure drops below a predetermined level, the driver is warned by a screen display and a warning light. $(\rightarrow P. 609, 614)$
- The tire pressure detected by the tire pressure warning system can be displayed on the multiinformation display. (→P. 133)



Installing tire pressure warning valves and transmitters

When replacing tires or wheels, tire pressure warning valves and transmitters must also be installed.

When new tire pressure warning valves and transmitters are installed, new ID codes must be registered in the tire pressure warning computer and the tire pressure warning system must be initialized. Have tire pressure warning valve and transmitter ID codes registered by your Lexus dealer. (\rightarrow P. 560)

- Initializing the tire pressure warning system
- The tire pressure warning system must be initialized in the following circumstances:
 - When rotating the tires.
 - When the tire inflation pressure is changed such as when changing traveling speed. (\rightarrow P. 660, 662)
 - When changing the tire size.

When the tire pressure warning system is initialized, the current tire inflation pressure is set as the benchmark pressure.

■ How to initialize the tire pressure warning system

- 1 Park the vehicle in a safe place and turn the engine switch off. Initialization cannot be performed while the vehicle is moving.
- Adjust the tire inflation pressure to the specified cold tire inflation pressure level. $(\rightarrow P. 660, 662)$

Make sure to adjust the tire pressure to the specified cold tire inflation pressure level. The tire pressure warning system will operate based on this pressure level.

3 Turn the engine switch to IGNITION ON mode.



5 Wait for a few minutes with the engine switch in IGNITION ON mode and then turn the engine switch off.

Registering ID codes

The tire pressure warning valve and transmitter is equipped with a unique ID code. When replacing a tire pressure warning valve and transmitter, it is necessary to register the ID code. Have the ID code registered by your Lexus dealer.

■ When to replace your vehicle's tires

Tires should be replaced if:

- The treadwear indicators are showing on a tire.
- You have tire damage such as cuts, splits, cracks deep enough to expose the fabric, and bulges indicating internal damage
- A tire goes flat repeatedly or cannot be properly repaired due to the size or location of a cut or other damage

If you are not sure, consult with your Lexus dealer.

■ Replacing tires and wheels (vehicles with the tire pressure warning system)

If the ID code of the tire pressure warning valve and transmitter is not registered, the tire pressure warning system will not work properly. After driving for about 10 minutes, the tire pressure warning light blinks for 1 minute and stays on to indicate a system malfunction.

■ Tire life

Any tire over 6 years old must be checked by a qualified technician even if it has seldom or never been used or damage is not obvious.

Routine tire inflation pressure checks (vehicles with the tire pressure warning system)

The tire pressure warning system does not replace routine tire inflation pressure checks. Make sure to check tire inflation pressure as part of your routine of daily vehicle checks.

■ When rotating the tires (vehicles with the tire pressure warning system)

Make sure that the engine switch is off. If the tires are rotated while the engine switch is in IGNITION ON mode, the tire position information will not be updated. If this accidentally occurs, either turn the engine switch to off and then to IGNITION ON mode, or initialize the system after checking that the tire pressure is properly adjusted.

■ If the tread on snow tires wears down below 4 mm (0.16 in.)

The effectiveness of the tires as snow tires is lost.

- Situations in which the tire pressure warning system may not operate properly (vehicles with the tire pressure warning system)
 - In the following cases, the tire pressure warning system may not operate properly.
 - If non-genuine Lexus wheels are used.
 - A tire has been replaced with a tire that is not an OE (Original Equipment) tire.
 - A tire has been replaced with a tire that is not of the specified size.
 - Tire chains etc. are equipped.
 - An auxiliary-supported run-flat tire is equipped.
 - If a window tint that affects the radio wave signals is installed.
 - If there is a lot of snow or ice on the vehicle, particularly around the wheels or wheel housings.
 - If the tire inflation pressure is extremely higher than the specified level.
 - If the spare tire is in a location subject to poor radio wave signal reception.
 - If a large metallic object which can interfere with signal reception is put in the trunk.
 - If tires not equipped with tire pressure warning valves and transmitters are used.
 - If the ID code on the tire pressure warning valves and transmitters is not registered in the tire pressure warning computer.
 - Performance may be affected in the following situations.
 - Near a TV tower, electric power plant, gas station, radio station, large display, airport or other facility that generates strong radio waves or electrical noise
 - When carrying a portable radio, cellular phone, cordless phone or other wireless communication device

If tire position information is not correctly displayed due to the radio wave conditions, the display may be corrected by driving and changing the radio wave conditions.

- When the vehicle is parked, the time taken for the warning to start or go off could be extended.
- When tire inflation pressure declines rapidly for example when a tire has burst, the warning may not function.

■ The initialization operation (vehicles with the tire pressure warning system)

- Make sure to carry out initialization after adjusting the tire inflation pressure. Also, make sure the tires are cold before carrying out initialization or tire inflation pressure adjustment.
- If you have accidentally turned the engine switch off during initialization, it is not necessary to press the reset switch again as initialization will restart automatically when the engine switch has been turned to IGNITION ON mode for the next time.
- If you accidentally press the reset switch when initialization is not necessary, adjust the tire inflation pressure to the specified level when the tires are cold, and conduct initialization again.
- Warning performance of the tire pressure warning system (if equipped)

The warning of the tire pressure warning system will change in accordance with driving conditions. For this reason, the system may give a warning even if the tire pressure does not reach a low enough level, or if the pressure is higher than the pressure that was adjusted to when the system was initialized.

■ When initialization of the tire pressure warning system has failed (vehicles with the tire pressure warning system)

Initialization can be completed in a few minutes. However, in the following cases, the settings have not been recorded and the system will not operate properly. If repeated attempts to record tire inflation pressure settings are unsuccessful, have the vehicle inspected by your Lexus dealer.

- When operating the tire pressure warning reset switch, the tire pressure warning light does not blink 3 times.
- After carrying out the initialization procedure, the tire pressure warning light blinks for 1 minute then stays on after driving for 20 minutes.

■ Certification for tire pressure warning system

► For vehicles sold in the United Arab Emirates

TRA

REGISTERED No:

ER0063621/11

DEALER No:

DA0063612/11

► For vehicles sold in Jordan

Type approval No.: TRC/LPD/2010/44

► For vehicles sold in South Africa

TPMS (Tire Pressure Monitoring System) Transmitter conforms to the requirement of ICASA.



► For vehicles sold in Singapore

Complies With IDA Standards DA101418 ► For vehicles sold in Taiwan

經型式認證合格之低功率射頻電機,非經許可,公司、商號或使用者均不得擅 自變更頻率、加大功率或變更原設計之特性及功能。

低功率射頻電機之使用不得影響飛航安全及干擾合法通信;經發現有干擾現象時,應立即停用,並改善至無干擾時方得繼續使用。

前項合法通信,指依電信法規定作業之無線電通信。

低功率射頻電機須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之 干擾。

- ► For vehicles sold in Korea
- Transmitter

Identification Number: PCX-PMV-C210

Equipment Name (Model Number): 특정소출력무선기기(PMV-C210)

Manufactured date:See product Applicant: Pacific Industrial Co., Ltd.

Manufacturer: Pacific Industrial Co., Ltd.

Country of Origin: Japan

Initiator



상호명/제조자 :DENSO CORPORATION 기자재의 명칭(모델명) :자계 유도식 무선기기(22AAA)

제조연월/제조국 : See lower part of the product. / Japan

식별부호 :KCC-CRM-DKR-22AAA



A CAUTION

■ When inspecting or replacing tires

Observe the following precautions to prevent accidents.

Failure to do so may cause damage to parts of the drive train as well as dangerous handling characteristics, which may lead to an accident resulting in death or serious injury.

- Do not mix tires of different makes, models or tread patterns. Also, do not mix tires of remarkably different treadwear.
- Do not use tire sizes other than those recommended by Lexus.
- Do not mix differently constructed tires (radial, bias-belted or bias-ply tires).
- Do not mix summer, all season and snow tires.
- Do not use tires that have been used on another vehicle. Do not use tires if you do not know how they were used previously.

تلفن شبانه روزي: ۵۸۰۲۹۸۸ - ۲۱

FarmaSOS.com

A CAUTION


■Using tires of a different size

Do not use tires of a different size from those equipped when the vehicle was new, as the front tire steering angle setting is designed for the original tire size. It is dangerous to use an incorrect wheel and tire combination as this may result in reduced vehicle stability.

■ When initializing the tire pressure warning system (vehicles with the tire pressure warning system)

Do not operate the tire pressure warning reset switch without first adjusting the tire inflation pressure to the specified level. Otherwise, the tire pressure warning light may not come on even if the tire inflation pressure is low, or it may come on when the tire inflation pressure is actually normal.

- Caution regarding interference with electronic devices (vehicles with the tire pressure warning system)
 - People with implantable cardiac pacemakers, cardiac resynchronization therapy-pacemakers or implantable cardioverter defibrillators should not come within 450 mm (17.7 in.) of the tire pressure warning system initiators. The radio waves may affect the operation of such devices.



Users of any electrical medical device other than implantable cardiac pacemakers, cardiac resynchronization therapy-pacemakers or implantable cardioverter defibrillators should consult the manufacturer of the device for information about its operation under the influence of radio waves.

Radio waves could have unexpected effects on the operation of such medical devices.

♠ NOTICE

- Repairing or replacing tires, wheels, tire pressure warning valves, transmitters and tire valve caps (vehicles with the tire pressure warning system)
 - When removing or fitting the wheels, tires or the tire pressure warning valves and transmitters, contact your Lexus dealer as the tire pressure warning valves and transmitters may be damaged if not handled correctly.
 - Make sure to install the tire valve caps. If the tire valve caps are not installed, water could enter the tire pressure warning valves and the tire pressure warning valves could be bound.
 - When replacing tire valve caps, do not use tire valve caps other than those specified. The cap may become stuck.
- To avoid damage to the tire pressure warning valves and transmitters (vehicles with the tire pressure warning system)

When a tire is repaired with liquid sealants, the tire pressure warning valve and transmitter may not operate properly. If a liquid sealant is used, contact your Lexus dealer or other qualified service shop as soon as possible. Make sure to replace the tire pressure warning valve and transmitter when replacing the tire. $(\rightarrow P.558)$

Driving on rough roads

Take particular care when driving on roads with loose surfaces or potholes. These conditions may cause losses in tire inflation pressure, reducing the cushioning ability of the tires. In addition, driving on rough roads may cause damage to the tires themselves, as well as the vehicle's wheels and body.

If tire inflation pressure of each tire becomes low while driving Do not continue driving, or your tires and/or wheels may be ruined.

Tire inflation pressure

Make sure to maintain proper tire inflation pressure. Tire inflation pressure should be checked at least once per month. However, Lexus recommends that tire inflation pressure be checked once every two weeks. $(\rightarrow P. 660, 662)$

■ Effects of incorrect tire inflation pressure

Driving with incorrect tire inflation pressure may result in the following:

- Reduced fuel economy
- Reduced driving comfort and poor handling.
- Reduced tire life due to wear
- Reduced safety
- Damage to the drive train

If a tire needs frequent inflating, have it checked by your Lexus dealer.

■ Instructions for checking tire inflation pressure

When checking tire inflation pressure, observe the following:

- Check only when the tires are cold.
 If your vehicle has been parked for at least 3 hours or has not been driven for more than 1.5 km or 1 mile, you will get an accurate cold tire inflation pressure reading.
- Always use a tire pressure gauge.

 It is difficult to judge if a tire is properly inflated based only on its appearance.
- It is normal for the tire inflation pressure to be higher after driving as heat is generated in the tire. Do not reduce tire inflation pressure after driving.
- Passengers and luggage weight should be placed so that the vehicle is balanced.



■ Proper inflation is critical to save tire performance

Keep your tires properly inflated.

If the tires are not properly inflated, the following conditions may occur which could lead to an accident resulting in death or serious injury:

- Excessive wear
- Uneven wear
- Poor handling
- Possibility of blowouts resulting from overheated tires
- Air leaking from between tire and wheel
- Wheel deformation and/or tire damage
- Greater possibility of tire damage while driving (due to road hazards, expansion joints, sharp edges in the road, etc.)



■ When inspecting and adjusting tire inflation pressure

Be sure to put the tire valve caps back on.

If a valve cap is not installed, dirt or moisture may get into the valve and cause an air leak, resulting in decreased tire inflation pressure.

FarmaSOS.com

Wheels

If a wheel is bent, cracked or heavily corroded, it should be replaced. Otherwise, the tire may separate from the wheel or cause a loss of handling control.

Wheel selection

When replacing wheels, care should be taken to ensure that they are equivalent to those removed in load capacity, diameter, rim width and inset*.

Replacement wheels are available at your Lexus dealer.

*: Conventionally referred to as "offset".

Lexus does not recommend using the following:

- Wheels of different sizes or types
- Used wheels
- Bent wheels that have been straightened

Aluminum wheel precautions

- Use only Lexus wheel nuts and wheel nut wrenches designed for use with your aluminum wheels.
- When rotating, repairing or changing your tires, check that the wheel nuts are still tight after driving 1600 km (1000 miles).
- Be careful not to damage the aluminum wheels when using tire chains.
- Use only Lexus genuine balance weights or equivalent and a plastic or rubber hammer when balancing your wheels.

■ When replacing wheels (vehicles with the tire pressure warning system)

The wheels of your vehicle are equipped with tire pressure warning valves and transmitters that allow the tire pressure warning system to provide advance warning in the event of a loss in tire inflation pressure. Whenever wheels are replaced, tire pressure warning valves and transmitters must be installed. $(\rightarrow P.558)$



A CAUTION

- When replacing wheels
 - Do not use wheels that are a different size from those recommended in the Owner's Manual, as this may result in a loss of handling control.
 - Never use an inner tube in a leaking wheel which is designed for a tubeless tire. Doing so may result in an accident, causing death or serious injury.

NOTICE


- Replacing tire pressure warning valves and transmitters (vehicles with the tire pressure warning system)
 - Because tire repair or replacement may affect the tire pressure warning valves and transmitters, make sure to have tires serviced by your Lexus dealer or other qualified service shop. In addition, make sure to purchase your tire pressure warning valves and transmitters at your Lexus dealer.
 - Ensure that only genuine Lexus wheels are used on your vehicle. Tire pressure warning valves and transmitters may not work properly with nongenuine wheels.

Air conditioning filter


The air conditioning filter must be changed regularly to maintain air conditioning efficiency.

Removal method

- Front air conditioning filter
 - Set the air conditioning system to recirculated air mode. (→P. 428)
 The air conditioning filter case cannot be removed with the system in outside air mode.
 - **2** Turn the engine switch off.
 - 3 Open the glove box. Remove the partition. $(\rightarrow P.453)$
 - 4 Remove the filter cover.




5 Remove the filter case.




6

6 Remove the air conditioning filter from the filter case and replace it with a new one.

The "TUP" marks shown on the filter and the filter case should be pointing up.




- **7** Reset the air conditioning filter maintenance data. $(\rightarrow P. 574)$
- Rear air conditioning filter (if equipped)
 - 1 Turn the engine switch off.
 - 2 Open the trunk lid. Remove the filter cover.



Remove the air conditioning filter and replace it with a new one.

The "TUP" mark shown on the filter should be pointing up.



■ Checking interval

► Front air conditioning filter

Inspect and replace the air conditioning filter when a message is appeared on the multi-information display. In dusty areas or areas with heavy traffic flow, early replacement may be required.

▶ Rear air conditioning filter (if equipped)

Replace every 15000 km (9000 miles).

■ If air flow from the vents decreases dramatically

The filter may be clogged. Check the filter and replace if necessary.

■ After changing the front air conditioning filter

The front air conditioning filter maintenance data should be reset. Perform the following procedures:

- 1 Turn the engine switch to IGNITION ON mode.
- 2 Press and hold (on the air conditioning panel) for 4 seconds or more.

A buzzer will sound to indicate that the maintenance data has been successfully reset.

■ Rear air conditioning filter (if equipped)

If it is necessary to clean or replace the filter, contact your Lexus dealer.

■ Climate control seat filter (if equipped)

Filters are installed in the seats. When it is necessary to clean or replace the filters, contact your Lexus dealer.

تلفن شبانه روزی: 🕠

↑ NOTICE

■ When using the air conditioning system

Make sure that a filter is always installed.

Using the air conditioning system without a filter may cause damage to the system.

Electronic key battery

Replace the battery with a new one if it is depleted.

You will need the following items:

- Small Phillips-head screwdriver (type A only)
- Flathead screwdriver (type B only)
- Small flathead screwdriver
- Lithium battery CR1632

Replacing the battery


▶ Type A



2 Remove the cover.



3 Remove the battery cover bolts and remove the battery cover.



Remove the depleted battery.

Insert a new battery with the "+" terminal facing up.




▶ Type B

1 Take out the mechanical key.



2 Remove the cover.

To prevent damage to the key, cover the tip of the screwdriver with a rag.




3 Remove the depleted battery.

Insert a new battery with the "+" terminal facing up.



廢電池譜向收。*

*: Taiwan only



■ Use a CR1632 lithium battery

- Batteries can be purchased at your Lexus dealer, local electrical appliance shops or camera stores.
- Replace only with the same or equivalent type recommended by the manufacturer.
- Dispose of used batteries according to local laws.
- When the card key battery needs to be replaced (if equipped)

The battery for the card key is available only at Lexus dealers. Your Lexus dealer can replace the battery for you.

■ If the electronic key battery is depleted

The following symptoms may occur: • ٨٥ : تلفن شبانه روزی:

- The smart entry & start system and wireless remote control will not function properly.
- The operational range will be reduced.

A CAUTION

■ Removed battery and other parts

These parts are small and if swallowed by a child, they can cause choking. Keep away from children. Failure to do so could result in death or serious injury.

■ Lithium battery precautions

CAUTION

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE.

DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS

↑ NOTICE

For normal operation after replacing the battery

Observe the following precautions to prevent accidents:

- Always work with dry hands.
 Moisture may cause the battery to rust.
- Do not touch or move any other component inside the remote control.
- Do not bend either of the battery terminals.



تلفن شبانه روزی: ۱۵۸۰۲۹۸۸ - ۲۱

Checking and replacing fuses

If any of the electrical components do not operate, a fuse may have blown. If this happens, check and replace the fuses as necessary.


- 1 Turn the engine switch off.
- 2 Open the fuse box cover.
 - ► Engine compartment: type A fuse box (left-hand drive vehicles)

Remove the engine compartment cover $(\rightarrow P. 541)$ and push the tabs in and lift the lid off.




► Engine compartment: type A fuse box (right-hand drive vehicles)

Remove the engine compartment cover (\rightarrow P. 541) and push the tabs in and lift the lid off.



► Engine compartment (type B fuse box)

Remove the engine compartment cover (\rightarrow P. 541) and push the tab in and lift the lid off.



▶ Driver's side instrument panel Remove the lid.






CLY63BA068

► Passenger's side instrument panel

Remove the lid.




Remove the lid.



3 Remove the fuse with the pullout tool.

Only type A fuse can be removed using the pullout tool.



درو فارما

تلفن شبانه روزی: ۱۲۰۸۸۶۲۰۲۵ تلفن شبانه روزی: ۱۲۰۸۸۸۶۲۰۲۰

- 4 Check if the fuse is blown.
 - 1 Normal fuse
 - (2) Blown fuse

Type A and B:


Replace the blown fuse with a new fuse of an appropriate amperage rating. The amperage rating can be found on the fuse box lid.


Type C and D:

Contact your Lexus dealer.


▶ Type A













■ After a fuse is replaced

- If the lights do not turn on even after the fuse has been replaced, a bulb may need replacement. $(\rightarrow P. 584)$
- If the replaced fuse blows again, have the vehicle inspected by your Lexus dealer.

■ If there is an overload in a circuit

The fuses are designed to blow, protecting the wiring harness from damage.

A CAUTION

■To prevent system breakdowns and vehicle fire

Observe the following precautions.

Failure to do so may cause damage to the vehicle, and possibly a fire or injury.

- Never use a fuse of a higher amperage rating than that indicated, or use any other object in place of a fuse.
- Always use a genuine Lexus fuse or equivalent.
 Never replace a fuse with a wire, even as a temporary fix.
- Do not modify the fuses or fuse boxes.

تلفن شبانه روزی: NOTICE + ۲ \ − ۱۸۸۸۶۲ + ۱۵۸ این شبانه روزی:

■ Before replacing fuses

Have the cause of electrical overload determined and repaired by your Lexus dealer as soon as possible.

Light bulbs

You may replace the following bulbs by yourself. The difficulty level of replacement varies depending on the bulb. As there is a danger that components may be damaged, we recommend that replacement is carried out by your Lexus dealer.

Preparing for light bulb replacement


Check the wattage of the light bulb to be replaced. $(\rightarrow P. 664)$



تلفن شبانه روزى: ۱۵۸۰۲۹۸۸۸–۲۱

Bulb locations

► Vehicles with discharge headlights




- 1 Headlight high beams or high beam/near-infrared ray transmitters
- 2 Rear fog lights (if equipped)
 - ▶ Vehicles with LED headlights



Replacing light bulbs


- Headlight high beams or high beam/near-infrared ray transmitters (vehicles with discharge headlights)
 - \blacksquare Remove the engine compartment covers. (\rightarrow P. 541)
 - **2** Before replacing the bulbs:
 - ▶ I eft side

Remove the securing bolt, and remove the washer fluid filler opening.




▶ Right side


Remove the securing bolts and nut, and move the fuse block.



Turn the cover counterclockwise and remove it.



Turn the bulb base counter-clockwise.




Remove the light bulb.




6 Replace the light bulb, and install the bulb base.

Align the 3 tabs on the light bulb with the mounting, and insert.



7 Turn and secure the bulb base.

Shake the bulb base gently to check that it is not loose, turn the headlights on once and visually confirm that no light is leaking through the mounting.



8 Install the cover and turn it clockwise.




- 9 Install by performing the reverse of 2.
- 10 Install the engine compartment covers.

■ Rear fog lights (if equipped)

1 Open the trunk lid and remove the cover.



2 Turn the bulb base counterclockwise.



Remove the light bulb.



4 When installing, reverse the steps listed.

■ Replacing the following bulbs

If any of the lights listed below has burnt out, have it replaced by your Lexus dealer.

- Front position lights and daytime running lights
- Front turn signal lights
- Front fog lights
- Side turn signal lights
- Outer foot lights
- Tail lights
- Stop lights
- Back-up lights
- Rear turn signal lights
- High mounted stoplight
- License plate lights
- ▶ Vehicles with discharge headlights
- Headlight low/high beams
- ► Vehicles with LED headlights
- Headlight low beams
- Headlight low/high beams
- Headlight high beams (vehicles without near-infrared ray transmitters)

■ Discharge headlights (if equipped)

If voltage to the discharge bulbs is insufficient, the bulbs may not come on, or may go out temporarily. The discharge bulbs will come on when normal power is restored.

■ LED light bulbs

The lights other than the headlight low/high beams (vehicles with discharge headlights), high beams or high beam/near-infrared ray transmitters (vehicles with discharge headlights), and rear fog lights (if equipped) each consist of a number of LEDs. If any of the LEDs burn out, take your vehicle to your Lexus dealer to have the light replaced.

Condensation build-up on the inside of the lens

Temporary condensation build-up on the inside of the headlight lens does not indicate a malfunction. Contact your Lexus dealer for more information in the following situations:

- Large drops of water have built up on the inside of the lens.
- Water has built up inside the headlight.

A CAUTION

■ Replacing light bulbs

 Turn off the lights. Do not attempt to replace the bulb immediately after turning off the lights.

The bulbs become very hot and may cause burns.

- Do not touch the glass portion of the light bulb with bare hands. When it is unavoidable to hold the glass portion, use and hold with a clean dry cloth to avoid getting moisture and oils on the bulb.
 - Also, if the bulb is scratched or dropped, it may blow out or crack.
- Fully install light bulbs and any parts used to secure them. Failure to do so may result in heat damage, fire, or water entering the headlight unit. This may damage the headlights or cause condensation to build up on the lens.

A CAUTION

- Discharge headlights (if equipped)
 - Contact your Lexus dealer before replacing the discharge headlights (including light bulbs).
 - Do not touch the discharge headlight's high voltage socket when the headlights are turned on.
 - An extremely high voltage of $30000\ V$ will be discharged and could result in death or serious injury by electric shock.
 - Do not attempt to take apart or repair the headlight bulbs, connectors, power supply circuits, or related components.
 Doing so could result in electric shock and death or serious injury.
- ■To prevent damage or fire
 - Make sure bulbs are fully seated and locked.
 - Check the wattage of the bulb before installing to prevent heat damage.

تلفن شبانه روزی: ۱-۸۸۸۶۲۰۸۵ تلفن شبانه روزی:

7-1.	Essential information
	Emergency flashers594
	If your vehicle has to be
	stopped in an
	emergency595
7-2.	Steps to take in an
	emergency
	If your vehicle needs to be towed596
	If you think something is
1 1	wrong603
6/19 9/79	Fuel pump shut off system604
	If a warning light turns on
	or a warning
	buzzer sounds605
·	If a warning message is displayed614
	If you have a flat tire618
FarmaSOS	If the engine will not start 627
	If the parking brake
	cannot be released629
	If the electronic key does not operate properly
	If the vehicle battery is
	discharged636
	If your vehicle overheats641
	If the vehicle becomes
	stuck645


Emergency flashers

The emergency flashers are used to warn other drivers when the vehicle has to be stopped in the road due to a breakdown, etc.

Press the switch.

All the turn signals will flash.

To turn them off, press the switch once again.



■ Emergency flashers

If the emergency flashers are used for a long time while the engine is not operating, the battery may discharge.

تلفن شبانه روزى: ۱۵۸۰۲۰۸۸ - ۲۱

If your vehicle has to be stopped in an emergency

Only in an emergency, such as if it becomes impossible to stop the vehicle in the normal way, stop the vehicle using the following procedure:

- 1 Steadily step on the brake pedal with both feet and firmly depress it.

 Do not pump the brake pedal repeatedly as this will increase the effort required to slow the vehicle.
- 2 Shift the shift lever to N.
- ▶ If the shift lever is shifted to N
- **3** After slowing down, stop the vehicle in a safe place by the road.
- 4 Stop the engine.
- ▶ If the shift lever cannot be shifted to N
- **3** Keep depressing the brake pedal with both feet to reduce vehicle speed as much as possible.
- A To stop the engine, press and hold the engine switch for 2 consecutive seconds or more, or press it briefly 3 times or more in succession.



Press and hold for 2 seconds or more, or press briefly 3 times or more

CLY71BA001

5 Stop the vehicle in a safe place by the road.

A CAUTION

■ If the engine has to be turned off while driving

Power assist for the steering wheel will be lost, making the steering wheel heavier to turn. Decelerate as much as possible before turning off the engine.

If your vehicle needs to be towed

If towing is necessary, we recommend having your vehicle towed by your Lexus dealer or commercial towing service, using a wheel-lift type truck or flatbed truck.

Use a safety chain system for all towing, and abide by all state/provincial and local laws

Situations when it is necessary to contact dealers before towing

The following may indicate a problem with your transmission. Contact your Lexus dealer or commercial towing service before towing.

- The engine is running but the vehicle does not move.
- The vehicle makes an abnormal sound.

تلفن شبانه روزى: ۱۵۰ ۲۹۸۸۸ - ۲۱

Towing with a sling-type truck

Do not tow with a sling-type truck to prevent body damage.



Towing with a wheel-lift type truck

► From the front




▶ From the rear



Use a towing dolly under the rear Use a towing dolly under the front wheels.


Using a flatbed truck

If your vehicle is transported by a flatbed truck, it should be tied down at the locations shown in the illustration.



If you use chains or cables to tie down your vehicle, the angles shaded in black must be 45° .

Do not overly tighten the tie downs or the vehicle may be damaged.



Emergency towing


If a tow truck is not available in an emergency, your vehicle may be temporarily towed using cables or chains secured to the emergency towing eyelets. This should only be attempted on hard surfaced roads for at most 80 km (50 miles) at under 30 km/h (18 mph).

A driver must be in the vehicle to steer and operate the brakes. The vehicle's wheels, drive train, axles, steering and brakes must be in good condition.

Emergency towing procedure

- 1 Take out the towing eyelet. $(\rightarrow P. 619)$
- **2** Remove the eyelet cover using a flathead screwdriver.

To protect the bodywork, place a rag between the screwdriver and the vehicle body as shown in the illustration.




3 Insert the towing eyelet into the hole and tighten partially by hand.





Tighten down the towing eyelet securely using a wheel nut wrench or hard metal bar.

FarmaSOS.



- **5** Securely attach cables or chains to the towing eyelet. Take care not to damage the vehicle body.
- **6** Enter the vehicle being towed and start the engine.

 If the engine does not start, turn the engine switch to IGNITION ON mode.
- Shift the shift lever to N and release the parking brake. When the shift lever cannot be shifted: \rightarrow P. 267, 275

■ While towing

If the engine is not running, the power assist for the brakes and steering will not function, making steering and braking more difficult.

■ Wheel nut wrench

Wheel nut wrench is installed in trunk. $(\rightarrow P. 619)$



Observe the following precautions.

Failure to do so may result in death or serious injury.

■ When towing the vehicle

▶ 2WD models

Be sure to transport the vehicle with all four wheels raised off the ground. If the vehicle is towed with the tires contacting the ground, the drivetrain and related parts may be damaged or an accident may occur due to a change in direction of the vehicle.



FarmaSOS

A CAUTION

► AWD models

Be sure to transport the vehicle with all four wheels raised off the ground. If the vehicle is towed with the tires contacting the ground, the drivetrain or related parts may be damaged, the vehicle may fly off the truck.



■ While towing

- When towing using cables or chains, avoid sudden starts, etc. which place excessive stress on the towing eyelets, cables or chains. The towing eyelets, cables or chains may become damaged, broken debris may hit people, and cause serious damage.
- Do not turn the engine switch off.
 There is a possibility that the steering wheel is locked and cannot be operated.
- Installing towing eyelets to the vehicle

Make sure that towing eyelets are installed securely.

If not securely installed, towing eyelets may come loose during towing.

↑ NOTICE

- To prevent damage to the vehicle when towing using a wheel-lift type truck
 - Do not tow the vehicle from the rear when the engine switch is off. The steering lock mechanism is not strong enough to hold the front wheels straight.
 - When raising the vehicle, ensure adequate ground clearance for towing at the opposite end of the raised vehicle. Without adequate clearance, the vehicle could be damaged while being towed.
- To prevent damage to the vehicle when towing with a sling-type truck

Do not tow with a sling-type truck, either from the front or rear.

■ To prevent damage to the vehicle during emergency towing

Do not secure cables or chains to the suspension components.



تلفن شبانه روزی: ۱۳۵۰ ۱۳۹۸ - ۲۱ م

If you think something is wrong

If you notice any of the following symptoms, your vehicle probably needs adjustment or repair. Contact your Lexus dealer as soon as possible.

Visible symptoms

- Fluid leaks under the vehicle.
 (Water dripping from the air conditioning after use is normal.)
- Flat-looking tires or uneven tire wear
- Engine coolant temperature gauge needle continually points higher than normal.

Audible symptoms

- Changes in exhaust sound
- Excessive tire squeal when cornering
- Strange noises related to the suspension system
- Pinging or other noises related to the engine

Operational symptoms

- Engine missing, stumbling or running roughly
- Appreciable loss of power
- Vehicle pulls heavily to one side when braking
- Vehicle pulls heavily to one side when driving on a level road
- Loss of brake effectiveness, spongy feeling, pedal almost touches the floor

Fuel pump shut off system

To minimize the risk of fuel leakage when the engine stalls or when an airbag inflates upon collision, the fuel pump shut off system stops the supply of fuel to the engine.

Follow the procedure below to restart the engine after the system is activated.

- 1 Turn the engine switch to ACCESSORY mode or turn it off.
- **2** Restart the engine.



■ Before starting the engine

Inspect the ground under the vehicle.

If you find that fuel has leaked onto the ground, the fuel system has been damaged and is in need of repair. Do not restart the engine.

تلفن شبانه روزی: ۵۸ • ۲۹۸۸۸ – ۲۲

If a warning light turns on or a warning buzzer sounds

Calmly perform the following actions if any of the warning lights comes on or flashes. If a light comes on or flashes, but then goes off, this does not necessarily indicate a malfunction in the system. However, if this continues to occur, have the vehicle inspected by your Lexus dealer.

Stop the vehicle immediately. Continuing to drive the vehicle may be dangerous.

The following warning indicates a possible problem in the brake system. Immediately stop the vehicle in a safe place and contact your Lexus dealer.

Warning light	Warning light/Details	
	Brake system warning light (warning buzzer) Low brake fluid Malfunction in the electronically controlled brake system	

Stop the vehicle immediately.

The following warning indicates the possibility of damage to the vehicle that may lead to an accident. Immediately stop the vehicle in a safe place and contact your Lexus dealer.

Warning light	Warning light/Details	
<u>=</u>	Charging system warning light Indicates a malfunction in the vehicle's charging system	

Have the vehicle inspected by your Lexus dealer immediately.

Failure to investigate the cause of the following warnings may lead to the system operating abnormally and possibly cause an accident. Have the vehicle inspected by your Lexus dealer immediately.

	1./19 9.79 91 /.	
Warning light	Warning light/Details	
+	Malfunction indicator lamp Indicates a malfunction in: • The emission control system (on some models); • The electronic engine control system; • The electronic throttle control system; or • The electronic automatic transmission control system	
**	Indicates a malfunction in: The SRS airbag system; The front passenger occupant classification system (if equipped); The seat belt pretensioner system; or The active head restraints system	
(AB)	ABS warning light Indicates a malfunction in: • The ABS; or • The brake assist system	
©!	Electric power steering system warning light (warning buzzer) Indicates a malfunction in the EPS (Electric Power Steering) system	

Warning light	Warning light/Details
PCS (Flashes) (If equipped)	Pre-crash safety system warning light Indicates a malfunction in the pre-crash safety system The warning light will operate as follows, even when the system is not malfunctioning: • The light will flash quickly when the system is operating. (→P. 368) • The light will turn on when the pre-crash braking is disabled. (→P. 363, 370) • The light will turn on when the system cannot temporarily be used.
-	Slip indicator Indicates a malfunction in: • The VSC system; • The TRC system; • The ABS; or • The hill-start assist control system The light will flash when the VSC, the TRC, the ABS or the hill- start assist control system is operating. (→P. 362)
HOLD (Flashes)	Brake hold operated indicator Indicates a malfunction in the brake hold system
(Flashes)	Parking brake indicator Indicates a malfunction in the electric parking brake
	Brake system warning light Indicates a malfunction in: The electronically controlled brake system; or The electric parking brake

Follow the correction procedures.

After taking the specified steps to correct the suspected problem, check that the warning light goes off.

Warning light	Warning light/Details	Correction procedure
	Open door warning light (warning buzzer)*1 Indicates that a door or the trunk is not fully closed	Check that all the doors and the trunk are closed.
In the fuel gauge	Low fuel level warning light Indicates remaining fuel is approximately 13 L (3.4 gal., 2.8 Imp. gal.) or less	Refuel the vehicle.
4	Seat belt reminder light (warning buzzer)*2 Warns the driver and/or front passenger to fasten their seat belts	Fasten the seat belt. If the front passenger's seat is occupied, the front passenger's seat belt also needs to be fastened to make the warning light (warning buzzer) turn off.
A	Master warning light A buzzer sounds and the warning light comes on and flashes to indicate that the master warning system has detected a malfunction.	→P.614n

Warning light	Warning light/Details	Correction procedure
	Tire pressure warning light	
(!) (If equipped)	When the light comes on: Low tire inflation pressure such as • Natural causes (→P. 612) • Flat tire (→P. 618)	Adjust the tire inflation pressure (including the spare tire) to the specified level. The light will turn off after a few minutes. In case the light does not turn off even if the tire inflation pressure is adjusted, have the system checked by your Lexus dealer.
	When the light comes on after blinking for 1 minute: Malfunction in the tire pressure warning system (→P.612)	Have the system checked by your Lexus dealer.



*1: Open door warning buzzer:

The open door warning buzzer sounds to alert one or more of the doors is not fully closed (with the vehicle having reached a speed of 5 km/h [3 mph]).

- *2: Driver's and front passenger's seat belt buzzer:
 - ► For GCC countries*3, Yemen, Jordan, Lebanon and Syria

The driver's and front passenger's seat belt buzzer sounds to alert the driver and front passenger that his or her seat belt is not fastened. Once the engine switch is turned to IGNITION ON mode, the buzzer sounds for 6 seconds. If the vehicle reaches a speed of 20 km/h (12 mph), the buzzer sounds once. If the seat belt is still unfastened after 30 seconds, the buzzer will sound intermittently for 10 seconds. Then, if the seat belt is still unfastened, the buzzer will sound in a different tone for 20 more seconds.

Except for GCC countries *3, Yemen, Jordan, Lebanon and Syria

The driver's and front passenger's seat belt buzzer sounds to alert the driver and front passenger that his or her seat belt is not fastened. The buzzer sounds intermittently for 30 seconds after the vehicle reaches a speed of 20 km/h (12 mph). Then, if the seat belt is still unfastened, the buzzer will sound in a different tone for 90 more seconds.

*3: Saudi Arabia, Sultanate of Oman, Bahrain, United Arab Emirates, Qatar, Kuwait

■ Speed warning buzzer (if equipped)

The buzzer indicates that your vehicle speed reaches or exceeds 120 km/h (75 mph).

At this time, warning message will appear on the multi-information display. $(\rightarrow P.614)$

Front passenger detection sensor, seat belt reminder and warning buzzer

- If luggage is placed on the front passenger seat, the front passenger detection sensor may cause the warning light to flash and the warning buzzer to sound even if a passenger is not sitting in the seat.
- If a cushion is placed on the seat, the sensor may not detect a passenger, and the warning light may not operate properly.

■ Electric power steering system warning light (warning buzzer)

When the battery charge becomes insufficient of the voltage temporarily drops, the electric power steering system warning light may come on and the warning buzzer may sound.

■ If the malfunction indicator lamp comes on while driving (for Korea)

First check the following:

- Is the fuel tank empty? If it is, fill the fuel tank immediately.
- Is the fuel tank cap loose? If it is, tighten it securely.

The light will go off after several driving trips.

If the light does not go off even after several trips, contact your Lexus dealer as soon as possible.

تلفن شبانه روزی: ۱۸۵

■ If the malfunction indicator lamp comes on while driving (except for Korea)

For some models, the malfunction indicator lamp will come on if the fuel tank becomes completely empty. If the fuel tank is empty, refuel the vehicle immediately. The malfunction indicator lamp will go off after several trips.

If the malfunction indicator lamp does not go off, contact your Lexus dealer as soon as possible.

■ When the tire pressure warning light comes on (vehicles with the tire pressure warning system)

Carry out the following procedure after the tire temperature has lowered sufficiently.

- Check the tire inflation pressure and adjust it to the appropriate level.
- If the warning light does not go out after several minutes, check that the tire inflation pressure is at the specified level and carry out initialization.

The warning light may come on again if the above operations are conducted without first allowing the tire temperature to lower sufficiently.

■ The tire pressure warning light may come on due to natural causes (vehicles with the tire pressure warning system)

The tire pressure warning light may come on due to natural causes such as natural air leaks and tire inflation pressure changes caused by temperature. In this case, adjusting the tire inflation pressure will turn off the warning light (after a few minutes).

When a tire is replaced with a spare tire (vehicles with the tire pressure warning system)

The spare tire is also equipped with a tire pressure warning valve and transmitter. The tire pressure warning light will turn on if the tire inflation pressure of the spare tire is low. If a tire goes flat, the tire pressure warning light will not turn off even though the flat tire has been replaced with the spare tire.

Conditions that the tire pressure warning system may not function properly (vehicles with the tire pressure warning system)

 \rightarrow P. 561

If the tire pressure warning light frequently comes on after blinking for 1 minute (vehicles with the tire pressure warning system)

If the tire pressure warning light frequently comes on after blinking for 1 minute when the engine switch is turned to IGNITION ON mode, have it checked by your Lexus dealer.

■ Warning buzzer

In some cases, the buzzer may not be heard due to ambient noise or sounds from the audio system.

■ Customization (for GCC countries* and Yemen)

The vehicle speed linked seat belt reminder buzzer can be disabled. (Customizable features \rightarrow P. 678)

*: Saudi Arabia, Sultanate of Oman, Bahrain, United Arab Emirates, Qatar, Kuwait



A CAUTION

■ If both the ABS and the brake system warning lights remain on

Stop your vehicle in a safe place immediately and contact your Lexus dealer. The vehicle will become extremely unstable during braking, and the ABS system may fail, which could cause an accident resulting in death or serious injury.

■ When the electric power steering system warning light comes on

The steering wheel may become extremely heavy.

If the steering wheel becomes heavier than usual when operating, hold firmly and operate using more force than usual.

■ If the tire pressure warning light comes on (vehicles with the tire pressure warning system)

Be sure to observe the following precautions. Failure to do so could cause a loss of vehicle control and result in death or serious injury.

- As the tire inflation pressure may be low when this warning light is illuminated. stop your vehicle in a safe place as soon as possible and adjust the tire inflation pressure immediately.
- If the tire pressure warning light comes on even after tire inflation pressure adjustment, it is probable that you have a flat tire. Check the tires. If a tire is flat, change it with the spare tire and have the flat tire repaired by the nearest Lexus dealer.
- Avoid abrupt maneuvering and braking. If the vehicle tires deteriorate, you could lose control of the steering wheel or the brakes.
- If a blowout or sudden air leakage should occur (vehicles with the tire pressure warning system)

The tire pressure warning system may not activate immediately.



■ To ensure the tire pressure warning system operates properly (vehicles with the tire pressure warning system)

Do not install tires with different specifications or makers, as the tire pressure warning system may not operate properly.

If a warning message is displayed

The multi-information display shows warnings for system malfunctions, incorrectly performed operations, and messages that indicate a need for maintenance. When a message is shown, perform the correction procedure appropriate to the message.

- 1 Master warning light
 - The master warning light also comes on or flashes in order to indicate that a message is currently being displayed on the multi-information display.
- (2) Multi-information display



If any of the warning messages is shown again after the following actions have been performed, contact your Lexus dealer.



Messages and warnings

The warning lights and warning buzzers operate as follows depending on the content of the message. If a message indicates the need for inspection by a dealer, have the vehicle inspected by your Lexus dealer immediately.

A	System warn- ing light	Warning buzzer*	Warning
Remains on	_	Sounds	Indicates an important situation such as the malfunction of the system related to driving that may result in danger
_	Remains on or flashes	Sounds	Indicates an important situation such as the malfunction of the system shown on the multi-infor- mation display
Flashes	6 <u>7</u> 6	Sounds	Indicates a situation such as damage to the vehicle that may result in danger
Remains on	+ 7 <u>1</u> - 1	Does not sound	Indicates a condition such as a malfunction of electrical components and the need for maintenance
Flashes	Farm	Does not sound	Indicates a situation such as the incorrect performance of an operation and how to perform the operation correctly

^{*:} A buzzer sounds the first time a message is shown on the multi-information display.

■ Warning message in radar cruise mode (if equipped)

In the following cases, the warning message may not be displayed even if vehicle-to-vehicle distance decreases:

- When your vehicle and the vehicle ahead are traveling at the same speed or the vehicle ahead is traveling more quickly than your vehicle
- When the vehicle ahead is traveling at a very low speed
- Immediately after cruise control speed is set
- At the instant the accelerator pedal is depressed

■ The LKA (Lane-Keeping Assist) lane departure warning function (if equipped)

In the following cases, the warning message will not be displayed even if a lane line is crossed.

- When the vehicle speed deviates from the operating range of the LKA system functions
- When the lane lines cannot be recognized
- When the steering wheel is turned as far as necessary to cause the vehicle to change lanes

■ System warning lights

The master warning light does not come on or flash in the following cases. Instead, a separate system warning light will come on or flash along with the message shown on the multi-information display.


- Malfunction of the brake system
 The brake system warning light (red indicator) comes on. (→P. 605)
- ullet Malfunction of the electronically controlled brake system or electric parking brake The brake system warning light (yellow indicator) comes on. (\rightarrow P. 607)
- Malfunction of the ABS The ABS warning light comes on. (→P. 606)
- Malfunction of the charging system
 The charging system warning light comes on. (→P. 606)
- Indicates that a door or the trunk is not fully closed The open door warning light comes on. (→P. 608)
- ◆ High engine coolant temperature
 The needle of the engine coolant temperature gauge enters the red zone.
 (→P. 641)

■ When "Electrical equipment operation is limited" is shown

This message indicates that the battery is low. When the message is shown, operation of electrical equipment that uses a large amount of electric power, such as the air conditioning system, may be limited temporarily. This does not indicate a malfunction. Operation of electrical equipment will be restored after the battery is charged.

■ Warning buzzer

In some cases, the buzzer may not be heard due to ambient noise or sounds from the audio system.



If you have a flat tire

Your vehicle is equipped with a spare tire. The flat tire can be replaced with the spare tire.

For details about tires: \rightarrow P. 556

A CAUTION

■ If you have a flat tire

Do not continue driving with a flat tire.

Driving even a short distance with a flat tire can damage the tire and the wheel beyond repair, which could result in an accident.


Before jacking up the vehicle

- Stop the vehicle in a safe place on a hard, flat surface.
- Set the parking brake.
- The shift lever to P. ۱۹۶۲ + ۱۵ : دوزی: Shift the shift lever to P. ۱۹۶۲ + ۱۵ الفن شبانه روزی:
- Stop the engine.
- Turn on the emergency flashers. $(\rightarrow P. 594)$

7

When trouble arises

Location of the spare tire, jack and tools



- 1 Parking brake release tool
- 2 Jack handle
- 3 Wheel nut wrench
- (4) Jack

- (5) Tools
- 6 Screwdriver
- 7) Spare tire
- 8 Towing eyelet

A CAUTION

■Using the tire jack

Observe the following precautions.

Improper use of the tire jack may cause the vehicle to suddenly fall off the jack, leading to death or serious injury.

- Do not use the tire jack for any purpose other than replacing tires or installing and removing tire chains.
- Only use the tire jack that comes with this vehicle for replacing a flat tire.
 Do not use it on other vehicles, and do not use other tire jacks for replacing tires on this vehicle.
- Put the jack properly in its jack point.
- Do not put any part of your body under the vehicle while it is supported by the jack.
- Do not start the engine or drive the vehicle while the vehicle is supported by the jack.
- Do not raise the vehicle while someone is inside.
- When raising the vehicle, do not put an object on or under the jack.
- Do not raise the vehicle to a height greater than that required to replace the tire.
- Use a jack stand if it is necessary to get under the vehicle.
- Vehicles with electronically modulated air suspension: Be sure to turn off the height control and stop the engine.
- When lowering the vehicle, make sure that there is no-one near the vehicle. If there are people nearby, warn them vocally before lowering.


_

Taking out the jack and jack handle

- Lift up the luggage mat and secure it by using the hook provided. $(\rightarrow P. 466)$
- **2** Remove the tool tray.




Remove the jack after removing the hook.



Taking out the spare tire

- 1 Lift up the luggage mat and secure it by using the hook provided. (→P. 466)
- **2** Loosen the center fastener that secures the spare tire.

If the center fastener cannot be turned by hand, use the wheel nut wrench that is stored in the trunk. (To secure the tire, tighten the center fastener by hand. Do not use the wrench or other tools.)



A CAUTION

■ When storing the spare tire

Be careful not to catch fingers or other body parts between the spare tire and the body of the vehicle.


Replacing a flat tire

1 Chock the tires.



	Flat tire	Wheel chock positions	
Front	Left-hand side	Behind the rear right-hand side tire	
	Right-hand side	Behind the rear left-hand side tire	
Rear	Left-hand side	In front of the front right-hand side tire	
	Right-hand side	In front of the front left-hand side tire	

2 Slightly loosen the wheel nuts (one turn).



3 Turn the tire jack portion "A" by hand until the notch of the jack is in contact with the jack point.

The jack point guides are located under the rocker panel. They indicate the jack point positions.

4 Raise the vehicle until the tire is slightly raised off the ground.







FarmaSOS.co

5 Remove all the wheel nuts and the tire.

When resting the tire on the ground, place the tire so that the wheel design faces up to avoid scratching the wheel surface.



6 Remove the wheel ornament by pushing from the reverse side.



A CAUTION

■ Replacing a flat tire

- Observe the following precautions. Failure to do so may result in serious injury:
 - Do not try to remove the wheel ornament by hand. Take due care in handling the ornament to avoid unexpected personal injury.
 - Do not touch the disc wheels or the area around the brakes immediately after the vehicle has been driven.
 - After the vehicle has been driven the disc wheels and the area around the brakes will be extremely hot. Touching these areas with hands, feet or other body parts while changing a tire, etc. may result in burns.
- Failure to follow these precautions could cause the wheel nuts to loosen and the tire to fall off, resulting in death or serious injury.
 - Never use oil or grease on the wheel bolts or wheel nuts. Oil and grease may cause the wheel nuts to be excessively tightened, leading to bolt or disc wheel damage. In addition, the oil or grease can cause the wheel nuts to loosen and the wheel may fall off, causing a serious accident. Remove any oil or grease from the wheel bolts or wheel nuts.
 - Have the wheel nuts tightened with a torque wrench to 140 N·m (14.3 kgf·m, 103 ft•lbf) as soon as possible after changing wheels.
 - Do not attach a heavily damaged wheel ornament, as it may fly off the wheel while the vehicle is moving.
 - When installing a tire, only use wheel nuts that have been specifically designed for that wheel.
 - If there are any cracks or deformations in the bolt screws, nut threads or bolt holes of the wheel, have the vehicle inspected by your Lexus dealer.


Installing the spare tire


1 Remove any dirt or foreign matter from the wheel contact surface.

If foreign matter is on the wheel contact surface, the wheel nuts may loosen while the vehicle is in motion, causing the tire to come off.

Install the spare tire and loosely tighten each wheel nut by hand by approximately the same amount.

Turn the wheel nuts until the washers come into contact with the disc wheel.







3 Lower the vehicle.



FarmaS




Tightening torque: 140 N·m (14.3 kgf·m, 103 ft·lbf)





5 Reinstall the wheel ornament.



6 Stow the flat tire, tire jack and all tools.

A CAUTION

■ After using the tools and jack

Before driving, make sure all the tools and jack are securely in place in their storage location to reduce the possibility of personal injury during a collision or sudden braking.

♠ NOTICE

■ When replacing the tires (vehicles with the tire pressure warning system)

When removing or fitting the wheels, tires or the tire pressure warning valve and transmitter, contact your Lexus dealer as the tire pressure warning valve and transmitter may be damaged if not handled correctly.

■ To avoid damage to the tire pressure warning valves and transmitters (vehicles with the tire pressure warning system)

When a tire is repaired with liquid sealants, the tire pressure warning valve and transmitter may not operate properly. If a liquid sealant is used, contact your Lexus dealer or other qualified service shop as soon as possible. Make sure to replace the tire pressure warning valve and transmitter when replacing the tire. $(\rightarrow P.558)$

If the engine will not start

If the engine will not start even though correct starting procedures are being followed (\rightarrow P. 259), consider each of the following points:

The engine will not start even though the starter motor operates normally.

One of the following may be the cause of the problem:

- There may not be sufficient fuel in the vehicle's tank.
 Refuel the vehicle.
- The engine may be flooded.
 Try to restart the engine again following correct starting procedures.
 (→P. 259)
- There may be a malfunction in the engine immobilizer system. $(\rightarrow P.104)$

The starter motor turns over slowly, the interior lights and headlights are dim, or the horn does not sound or sounds at a low volume.

One of the following may be the cause of the problem:

- The battery may be discharged. (\rightarrow P. 636)
- The battery terminal connections may be loose or corroded.

The starter motor does not turn over

The engine starting system may be malfunctioning due to an electrical problem such as electronic key battery depletion or a blown fuse. However, an interim measure is available to start the engine. $(\rightarrow P. 627)$

The starter motor does not turn over, the interior lights and headlights do not turn on, or the horn does not sound.

One of the following may be the cause of the problem:

- One or both of the battery terminals may be disconnected.
- The battery may be discharged. $(\rightarrow P. 636)$
- There may be a malfunction in the steering lock system.

Contact your Lexus dealer if the problem cannot be repaired, or if repair procedures are unknown.

Emergency start function

When the engine does not start, the following steps can be used as an interim measure to start the engine if the engine switch is functioning normally:

- 1 Turn the engine switch to IGNITION ON mode (\rightarrow P. 260) and check that the parking brake is set.
- تلفن شبانه روزی: Shift the shift lever to P. ۱۹۹۸ ۲۰۸۵ تلفن شبانه روزی:
- **3** Turn the engine switch to ACCESSORY mode.
- Press and hold the engine switch for about 15 seconds while depressing the brake pedal firmly.

Even if the engine can be started using the above steps, the system may be malfunctioning. Have the vehicle inspected by your Lexus dealer.

If the parking brake cannot be released

In the event that the battery is discharged or switch operation does not release the parking brake, the parking brake can be released manually using the procedure below. This procedure should be performed only if necessary, such as in an emergency.


If the switch cannot be operated even when the battery is normal, the parking brake system may be malfunctioning. Have the vehicle inspected by your Lexus dealer immediately.

Before releasing the parking brake manually

- Shift the shift lever to P.
- Turn the engine switch off.
- Check that the parking brake indicator is off
- Chock the tires.


Releasing the parking brake manually تلفن شبانه روزي

- Take out the parking brake release tool and the screwdriver from the trunk. $(\rightarrow P. 619)$
- **2** Replace the screwdriver head with the parking brake release tool.




3 Take out the spare tire. $(\rightarrow P. 622)$

4 Remove the plug.



5 Insert the tool and press it down firmly while turning it counterclockwise until it stops.



■ Manual operation of the parking brake

The parking brake cannot be set manually \ الفن شبانه روزى على المالية الم

A CAUTION

- When releasing the parking brake manually
 - Shift the shift lever to P, turn the engine switch off and chock the tires. Failure to do so may cause the vehicle to move, resulting in an accident.
 - Turn the engine switch off and check that the parking brake indicator is off.
 Failure to do so may cause the system to operate and turn the inserted parking brake release tool, resulting in an injury.

If the electronic key does not operate properly

If communication between the electronic key and vehicle is interrupted (\rightarrow P. 163) or the electronic key cannot be used because the battery is depleted, the smart entry & start system and wireless remote control cannot be used. In such cases, the doors and trunk can be opened and the engine can be started by following the procedure below.

Locking and unlocking the doors, unlocking the trunk and key linked functions


Use the mechanical key built in to the electronic keys to operate the doors. $(\rightarrow P. 145)$

On some models: An alarm will sound if the alarm is set when the trunk or doors are unlocked. $(\rightarrow P. 112)$

Doors

1 Remove the cover on the driver's door handle.






- **2** Locks and unlocks the doors
 - 1 Locks all the doors
 - 2) Closes the windows and moon roof*1 (turn and hold)
 - (3) Unlocks the door*2

Turning the key rearward unlocks the driver's door. Turning the key once again unlocks the other doors.

Unlocks all doors*3

- (4) Opens the windows and moon roof*1 (turn and hold)
- *1: If equipped
- *2: For USF40L-AEZGHA, USF45L-AEZGHA, USF41L-AEZGHA,USF40L-AEZGHV, USF41L-AEZGHV and USF41L-AEZGKV models
- *3: Except for USF40L-AEZGHA, USF45L-AEZGHA, USF41L-AEZGHA,USF40L-AEZGHV, USF41L-AEZGHV and USF41L-AEZGKV models


The model code is indicated on the manufacturer's label. $(\rightarrow P. 650)$



3 After the operation is completed, reinstall the cover.


Hook the upper claw of the cover onto the upper catch on the vehicle side, and then push on the lower side of the cover

Make sure that the lower claw of the cover is securely fastened to the lower catch on the vehicle side. If the cover is not securely attached, it may fall off while driving.



■ Trunk

Turn the mechanical key clockwise to open.



Starting the engine

- 1 Ensure that the shift lever is in P and depress the brake pedal.
- **2** Touch the Lexus emblem side of the electronic key to the engine switch.

If any of the doors is opened or closed after the key was touched to the switch to start the vehicle, an alarm will sound to indicate that the start function cannot detect the key.



Press the engine switch within 10 seconds of the buzzer sounding, keeping the brake pedal depressed.

In the event that the engine still cannot be started, contact your Lexus dealer.

■ Stopping the engine

Shift the shift lever to P and press the engine switch as you normally do when stopping the engine.

■ Replacing the key battery

As the above procedure is a temporary measure, it is recommended that the electronic key battery be replaced immediately when the battery is depleted. $(\rightarrow P. 575)$

■ Alarm (on some models)

Using the mechanical key to lock the doors will not set the alarm system. If a door is unlocked using the mechanical key when the alarm system is set, the alarm may be triggered.

■ Changing engine switch modes

Within 10 seconds of the buzzer sounding, release the brake pedal and press the engine switch.

The engine does not start and modes will be changed each time the switch is pressed. $(\rightarrow P.260)$

A CAUTION

■ When using the mechanical key and operating the power windows or moon roof

Operate the power window or moon roof after checking to make sure that there is no possibility of any passenger having any of their body parts caught in the window or moon roof.

Also, do not allow children to operate the mechanical key. It is possible for children and other passengers to get caught in the power window or moon roof.



تلفن شبانه روزی: ۵۸ + ۲۹۸۸۸-۲۲ •

If the vehicle battery is discharged


The following procedures may be used to start the engine if the vehicle's battery is discharged.

You can also call your Lexus dealer or a qualified repair shop.

If you have a set of jumper (or booster) cables and a second vehicle with a 12-volt battery, you can jump start your vehicle by following the steps below


1 Confirm that the electronic key is being carried.

When connecting the jumper (or booster) cables, depending on the situation, the alarm may activate and doors locked. $(\rightarrow P. 114)$




2 Open the hood. Remove the engine compartment covers and battery cover. (→P. 536, 541, 543)

- **3** Connect the jumper cables according to the following procedure:
- ▶ Left-hand drive vehicles



▶ Right-hand drive vehicles



- (1) Connect a positive jumper cable clamp to the positive (+) battery terminal on your vehicle.
- (2) Connect the clamp on the other end of the positive cable to the positive (+) battery terminal on the second vehicle.
- (3) Connect a negative cable clamp to the negative (-) battery terminal on the second vehicle.
- (4) Connect the clamp at the other end of the negative cable to a solid, stationary, unpainted metallic point away from the battery and any moving parts, as shown in the illustration.

- 4 Start the engine of the second vehicle. Increase the engine speed slightly and maintain at that level for approximately 5 minutes to recharge the battery of your vehicle.
- **5** Open and close any of the doors of your vehicle with the engine switch off
- 6 Maintain the engine speed of the second vehicle and start the engine of your vehicle by turning the engine switch to IGNITION ON mode.
- Once the vehicle's engine has started, remove the jumper cables in the exact reverse order from which they were connected.

Once the engine starts, have the vehicle inspected at your Lexus dealer as soon as possible.

امداد خودرو فارما

تلفن شبانه روزی: ۱-۸۸۸۶۲ ۲۸ ا

■ Starting the engine when the battery is discharged

The engine cannot be started by push-starting.

■ To prevent battery discharge

- Turn off the headlights and the audio system while the engine is off.
- Turn off any unnecessary electrical components when the vehicle is running at a low speed for an extended period, such as in heavy traffic.

■ Charging the battery

The electricity stored in the battery will discharge gradually even when the vehicle is not in use, due to natural discharge and the draining effects of certain electrical appliances. If the vehicle is left for a long time, the battery may discharge, and the engine may be unable to start. (The battery recharges automatically during driving.)

■ When recharging or replacing the battery

In some cases, it may not be possible to unlock the doors using the smart entry & start system when the battery is discharged. Use the wireless remote control or the mechanical key to lock or unlock the doors.

■ If the battery is discharged

The information stored in the computer will be deleted.

If the battery is discharged, have the vehicle inspected by your Lexus dealer.

تلفن شبانه روزى: ۱۵۸۸۶۲۰۸۵ ۲۱ م

A CAUTION

Avoiding battery fires or explosions

Observe the following precautions to prevent accidentally igniting the flammable gas that may be emitted from the battery:

- Make sure each jumper cable is connected to the correct terminal and that it is not unintentionally in contact with any other than the intended terminal.
- Do not allow the other end of the jumper cable connected to the "+" terminal to come into contact with any other parts or metal surfaces in the area, such as brackets or unpainted metal.
- Do not allow the + and clamps of the jumper cables to come into contact with each other.
- Do not smoke, use matches, cigarette lighters or allow open flame near the battery.

■ Battery precautions

The battery contains poisonous and corrosive acidic electrolyte, while related parts contain lead and lead compounds. Observe the following precautions when handling the battery:

- When working with the battery, always wear safety glasses and take care not to allow any battery fluids (acid) to come into contact with skin, clothing or the vehicle body.
- Do not lean over the battery.
- In the event that battery fluid comes into contact with the skin or eyes, immediately wash the affected area with water and seek medical attention.
 Place a wet sponge or cloth over the affected area until medical attention can be received.
- Always wash your hands after handling the battery support, terminals, and other battery-related parts.
- Do not allow children near the battery.

■ When handling jumper cables

When connecting the jumper cables, ensure that they do not become entangled in the cooling fans or engine drive belt.

If your vehicle overheats

The following may indicate that your vehicle is overheating.

- The needle of the engine coolant temperature gauge (\rightarrow P. 125) enters the red zone or a loss of engine power is experienced. (For example, the vehicle speed does not increase.)
- Steam comes out from under the hood.


Correction procedures

- 1 Stop the vehicle in a safe place and turn off the air conditioning system, and then stop the engine.
- **2** If you see steam: Carefully lift the hood after the steam subsides. If you do not see steam: Carefully lift the hood.
- 3 After the engine has cooled down sufficiently, inspect the hoses and radiator core (radiator) for any leaks.
 - 1 Radiator
 - (2) Cooling fans

If a large amount of coolant leaks, immediately contact your Lexus dealer.





- The coolant level is satisfactory if it is between the "FULL" and "LOW" lines on the reservoir.
 - (1) Reservoir
 - ② "FULL"
 - (3) "LOW"



Water can be used in an emergency if coolant is unavailable.

FarmaS₀





7

6 Start the engine and turn the air conditioning system on to check that the radiator cooling fan operates and to check for coolant leaks from the radiator or hoses.

The fan operates when the air conditioning system is turned on immediately after a cold start. Confirm that the fan is operating by checking the fan sound and air flow. If it is difficult to check these, turn the air conditioning system on and off repeatedly.

(The fan may not operate in freezing temperatures.)

7 If the fan is not operating:

Stop the engine immediately and contact your Lexus dealer.

If the fan is operating:

Have the vehicle inspected at the nearest Lexus dealer.






A CAUTION

■ When inspecting under the hood of your vehicle

Observe the following precautions.

Failure to do so may result in serious injury such as burns.

- If steam is seen coming from under the hood, do not open the hood until the steam has subsided. The engine compartment may be very hot.
- Keep hands and clothing (especially a tie, a scarf or a muffler) away from the fans and belts. Failure to do so may cause the hands or clothing to be caught, resulting in serious injury.
- Do not loosen the coolant reservoir cap while the engine and radiator are hot.
 High temperature steam or coolant could spray out.



♠ NOTICE

■ When adding engine coolant

Add coolant slowly after the engine has cooled down sufficiently. Adding cool coolant to a hot engine too quickly can cause damage to the engine.

■ To prevent damage to the cooling system

Observe the following precautions:

- Avoid contaminating the coolant with foreign matter (such as sand or dust etc.).
- Do not use any coolant additive.

If the vehicle becomes stuck


Carry out the following procedures if the tires spin or the vehicle becomes stuck in mud, dirt or snow:

- \blacksquare Stop the engine. Set the parking brake and shift the shift lever to P.
- **2** Remove the mud, snow or sand from around the rear wheels.
- 3 Place wood, stones or some other material under the rear wheels to help provide traction.
- 4 Restart the engine.
- **5** Shift the shift lever to D or R and release the parking brake. Then, while exercising caution, depress the accelerator pedal.
- When it is difficult to free the vehicle

Press at to turn off TRC.

+ 71-11157+12

FarmaSO:





■ When attempting to free a stuck vehicle

If you choose to push the vehicle back and forth to free it, make sure the surrounding area is clear to avoid striking other vehicles, objects or people. The vehicle may also lunge forward or lunge back suddenly as it becomes free. Use extreme caution.

■ When shifting the shift lever

Be careful not to shift the shift lever with the accelerator pedal depressed. This may lead to unexpected rapid acceleration of the vehicle that may cause an accident resulting in death or serious injury.

↑ NOTICE

■ To avoid damaging the transmission and other components

- Avoid spinning the rear wheels and depressing the accelerator pedal more than necessary.
- If the vehicle remains stuck even after these procedures are performed, the vehicle may require towing to be freed.

تلفن شبانه روزی: ۱۵۸۰ ۲۹۸۸ – ۲۱

8-1.	Specifications	
	Maintenance data	
	(fuel, oil level, etc.)	648
	Fuel information	665
8-2.	Customization	
	Customizable features	667



تلفن شبانه روزی: ۱۳۵۰ ۲۹۸۸ - ۲۲ م

Maintenance data (fuel, oil level, etc.)

Dimensions and weights

▶ Dimensions

Overall length		LS460	5090 mm (200.4 in.)
		LS460L	5210 mm (205.1 in.)
Overall width			1875 mm (73.8 in.)
Overall height*1		2WD models	1475 mm (58.1 in.)*2 1465 mm (57.7 in.)*3 1455 mm (57.3 in.)*4
Overall fleight	1 16	AWD models	1480 mm (58.3 in.)*2 1465 mm (57.7 in.)*3 1455 mm (57.3 in.)*4
Wheelbase	U) U	LS460	2970 mm (116.9 in.)
vv neeibase		LS460L	3090 mm (121.7 in.)
	+ Front		1615 mm (63.6 in.)*5 1610 mm (63.4 in.)*6
Tread	FRear	2WD models	1620 mm (63.8 in.)*5 1615 mm (63.6 in.)*6
		AWD models	1615 mm (63.6 in.)*5 1610 mm (63.4 in.)*6

▶ Weights

	LS460	2WD models	2455 kg (5412 lb.)
		AWD models	2575 kg (5677 lb.)
Gross vehicle mass	LS460L	2WD models	2430 kg (5357 lb.)* ⁷ 2495 kg (5501 lb.)* ⁸
		AWD models	2560 kg (5644 lb.)* ⁷ 2625 kg (5787 lb.)* ⁸
Maximum permissible axle capacity	Front	2WD models	1235 kg (2723 lb.)
		AWD models	1385 kg (3053 lb.)
	Rear	2WD models	1365 kg (3009 lb.)
		AWD models	1385 kg (3053 lb.)

^{*1:} Unladen vehicles ۲۱ – ۱. Unladen vehicles ۲۱ – ۱. Unladen vehicles ۲۱ باتان شبانه روزی:

^{*2:} Without electronically modulated air suspension

^{*3:} Vehicles with electronically modulated air suspension but without paddle shift switches

^{*4:} Vehicles with electronically modulated air suspension and paddle shift switches

^{*5:} With 18-inch tires

^{*6:} With 19-inch tires

^{*7}: 4-seat models


^{*8: 5-}seat models

Vehicle identification

■ Vehicle identification number

The vehicle identification number (VIN) is the legal identifier for your vehicle. This is the primary identification number for your Lexus. It is used in registering the ownership of your vehicle.

This number is stamped on the top left of the instrument panel and in the engine compartment.



This number is also on the Certification Regulation label*¹ or the manufacturer's label*².



- *1: For Korea, GCC countries*3, Yemen and Lebanon
- *2: Except for Korea, GCC countries*3, Yemen and Lebanon
- *3: Saudi Arabia, Sultanate of Oman, Bahrain, United Arab Emirates, Qatar, Kuwait

■ Year of manufacture and country of origin (GCC countries*, Yemen and Lebanon)

The year of the manufacture and country of origin are shown on the Certification Regulation label.

*: Saudi Arabia. Sultanate of Oman, Bahrain, United Arab Emirates, Qatar, Kuwait

■ Engine number

▶ 2WD models

The engine number is stamped on the engine block as shown.





▶ AWD models

The engine number is stamped (stamped) on the engine block as shown.



Engine

Model	1UR-FSE	1UR-FE
Туре	8-cylinder V type, 4-cycle,	, gasoline
Bore and stroke	94.0 × 83.0 mm (3.70 × 3	3.27 in.)
Displacement	4608 cm ³ (281.2 cu. in.)	
Valve clearance (engine cold)	Automatic adjustment	
Drive belt tension	Automatic adjustment	
Maximum vehicle speed*1	250 km/h (155 mph)	
Maximum torque (NET)*1	493 N·m@4100 rpm	455 N·m@4000 rpm
Maximum power (NET)*1	285 kW@6400 rpm	260 kW@6400 rpm

 $^{^{*1}}$: For vehicles with model code *2 that has "V" as the last letter

تلفن شانه روزی: ۵۸۸۶۲ مالک در الفن شانه روزی: ۵۸۸۶۲ مالک ا

Fuel

Fuel type		Premium unleaded gasoline only
Research Octane	For Brazil	95 (Octane rating 91) or higher
Number	Except for Brazil	95 or higher
Fuel tank capacity (Reference)		84 L (22.2 gal., 18.4 Imp. gal.)

^{*2:} The model code is indicated on the manufacturer's label or the Certification Regulation label. $(\rightarrow P. 650)$

Lubrication system

Oil capacity (Drain and refill—reference*)	
With filter	
2WD models	8.6 L (9.1 qt., 7.6 lmp. qt.)
AWD models	9.0 L (9.5 qt., 7.9 lmp. qt.)
Without filter	8.4 L (8.9 qt., 7.4 lmp. qt.)

^{*:} The engine oil capacity is a reference quantity to be used when changing the engine oil. Warm up and turn off the engine, wait more than 5 minutes, and check the oil level on the dipstick.

■ Engine oil selection

"Toyota Genuine Motor Oil" is used in your Lexus vehicle. Use Lexus approved "Toyota Genuine Motor Oil" or equivalent to satisfy the following grade and viscosity.

Oil arade:

0W-20, 5W-20, 5W-30 and 10W-30:


API grade SL "Energy-Conserving", SM "Energy-Conserving" or SN "Resource-Conserving"; or ILSAC multigrade engine oil

15W-40:

API grade SL, SM or SN multigrade engine oil

Recommended viscosity (SAE):

If you use SAE 10W-30 or a higher viscosity engine oil in extremely low temperatures, the engine may become difficult to start, so SAE 0W-20, 5W-20 or 5W-30 engine oil is recommended



Oil viscosity (OW-20 is explained here as an example):

- The OW in OW-20 indicates the characteristic of the oil which allows cold startability. Oils with a lower value before the W allow for easier starting of the engine in cold weather.
- The 20 in OW-20 indicates the viscosity characteristic of the oil when the oil is at high temperature. An oil with a higher viscosity (one with a higher value) may be better suited if the vehicle is operated at high speeds, or under extreme load conditions.

Either or both API registered marks are added to some oil containers to help you select the oil you should use.

1) API Service Symbol


Top portion: "API SERVICE SN" means the oil quality designation by American Petroleum Institute (API).

Center portion: "SAE OW-20" means the SAE viscosity grade.

Lower portion: "Resource-Conserving" means that the oil has fuel-saving and environmental protection capabilities.



The International Lubricant Specification Advisory Committee (ILSAC) Certification Mark is displayed on the front of the container.







Cooling system

Capacity	2WD models	11.0 L (11.6 qt., 9.7 lmp. qt.)*1 11.8 L (12.5 qt., 10.4 lmp. qt.)*2
Capacity	AWD models	11.1 L (11.7 qt., 9.8 Imp. qt.)
Coolant type		Use either of the following: • "Toyota Super Long Life Coolant" • Similar high-quality ethylene glycol-based non-silicate, non-amine, non-nitrite, and non-borate coolant with long-life hybrid organic acid technology Do not use plain water alone.

^{*1:} For the Philippines, Vietnam, Hong Kong, Thailand, Singapore, Malaysia, the Republic of Indonesia, Brunei, Macao, Taiwan and Korea

Ignition system

Model	+ 7 1 - 1	1UR-FSE	1UR-FE
Spark plug		(3))	
Make		DENSO FK20HBR11	DENSO SK20HR11
Gap	Fari	1.1 mm (0.043 in.)	1.1 mm (0.043 in.)

⚠ NOTICE

■ Iridium-tipped spark plugs

Use only iridium-tipped spark plugs. Do not adjust the spark plug gap.

^{*2:} For countries other than those listed above

Electrical system

Battery	
Specific gravity reading at 20°C (68°F):	1.25 or higher If the specific gravity is lower than the standard value, charge the battery.
Charging rates Quick charge Slow charge	15 A max. 5 A max.

Automatic transmission

Fluid	2WD models	10.3 L (10.9 qt., 9.1 lmp. qt.)
capacity*	AWD models	10.7 L (11.3 qt., 9.4 lmp. qt.)
Fluid type	476	Toyota Genuine ATF WS

تلفن شبانه روزي: ۸۵ •

↑ NOTICE

Automatic transmission fluid type SOS.com

Using transmission fluid other than "Toyota Genuine ATF WS" may cause deterioration in shift quality, locking up of your transmission accompanied by vibration, and ultimately damage the transmission of your vehicle.

^{*:} The fluid capacity is a reference quantity.

If replacement is necessary, contact your Lexus dealer.

Transfer (AWD models)

Oil capacity	0.70 L (0.74 qt., 0.62 lmp. qt.)
Oil type and viscosity*	Toyota Genuine Transfer gear oil LL 80 or equivalent

^{*:} Your Lexus vehicle is filled with Toyota genuine gear oil at the factory. Use Lexus approved Toyota genuine gear oil or an equivalent of matching quality to satisfy the above specification. Please contact your Lexus dealer for further details.

Front differential (AWD models)

Oil capacity	0.75 L (0.79 qt., 0.66 lmp. qt.)
Oil type and viscosity*	Toyota Genuine Differential gear oil LT 75W-85 GL-5 or equivalent

^{*:} Your Lexus vehicle is filled with "Toyota Genuine Differential Gear Oil" at the factory. Use Lexus approved "Toyota Genuine Differential Gear Oil" or an equivalent of matching quality to satisfy the above specification. Please contact your Lexus dealer for further details.

Rear differential

▶ 2WD models (vehicles without paddle shift switches)

Oil capacity	1.35 L (1.42 qt., 1.19 lmp. qt.)
Oil type and viscosity*	Toyota Genuine Differential gear oil LT 75W-85 GL-5 or equivalent

▶ 2WD models (vehicles with paddle shift switches) and AWD models

Oil capacity	1.35 L (1.42 qt., 1.19 lmp. qt.)
	Toyota Genuine Differential gear oil LX 75W-85 GL-5 or equivalent

^{*:} Your Lexus vehicle is filled with "Toyota Genuine Differential Gear Oil" at the factory. Use Lexus approved "Toyota Genuine Differential Gear Oil" or an equivalent of matching quality to satisfy the above specification. Please contact your Lexus dealer for further details.

Brakes

Pedal clearance*	147 mm (5.8 in.) Min.
Pedal free play	1.0 - 2.0 mm (0.04 - 0.08 in.)
Fluid type	SAE J1703 or FMVSS No.116 DOT 3 or, SAE J1704 or FMVSS No.116 DOT 4

^{*:} Minimum pedal clearance when depressed with a force of 500 N (51 kgf, 112 lbf) while the engine is running.

When performing the brake pedal inspection, also be sure to check that the brake system warning light is not illuminated when the engine is running (If the brake system warning light is illuminated, refer to P. 605).

Free play Less than 30 mm (1.2 in.)

تلفن شبانه روزی: ۱۵۸۰۲۹۸۸ - ۲۱

Tires and wheels (for Korea)

▶ 18-inch tires

Tire manufacturer	Bridgestone	Dunlop	Michelin	
Tire rolling resistance rating (5 levels)*	4	3	4	
Tire wet grip rating (5 levels)*	3	3	3	
Tire size	P235/50R18 97\	/		
Tire inflation pressure (Recommended cold tire inflation pressure)	Driving under normal conditions Front: 230 kPa (2.3 kgf/cm ² or bar, 33 psi) Rear: 230 kPa (2.3 kgf/cm ² or bar, 33 psi) Driving at high speeds above 160 km/h (100 mph) (in countries where such speeds are permitted by law)			
Wheel size	18 × 7 1/2J			
Wheel nut torque	140 N•m (14.3 kgf	m, 103 ft•lbf) تلفن		

^{*:} A rating closer to "1" indicates higher performance.

Tire manufacturer	Bridgestone	Dunlop	Michelin	
Tire rolling resistance rating (5 levels)*	5	4	4	
Tire wet grip rating (5 levels)*	3	3	3	
Tire size	P245/45R19 98V			
Tire inflation pressure (Recommended cold tire inflation pressure)	Rear: 230 kPa (2 Driving at high spo countries where su Add 50 kPa (0.5 and rear tires. N	nal conditions 2.3 kgf/cm ² or bar, 2.3 kgf/cm ² or bar, eeds above 160 kn ch speeds are perm 5 kgf/cm ² or bar, 8 p Never exceed the reindicated on the tir	33 psi) n/h (100 mph) (in itted by law) osi) to the front tires naximum cold tire	
Wheel size	19 × 8J	וטעול		
Wheel nut torque	140 N·m (14.3 kgf·m, 103 ft·lbf)			

^{*:} A rating closer to "1" indicates higher performance.

Tires and wheels (except for Korea)

▶ 18-inch tires

Tire size	235/50R18 97W	235/50R18 97W				
	Vehicle speed	Front wheel kPa (kgf/cm ² or bar, psi)	Rear wheel kPa (kgf/cm ² or bar, psi)			
Tire inflation pressure	More than 210 km/h (130 mph)	330 (3.3, 48)*1 300 (3.0, 44)*2	330 (3.3, 48)*1 320 (3.2, 46)*2			
(Recommended cold tire inflation pressure)	From 160 km/h (100 mph) to 210 km/h (130 mph)	280 (2.8, 41)*1 250 (2.5, 36)*2	280 (2.8, 41)*1 260 (2.6, 38)*2			
1	160 km/h (100 mph) or less	250 (2.5, 36)*1 230 (2.3, 33)*2	240 (2.4, 35)*1 230 (2.3, 33)*2			
Wheel size	18×71/2J	וטעולי				
Wheel nut torque	140 N•m (14.3 kgf	•m, 103 ft•lbf)				

^{*1:} For all loads including full rated loads

^{*2:} For reduced loads (1 to 4 passengers only)

Tire size	245/45R19 98Y			
	Vehicle speed	Front wheel kPa (kgf/cm ² or bar, psi)	Rear wheel kPa (kgf/cm ² or bar, psi)	
Tire inflation pressure	More than 210 km/h (130 mph)	280 (2.8, 41)*1 260 (2.6, 38)*2	300 (3.0, 44)*1 260 (2.6, 38)*2	
(Recommended cold tire inflation pressure)	From 160 km/h (100 mph) to 210 km/h (130 mph)	250 (2.5, 36)*1 230 (2.3, 33)*2	270 (2.7, 39)*1 230 (2.3, 33)*2	
	160 km/h (100 mph) or less	240 (2.4, 35)*1 230 (2.3, 33)*2	240 (2.4, 35)*1 230 (2.3, 33)*2	
Wheel size	19 × 8 J	~ / /		
Wheel nut torque	140 N·m (14.3 kgf	·m, 103 ft•lbf)		

^{*1:} For all loads including full rated loads

تلفن شبانه روزي: ۱۵۸۰ ۲۹۸۸۸ - ۲۱

■ Certification

The tires fitted on this vehicle meet the requirements of Indian Standard IS 15633 and they comply with the requirements of Rule 95 as specified under Central Motor Vehicle Rules (CMVR) 1989.

^{*2:} For reduced loads (1 to 4 passengers only)

Light bulbs

	Light bulbs	W	Туре
Exterior	Headlights (vehicles with discharge headlights) High beam *1 High beam or high beam/near-infrared ray	60 65	A B
	High beam *1 High beam or high beam/near-infrared ray transmitters *2 Low/high beam Rear fog lights *3 Vanity lights Front Rear	35 21	С
			D
Interior	, ,	8	D E
	Trunk lid light	3.8	D
	Trunk light	3.8	D

A: HB3 halogen bulbs

B: H9 halogen bulbs

C: D4S discharge bulbs

D: Wedge base bulbs

E: Double end bulbs

*1: Left-hand drive vehicles without Adaptive High-beam System

 $^{\star 2}$: Left-hand drive vehicles with Adaptive High-beam System and right-hand drive vehicles FarmaSOS.com

*3: If equipped

Fuel information

For Brazil:

You must only use unleaded gasoline.

Select premium unleaded gasoline with a Research Octane Number of 95 (octane rating 91) or higher for optimum engine performance.

If this premium type cannot be obtained, you may temporarily use unleaded gasoline with a Research Octane Number as low as 91 (octane rating 87).

Except for Brazil:

You must only use unleaded gasoline.

Select premium unleaded gasoline with a Research Octane Number of 95 or higher for optimum engine performance.

If this premium type cannot be obtained, you may temporarily use unleaded gasoline with a Research Octane Number as low as 91.




■ Use of ethanol blended gasoline in a gasoline engine (except for Korea)

Lexus allows the use of ethanol blended gasoline where the ethanol content is up to 10%. Make sure that the ethanol blended gasoline to be used has a Research Octane Number that follows the above.

■ Use of ethanol blended gasoline in a gasoline engine (for Korea)

 Use only gasoline containing up to 15% ethanol.

DO NOT use any flex-fuel or gasoline that could contain more than 15% ethanol, including from any pump labeled E30, E50, E85 (which are only some examples of fuel containing more than 15% ethanol).



• Make sure that the ethanol blended gasoline to be used has a suitable Research Octane Number.

■ If your engine knocks

- Consult your Lexus dealer.
- You may occasionally notice light knocking for a short time while accelerating or driving uphill. This is normal and there is no need for concern.

♦ NOTICE

■ Notice on fuel quality

- Do not use improper fuels. If improper fuels are used, the engine will be damaged.
- Do not use leaded gasoline.
 Leaded gasoline will cause the three-way catalytic converter to lose its effectiveness and the emission control system to function improperly.
- Do not use the methanol blended gasoline such as M15, M85, M100.
 The use of gasoline containing methanol may cause engine damage or failure.

Customizable features

Your vehicle includes a variety of electronic features that can be personalized to your preferences. These preferences can be changed by using the "DISP" button, by using the Remote Touch, or at your Lexus dealer.

Customizing vehicle features

- Changing by using the Remote Touch
 - 1 Press the "MENU" button on the Remote Touch.
 - 2 Select 💣 on the "Menu" screen and select 🥰 .

Various setting can be changed. Refer to the list of settings that can be changed for details.

■ Changing by using the "DISP" button

 \rightarrow P. 135

Customizable features

Some function settings are changed simultaneously with other functions being customized. Contact your Lexus dealer for further details.

- 1 Settings that can be changed using the Remote Touch
- ② Settings that can be changed using the "DISP" button
- 3 Settings that can be changed by your Lexus dealer Definition of symbols: O = Available, — = Not available

	ltem	Function	Default setting	Custom- ized setting	1	2	3
				British English*2			
				French*2			
				Spanish*2			
			American	German*2			
		Language*1	English*2	Italian*2	_	0	0
				Russia*2 Simplified Chinese*2 Traditional Chinese*2			
		, •	•	_		- O	
	Multi-infor- mation display	ودرو فارما	7)	/ .			
	(→P. 129)	Units*1	km (L/100km)	km (km/L)	- 0 0	0	
		ECO lamp	شبانه ON (Self-light- ing)	OFF ON (Always)	_	0	0
		Drive monitor	Cruising range	Fuel consump- tion	_	0	0
		Lamp brightness	Standard	Bright	-	0	0
		SPORT lamp	ON	OFF	_	0	0
		Background screen	ON	OFF	_	0	0
		Default settings	OFF	ON	_	0	0

ltem	Function	Default setting	Custom- ized setting	1	2	3
	Unlocking using a mechanical key*1	All doors unlocked in one step	Driver's door unlocked in one step, all doors unlocked in two steps	_	_	0
Door lock (→P. 186,	Speed-detecting automatic door lock function	On	Off	0	_	0
631)	Shifting gears to position other than P locks all doors.	Off	On	0	_	0
	Shifting gears to P unlocks all doors.*1	Off	On	0	_	0
	Opening driver's door unlocks all doors.*1	On	Off	0	_	0
	Operation buzzer volume	7 شبانه روزی: (Off to 6 الفن	0	_	0
Smart entry & start system	Operational signal (Emergency flashers)	On	Off	0	_	0
(→P.153) and wireless	Time elapsed before automatic lock function is acti-	30	60 seconds			0
remote control (→P.177)	vated if door is not opened after being unlocked	seconds	120 seconds		0 - 0 - 0 - 0 -	
	Open door warning buzzer	On	Off	_	_	0

ltem	Function	Default setting	Custom- ized setting	1	2	3
	Smart entry & start system	On	Off	0	-	0
Item Function setting ized setting						
Smart ontry	Smart door unlocking *1	_	Each door	0		0
& start system						
(→P.153)	_	On	Off	_	_	0
	electronic key when all	On	Off	_	_	0
	Wireless remote control	On	Off	-	-	0
remote control		unlockedin	door unlocked in one step, all doors unlocked in	0	_	0
		_	Push twice	ff O - O er's or or or or or or or or or or or or or	0	
	Driver's seat movement	C	Off			
		Standard	Partial	O - 0	O	
(→۲. 198)	port movement when exit-	On	Off	_		0

ltem	Function	Default setting	Custom- ized setting	1	2	3
	Front passenger's seat lumbar support firmness adjustment when exiting the vehicle	On	Off	_	_	0
	Front passenger's seat ottoman movement when exiting the vehicle*2	On	Off	_	-	0
Front seats (→P. 198)	Upward movement of entire front passenger seat during stowage when the seat is stowed by using the front passenger seat operation AUTO switch on front console or the front passenger seat operation AUTO button on the rear armrest *2	On	Off	_		0
	The following is the default order of front passenger seat storage operations performed by pressing and holding the front passenger seat operation switch on the rear armrest *2 1 Seat moves forward 2 Seatback folds forward 3 Head restraint moves upward and entire seat moves downward 4 Head restraint folds forward	S. CO 1, 2, 3 and then 4	3, 4, 2 and then 1			0

ltem	Function	Default setting	Custom- ized setting	1	2	3
	The following is the default order of front passenger seat storage operations performed by pressing and holding the front passenger seat operation switch on the front passenger seat seatback *2 1 Seatback folds forward 2 Head restraint moves upward and entire seat moves downward 3 Head restraint folds forward	1, 2 and then 3	2, 3 and then	-	-	0
Front seats (→P. 198)	The following is the default order of front passenger seat return operations performed by pressing and holding the front passenger seat operation switch on the rear armrest *2 1 Head restraint rises and then moves downward 2 Seatback rises 3 Seat moves backwards	1.59.2 and then 3 S.CO	2, 1 and then 3	_		0
	The following is the default order of front passenger seat return operations performed by pressing and holding the front passenger seat operation switch on the front passenger seat seatback*2 1 Head restraint rises and then moves downward 2 Seatback rises	1 to 2	2 to 1	_	_	0

Item	Function	Default setting	Custom- ized setting	1	2	3
Power windows (→P. 236) and moon roof*1	One-touch close opera- tion using the power win- dow switches on the front passenger door and each rear door	On	Off	_	_	0
	One-touch front passen- ger window or rear win- dow close operation using the power window switch on the driver's door	On	Off	_	_	0
(→P. 240)	Mechanical key linked operation	On	Off	_	_	0
	Wireless remote control linked operation *2	Off	On	_	_	0
	Linked entry function	On	Off	-	_	0
Turn signal lever (→P. 278)	Times of flashing of the lane change signal flashers Farmaso	شبانه _{او} زی: (S.C 0	5 7 9 11	0	_	0
	Light sensor sensitivity	Standard	-2 to 2	0	_	0
Automatic light control system (→P. 285)	lights automatically turn off	30 sec- onds	onds		_	
				0		0
(, 255)	after doors are closed ^{*2}		90 sec- onds			

ltem	Function	Default setting	Custom- ized setting	1	2	3
	Time elapsed before head- lights and tail lights auto- matically turn off*2	30 seconds	60 seconds	_		
Automatic			90 seconds		_	0
light control system (→P. 285)			120 seconds			
	Time elapsed before head- lights automatically turn on*2	Standard	Long	_	_	0
AFS (Adaptive Frontlighting System) (→P. 288)	Adaptive Front-lighting System	On	Off	_	_	0
	Changing to variable shade beam	On	Off	_	_	0
	• Y \ - \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \	شبانه روزی: ۵	Normal driving (Speed: low)*3			
Adaptive High-beam System ^{*2} (→P. 291)	Vehicle speed at which Adaptive High-beam Sys- tem operates and variable shade beam adaptation	Normal driving	For ease of operation under mountain road driving conditions	_	_	0
	angle		For ease of operation under mountain road driving conditions (Speed: low)*3			

ltem	Function	Default setting	Custom- ized setting	1	2	3
Lexus parking	Detection distance of the front center sensor	Far	Near	0	1	0
	Detection distance of the rear center sensor	Far	Near	0	-	0
assist-sen- sor ^{*4}	Buzzer volume	3	1 to 5	0	-	0
Sor	Display setting (when Lexus parking assist-sen- sor is operating)	All sensors displayed	Display off	0	ı	0
Automatic air condi- tioning sys- tem (→P. 418)	Switching between outside air and recirculated air mode linked to "AUTO" switch operation*2	On	Off	0	_	0
	A/C Auto switch operation	On	Off	0	ı	0
	Exhaust gas sensor sensitivity*2	Standard	-3 to 3	0	ı	0
	Air conditioning control of Eco drive mode	شبانه وQ <i>ي</i> : (Off	_	_	0

ltem	Function	Default setting	Custom- ized setting	1	2	3
Climate control seats*2/ seat heaters*2 (→P. 478)	Front climate control seat/ seat heater temperature adjustment during auto- matic operation (individual seat adjustment avail- able)*2	Level 3 (standard)	Level 1 (cool) to level 5 (warm)	0	_	0
	Rear climate control seat/ rear seat heater start-up conditions when engine switch is in the ON posi- tion (individual seat adjust- ment available)*2	Off	On (AUTO)	0	_	0
	Function that warms seats faster than usual (individual seat adjustment available)	On	Off	_	_	0
	Time until function that warms seats faster than usual turns off (individual seat adjustment available)	Standard شبانه روزی: (Short Long	_	_	0
Heated steering wheel*2 (→P. 476)	Automatic steering wheel heating	On	Off	0	_	0
	Time until automatic steering wheel heating turns off	Level 3 (standard)	Level 1 (short) to level 5 (long)	0	_	0

Item	Function	Default setting	Custom- ized setting	1	2	3
	Time elapsed before the interior lights turn off	15 seconds	Off		_	
			7.5 seconds	0		0
			30 seconds			
	Operation after the engine switch is turned off	On	Off	_	1	0
	Operation when the doors are unlocked	On	Off	_	1	0
	Operation when you approach the vehicle with the electronic key on your person	On	Off	_	_	0
	Footwell and inside door handle lights	On	Off	_	-	0
Illumination	Shift lever light	On	Off	_	_	0
(→P. 447)	Seat belt buckle illumina- tion when driver's door is opened	شبانه روزی: (On	تلفن Off	_	-	0
	Seat belt buckle illumina- tion after the engine switch is turned off	S.Co	m _{Off}	_	-	0
	Instrument panel illumina- tion method	Choreo- graphed	Simple illu- mination	_	1	0
	tionmethod	illumination	Off			
	Exterior light control	On	Off	_	_	0
		15 seconds	Off 7.5 seconds 30 seconds			
	Time elapsed before the outer foot lights turn off			0	_	0

ltem	Function	Default setting	Custom- ized setting	1	2	3
Illumination (→P. 447)	Operation of the outer foot lights when you approach the vehicle with the elec- tronic key on your person	On	Off	_	_	0
	Operation of the outer foot lights when the doors are unlocked with the power door lock switch	On	Off	_	_	0
Seat belt reminder*5 (→P. 608)	Vehicle speed linked seat belt reminder buzzer	On	Off	_	_	0

^{*1:} The default setting varies according to countries.

^{*2:} If equipped

^{*3:} For GCC countries *6

^{*4:} Refer to "Navigation and Multimedia System Owner's Manual" or "Navigation System Owner's Manual".

^{*5:} For GCC countries *6, Yemen, Jordan, Lebanon and Syria

^{*6:} Saudi Arabia, Sultanate of Oman, Bahrain, United Arab Emirates, Qatar, Kuwait

■ Vehicle customization

- When the speed-detecting automatic door lock and shift-linked automatic door lock are both on, the door lock operates as follows.
 - When shifting the shift lever to any position other than P, all the doors will be locked.
 - If the vehicle is started with all doors locked, the speed- detecting automatic door lock will not operate.
 - If the vehicle is started with any door unlocked, the speed- detecting automatic door lock will operate.
- When the smart entry & start system is off, the entry unlock function cannot be customized.
- When the doors remain closed after unlocking the doors and the timer activated automatic door lock function activates, signals will be generated in accordance with the operation buzzer volume and operational signal (Emergency flashers) function settings.

■ When customizing using the Remote Touch

Stop the vehicle in a safe place, apply the parking brake, and shift the shift lever to P. Also, to prevent battery discharge, leave the engine running while customizing the features.



During customization

As the engine needs to be running during customization, ensure that the vehicle is parked in a place with adequate ventilation. In a closed area such as a garage, exhaust gases including harmful carbon monoxide (CO) may collect and enter the vehicle. This may lead to death or a serious health hazard.



■ During customization

To prevent battery discharge, ensure that the engine is running while customizing features.



تلفن شبانه روزی: ۱۵۸۰۲۰۸۵ – ۲۱

Index

What to do if	
(Troubleshooting)	682
Alphabetical index	688



تلفن شبانه روزی: ۱۵۸۰۲۹۸۸ - ۲۱

FarmaSOS.com

For information regarding the equipment listed below, refer to "Navigation and Multimedia System Owner's Manual" or "Navigation System Owner's Manual".

- Navigation system
- Audio/visual system
- Rear seat entertainment system
- Lexus parking assist-sensor
- Lexus parking assist monitor

What to do if... (Troubleshooting)

If you have a problem, check the following before contacting your Lexus dealer.

The doors cannot be locked, unlocked, opened or closed



You lose your keys

- If you lose your mechanical keys, new genuine mechanical keys can be made by your Lexus dealer. (→P. 147)
- If you lose your electronic keys, the risk of vehicle theft increases significantly. Contact your Lexus dealer immediately. (→P. 152)



The doors cannot be locked or unlocked

- Is the electronic key battery weak or depleted? $(\rightarrow P. 575)$
- Is the engine switch in IGNITION ON mode?
 When locking the doors, turn the engine switch off. (→P. 260)
- Is the electronic key left inside the vehicle?
 When locking the doors, make sure that you have the electronic key on your person.
- The function may not operate properly due to the condition of the radio wave. (→P. 163)



The rear door cannot be opened

• Is the child-protector lock set? The rear door cannot be opened from inside the vehicle when the lock is set. Open the rear door from outside and then unlock the child-protector lock. (→P. 188)



The trunk lid is closed with the electronic key left inside

 The function to prevent the electronic key from being left inside the trunk will operate and you can open the trunk as usual. Take the key out from the trunk. (→P. 193)

تلفن شبانه روزی: ۱۵۸۰۲۹۸۸ - ۲۱

If you think something is wrong



The engine does not start

- Did you press the engine switch while firmly depressing the brake pedal? $(\rightarrow P. 259)$
- Is the shift lever in P? $(\rightarrow P. 259)$
- Is the electronic key anywhere detectable inside the vehicle? $(\rightarrow P. 157)$
- Is the steering wheel unlocked? $(\rightarrow P. 261)$
- Is the electronic key battery weak or depleted?
 In this case, the engine can be started in a temporary way.
 (→P. 634)
- Is the battery discharged? (→P. 636)



The shift lever cannot be shifted from P even if you depress the brake pedal

Is the engine switch in IGNITION ON mode?
 If you cannot release the shift lever by depressing the brake pedal with the engine switch in IGNITION ON mode
 (→P. 267, 275)



The steering wheel cannot be turned after the engine is stopped

It is locked automatically to prevent theft of the vehicle.
 (→P. 261)



The windows do not open or close by operating the power window switches

Is the window lock switch pressed?
 The power window except for the one at the driver's seat cannot be operated if the window lock switch is pressed.
 (→P. 236)



The engine switch is turned off automatically

 The auto power off function will be operated if the vehicle is left in ACCESSORY mode for a period of time. (→P. 261)



A warning buzzer sounds during driving

- The seat belt reminder light is flashing Are the driver and the front passenger wearing the seat belts? $(\rightarrow P.608)$
- The parking brake indicator is on Is the parking brake released? (→P. 279)

Depending on the situation, other types of warning buzzer may also sound. $(\rightarrow P. 605, 614)$



An alarm is activated and the horn sounds

- Did anyone inside the vehicle open a door or anything move inside the vehicle* during setting the alarm? The sensor detects them and the alarm sounds. $(\rightarrow P. 112)$
- *: If the vehicle is equipped with intrusion sensor and tilt sensor.

Do one of the following to stop the alarm:

- ► Vehicles without airbag manual on-off system
 - Unlock the doors or open the trunk.
 - Turn the engine switch to ACCESSORY or IGNITION ON mode, or start the engine.
- ▶ Vehicles with airbag manual on-off system
 - Unlock the doors or open the trunk using the entry function or wireless remote control. • ۱۵ :دوزی: مانه روزی:
 - Start the engine.



FarmaSOS.com A warning buzzer sounds when leaving the vehicle

• Is the message displayed on the multi-information display? Check the message on the multi-information display. $(\rightarrow P.614)$



A warning light turns on or a warning message is displayed

• When a warning light turns on or a warning message is displayed, refer to P. 605, 614.

When a problem has occurred



If you have a flat tire

 Stop the vehicle in a safe place and replace the flat tire with the spare tire. (→P. 618)



The vehicle becomes stuck

 Try the procedure for when the vehicle becomes stuck in mud, dirt, or snow. (→P. 645)

تلفن شبانه روزی: ۱-۸۸۸۶۲ ۲۸ ا

FarmaSOS.com

Alphabetical index

A	
A/C	
Air conditioning filter	572
Front automatic air conditioni	ng
system	418
Rear air conditioning	
system	438
ABS (Anti-lock Brake System)	360
Function	360
Warning light	606
Adaptive Front-lighting System	
(AFS)	288
Adaptive High-beam System	
(AHS)	291
AFS (Adaptive Front-lighting	,ונכ
System)	288
AHS (Adaptive High-beam	
System)	291
Air cleaner filter	554
Air conditioning filter	572
Air conditioning system	
Air conditioning filter	572
Front automatic air	
conditioning system	418
Rear air conditioning system	438

Airbags	51
Airbag manual on-off system	69
Airbag operating conditions	59
Airbag precautions for	
your child	54
Airbag warning light	506
Correct driving posture	44
Curtain shield airbag operating	
conditions	60
Curtain shield airbag	
precautions	54
Front passenger occupant	
classification system	64
General airbag precautions	54
Locations of airbags	51
Modification and	
disposal of airbags	58
Side airbag operating	
conditions	60
Side airbag precautions	54
Side and curtain shield airbags	
Operating conditions	60
Side and curtain shield airbags	
precautions	54
SRS airbags	51

Airbag manual on-off system69	В
Alarm	Back-up lights
Alarm112	Replacing light bulbs590
Warning buzzer605, 614	Battery549
Anchor brackets89, 90	Battery checking549
Antennas (smart entry &	If the vehicle battery is
start system)156	discharged636
Anti-lock Brake System (ABS)360	Preparing and checking before
Function360	winter399
Warning light606	Warning light606
Anti-theft device118	Blind Spot Monitor (BSM)381
Approach warning319, 335	Brake
Armrest483	Brake Hold282
Armrest door494	Emergency brake signal361
Ashtrays470	Fluid659
Assist grips497	Parking brake279
Audio/visual system*	Warning light605, 607
Automatic headlight leveling	Brake assist
system289	Brake Hold282
Automatic light control system285	Break-in tips248
Automatic transmission264, 269	Brightness control
If the shift lever cannot be	Instrument panel light control126
shifted from P267, 275	BSM (Blind Spot Monitor)
M mode272	
Paddle shift switches271	
S mode265	
Auxiliary boxes462	

^{*:} Refer to "Navigation and Multimedia System Owner's Manual" or "Navigation System Owner's Manual".

С	
Card key	144
Care51	0, 514
Aluminum wheels	511
Exterior	510
Interior	514
Seat belts	515
Cargo hooks	465
Cargo net	465
Chains	401
Child restraint system	72
Baby seats (infant seats),	
definition	72
Baby seats (infant seats),	4
installation	91
Child seats (convertible seats)	J
definition	72
Child seats (convertible seats)	, cy.
installation	91
Front passenger occupant	
classification system	
Installing CRS with ISOFIX	a5
rigid anchors	94
Installing CRS with seat belts	91
Installing CRS with top strap	95
Junior seats (booster seats),	
definition	72
Junior seats (booster seats),	
installation	93

Child safety71
Airbag precautions54
Battery precautions551, 640
Child restraint system72
Climate control seat
precautions482
Heated steering wheel
precautions477
How your child should wear
the seat belt47, 48
Installing child restraints89
Moon roof precautions243
Power window lock switch236
Power window precautions238
Rear door child-protectors188
Removed electronic key
battery precautions577
Seat belt comfort guide47
Seat belt precautions50
Seat heater precautions482
Trunk precautions194
Child-protectors188
Cigarette lighter471
Cleaning510, 514
Aluminum wheels511
Exterior510
Interior514
Seat helts 515

Climate control seat	478	D	
Climate control seat filter	481	Daytime running light system	288
Clock	469	Defogger	
Clock light	447	Front windshield	427
Coat hooks	496	Outside rear view mirrors	445
Coin holder	454	Rear window	445
Condenser	549	Differential	
Console box	457	Front differential	658
Cool box	459	Rear differential	658
Coolant	547	Dimensions	648
Capacity	.656	Display	
Checking	547	Dynamic radar cruise control	313
Preparing and checking		Dynamic radar cruise control	
before winter	399	with full-speed range	328
Cooling system	.547	LKA (Lane-Keeping Assist)	348
Engine overheating	641	Multi-information display	129
Cruise control		Remote Touch screen	406
Cruise control	309	Trip information	13
Dynamic radar cruise control	313 · /\\ \(\text{i} :	تلفن شانه وزی message	614
Dynamic radar cruise control		Do-it-yourself maintenance	533
with full-speed range		Door courtesy lights	447
Cup holders	455	Door lock	
Curtain shield airbags	52	Doors	186
Customizable features	667	Smart entry & start system	153
		Wireless remote control	177
		Door pockets	454

Doors	186		Е	
Automatic door locking and			Eco drive mode	354
unlocking system	189		Eco Driving Indicator	132
Door glasses	236		Eco-friendly driving tips	
Door lock	186		Electric Power Steering (EPS)	361
Open door warning buzzer	158		Function	361
Open door warning light	608		Warning light	606
Outside rear view mirrors	232		Electronic key	144
Rear door child-protector	188		If the electronic key does not	
Double locking system	111		operate properly	631
Driver's seat position memory.	218		Replacing the battery	575
Driving	246		Electronically modulated air	
Break-in tips	248		suspension	358
Correct driving posture	44	1	Emergency brake signal	361
Driving mode select switch	354		Emergency flashers	594
Eco-friendly driving tips	403			
Procedures	246			
Winter drive tips	399	۸ ۸	A e efe	
Dynamic radar cruise control		/(ω :	تلفن شبانه روزی	
Function	313			
Dynamic radar cruise control v	vith			
full-speed range	328	US	com.	
Function	328			

Warning light.....606

Emergency, in case of	Engine	
If the electronic key does not	ACCESSORY mode	260
operate properly631	Air cleaner	554
If the engine will not start627	Compartment	539
If the parking brake cannot be	Engine switch	259
released629	Hood	536
If the vehicle battery is	How to start the engine	259
discharged636	Identification number	651
If the warning buzzer sounds 605	If the engine will not start	627
If the warning light turns on 605	Ignition switch (engine switch)	259
If the warning message is	Overheating	641
displayed614	Engine compartment cover	541
If you have a flat tire618	Engine coolant	547
If you think something is	Capacity	656
wrong603	Checking	547
If your vehicle becomes stuck645	Preparing and checking befor	е
If your vehicle has to be stopped	winter	399
in an emergency595	Engine coolant temperature	
If your vehicle needs to be	تلفن شبانه روزی: gauge :	125
towed596	Engine immobilizer system	104
If your vehicle overheats641	Engine oil	544
FarmaSOS	Capacity	653
	Checking	544
	Preparing and checking befor	е
	winter	399
	Engine switch	259
	EPS (Electric Power Steering)	361
	Function	361

г	100
Front seats	
Adjustment	
Cleaning	514
Climate control seats	478
Correct driving posture	44
Driving position memory	218
Head restraints	225
Power easy access system	201
Seat position memory	218
Front turn signal lights	278
Replacing light bulbs	590
Turn signal lever	
Fuel	
Capacity	652
Fuel gauge	
Fuel pump shut off system	604
Information	665
Refueling	305
تلفنٌ شيأنه ₇ وزء	652,665
Warning light	
Fuel filler door	
If the fuel filler door cannot	
be opened	
Refueling	
Fuel pump shut off system	
Fuses	

G		Heaters	
Garage door opener498		Front automatic air	
Gauges125		conditioning system	418
Gear Shift Indicator273		Heated steering wheel	. 476
Glove box453		Outside rear view mirrors	.445
		Rear air conditioning system	.438
Н		Seat heaters	. 479
Head restraints225		Height control	
Active head restraint226		Electronically modulated air	
Adjustment225		suspension	.358
Headlight cleaner304		Hill-start assist control	360
Headlights285		Hood	536
Adaptive Front-lighting		Open	.536
System (AFS)288	14	Hooks	
Adaptive High-beam System		Cargo hooks	.465
(AHS)291		Coat hooks	.496
Discharge headlights		Retaining hooks (floor mat)	42
precautions592	٠٨٨.	Shopping bag hooks	.465
Follow me home system287	/ τω .	تلفن شبانه روزن	284
Light switch285			
Replacing light bulbs590	00		
Wattage664	U2).COM	

1		J
Identification	650	Jack
Engine	651	Positioning the jack537
Vehicle	650	Vehicle-equipped jack619
Ignition switch (engine switch)	259	Jack handle619
Illuminated entry system	450	Jam protection function
Immobilizer system	104	Moon roof24
Indicators	123	Power trunk lid193
Initialization		Power window237
Moon roof	242	Rear door sunshade492
Power windows	237	
Tire pressure warning		K
system	558	Keyless entry153
Initiators (tire pressure warning	0 1 4	Smart entry & start system153
system)	566	Wireless remote control177
Inside door handle lights	447	Keys144
Inside rear view mirror	229	Electronic key144
Instrument panel light control	126	Engine switch259
Instrument panel ornament	V 1 1/14	If the electronic key does not
lights	447	operate properly63
Interior lights	448	If you lose your keys147, 152
Front interior lights	448	Key number plate144
Rear interior lights	448	Keyless entry153, 177
Interior lights list	447	Mechanical key145
Intrusion sensor and tilt sensor	115	Replacing the battery575
ISOFIX rigid anchors	89	Warning buzzer158
		Wireless remote control key177
		Knee airbags5

L			Lights	
Lane-Keeping Assist (LKA)	344		Adaptive High-beam System	
Operation	346		(AHS)	291
Language (multi-information			Fog light switch	298
display)	135		Follow me home system	287
Lever			Headlight switch	285
Auxiliary catch lever	536		Illuminated entry system	450
Hood lock release lever	536		Interior lights	448
Shift lever20	64, 269		Interior lights list	447
Turn signal lever	278		Personal lights	449
Wiper lever	300		Replacing light bulbs	586
Lexus Climate Concierge	417		Trunk light	193
Lexus night view	393		Turn signal lever	278
Lexus parking assist monitor*		4 67	Vanity lights	467
Lexus parking assist-sensor*	フノ		Wattage	664
License plate lights	285		Welcome light illumination	
Light switch	285		control	154
Replacing light bulbs	590		LKA (Lane-Keeping Assist)	344
Welcome light illumination	//)	·/\ω :	تلف: شيانه وزی 	346
control	154		Lock steering column	261
Light bulbs			Luggage security system	192
ReplacingReplacing	586	OS	com.	
Wattage	664			

^{*:} Refer to "Navigation and Multimedia System Owner's Manual" or "Navigation System Owner's Manual".

M		N	
Maintenance		nanoe TM	436
Do-it-yourself maintenance533		Navigation system*	
Maintenance data648		Noise from under vehicle	8
Maintenance requirements517			
Scheduled maintenance520		0	
Malfunction indicator lamp606		Odometer	125
Master warning light608		Oil	
Meter125		Engine oil	653
Indicators123		Front differential oil	658
Instrument panel light control126		Rear differential oil	658
Meters125		Opener	
Multi-information display129		Fuel filler door	307
Warning lights122) 4	Hood	536
Mirrors		Trunk	191
Inside rear view mirror229		Outer foot lights	
Outside rear view mirror		Location	447
defoggers445 Outside rear view mirrors232	٠٨٨.	Replacing light bulbs	590
	7 100 .	Outside rear view mirrors	232
Vanity mirrors467		Adjusting and folding	232
Moon roof240	00	BSM (Blind Sport Monitor)	381
Door lock linked moon roof	U	Linked mirror function when	
operation241		reversing	234
Jam protection function241		Mirror position memory	218
Operation240		Outside rear view mirror	
Multi-information display129		defoggers	445
Dynamic radar cruise control313		Outside temperature display	
Dynamic radar cruise control		Overheating, Engine	641
with full-speed range328			
Lane-Keeping Assist348			
Language		1	
Switching the display131		1	
Trip information131		1	
Warning message614			

Р	Power windows236
Paddle shift switches271	Door lock linked window
Parking brake279	operation238
If the parking brake cannot	Jam protection function237
be released629	Operation236
Operation279	Window lock switch236
Parking brake engaged	Pre-Crash Safety system
warning buzzer281	(PCS)368
PCS (Pre-Crash Safety	Function368
system)368	Pre-crash braking off switch370
Function368	Warning light607
Pre-crash braking off switch370	
Warning light607	
Pelvic support seat with seat	
vibrator210	ושעול לי
Personal lights449	
Front personal light449	
Rear personal light449	
Pollen removal mode431	تلفن شبانه روزی <mark>: ۸۵ •</mark>
Power easy access system201	
Power outlets473	
Power steering361	OS.com
Warning light606	
Power trunk lid191	

^{*:} Refer to "Navigation and Multimedia System Owner's Manual" or "Navigation System Owner's Manual".

R		Rear turn signa
Radar cruise control (dynamic		Replacing lig
radar cruise control)3	13, 328	Turn signal le
Radiator	549	Rear view mirro
RCTA	390	Inside rear vi
Rear air conditioning system	438	Outside rear
Rear door sunshades	490	Rear window de
Rear fog lights	298	Refueling
Replacing light bulbs	589	Capacity
Switch		Fuel types
Wattage	664	If the fuel fille
Rear seat		be opened
Adjustment	205	Opening the
Climate control seat	479	Remote Touch.
Seat heaters	479	Remote Touch
Seat position memory	223	Replacing
Rear seat entertainment system	* I	Electronic ke
Rear seat relaxation system	212	Fuses
Rear sunshade	\	تلفران شرانه Light bulbs
Operation	486	Tires
Reverse operation feature		Retractable tab
Farm	a508	i.com

Rear turn signal lights	278
Replacing light bulbs	
Turn signal lever	
Rear view mirror	
Inside rear view mirror	229
Outside rear view mirrors	
Rear window defogger	
Refueling	
Capacity	
Fuel types	
If the fuel filler door cannot	002
be opened	308
Opening the fuel tank cap	
Remote Touch	
Remote Touch screen	
Replacing	400
1 3	5.75
Electronic key battery	
Fuses	5/9
تلفران الفيالية الفيارة النهاع وزع Light bulbs	
Tires	
Retractable table	484

S	Se	eats	198, 205
Schedule maintenance520		Adjustment	198, 205
Seat belt reminder light608	,	Adjustment precautions.	203, 216
Seat belts46	,	Child seats/child restrain	ıt
Adjusting the seat belt47	,	system installation	89
Child restraint system		Cleaning	514
installation91		Climate control seat	478
Cleaning and maintaining		Driving position memory	·218
the seat belt515	•	Head restraints	225
Emergency locking retractor		Pelvic support seat with s	seat
(ELR)48		vibrator	210
How to wear your seat belt46		Power easy access syste	m201
How your child should wear		Properly sitting in the sea	ıt44
the seat belt48	4 67	Rear seat position memo	ry223
Pre-crash seat belts48	17 /	Rear seat relaxation syste	em 212
Pregnant women, proper		Seat heaters	479
seat belt use49)	Seat position memory	218, 223
Reminder light and buzzer608		a) a +1	
Seat belt pretensioners47	زی: ۲۸ω۰	تلفن شبانه رو	
SRS warning light606)		
Seat cushion airbag52			
Seat heaters479	505.	com	
Seat position memory218, 223			

^{*:} Refer to "Navigation and Multimedia System Owner's Manual" or "Navigation System Owner's Manual".

Sensor	Side turn signal lights	278
Adaptive High-beam System	Replacing light bulbs	
(AHS)297	Turn signal lever	
Automatic headlight system 288	Smart entry & start system	
Camera sensors371	Antenna location	
Driver monitor sensor371	Entry functions	153
Inside rear view mirror231	Starting the engine	259
Intrusion sensor and tilt sensor 115	Snow mode	
Lexus night view	Snow tires	402
LKA (Lane-Keeping Assist)344	Spare tire	618
Radar sensor322, 338, 370, 386	Inflation pressure	660, 662
Rain-sensing windshield	Storage location	619
wipers302	Spark plug	656
Shift lever264, 269	Specifications	648
Automatic transmission264, 269	Speedometer	125
If the shift lever cannot	Sport mode	354
be shifted from P267, 275	Steering lock	26
Shift lever light447	Column lock release	26
Shift lock system267, 275	Steering wheel	228
Shopping bag hooks465	Adjustment	228
Side airbags52	Heated steering wheel	476
Side mirrors232	Power easy access system	m20
Adjusting and folding232	Steering wheel position	
BSM (Blind Spot Monitor)381	memory	218
Linked mirror function when	Stop lights	
reversing234	Emergency brake signal.	36
Mirror position memory218	Replacing light bulbs	590
	Storage feature	45

Stuck
If the vehicle becomes stuck645
Sun shade
Rear486
Rear door490
Roof241
Sun visors 467
Switches
Adaptive High-beam System
switch292
Airbag manual on-off system69
Brake hold switch282
BSM (Blind Spot Monitor)
main switch381
Climate control seat switches478
Cruise control switch309
"DISP" button131
Door lock switches186
Driving mode select switch354
Driving position memory
switches218

	Dynamic radar cruise control.	313
	Dynamic radar cruise control	
	with full-speed range	328
	Emergency flashers switch	594
	Engine switch	
	Fog light switch	298
	Headlight cleaner switch	304
	Heated steering wheel	
	switch	476
	Ignition switch	259
	Lexus night view switch	393
,	Light switch	285
	LKA (Lane-Keeping Assist)	
	switch	346
	Moon roof switches	240
	Outside rear view mirror	
	switches	232
	Paddle shift switches	
.ک	Parking brake switches	279
	Power door lock switch	186
	Power trunk lid	191
Š.	Power window switches	236
	Pre-crash braking off switch	370

Rear door sunshade switch 490	Т
Rear seat position memory	Tachometer125
switches223	Tail lights285
Rear sunshade switch486	Light switch285
Rear window and outside	Replacing light bulbs590
rear view mirror defoggers	Welcome light illumination
switch445	control154
Seat heater switches479	Theft deterrent system
Snow mode switch266, 274	Alarm112
Tilt and telescopic steering	Double locking system111
control switch228	Engine immobilizer system104
Tire pressure warning	Intrusion sensor and tilt sensor115
reset switch559	Tire inflation pressure568
Trunk closer switch192	Maintenance data660, 662
Trunk opener main switch192	Tire inflation pressure display
Trunk opener switch191	function133
Vehicle-to-vehicle distance	Warning light609
button316, 331	Tire pressure warning system558
button	558558558
Window lock switch236	Initializing558
Windshield wipers and	Installing tire pressure warning
washer switch300	valves and transmitters558
	Registering ID codes560
	Tire pressure warning reset

switch.....559 Warning light.....609

Tires	556	TRC (Traction Control)
Chains	401	Trip information
Checking	556	Trip meters
If you have a flat tire	618	Trunk
Inflation pressure	660, 662	Extending a space
Replacing	618	Jam protection function
Rotating tires	557	Luggage security system
Size		Power trunk lid
Snow tires	402	Smart entry & start syste
Spare tire	618	Trunk closer switch
Tire inflation pressure o	display	Trunk easy closer
function	133	Trunk features
Tire pressure warning	system558	Trunk grip
Warning light		Trunk lid light
Tools		Trunk light
Top strap	95	Trunk opener main swit
Towing	596	Trunk opener switch
Emergency towing	596	Trunk storage extension
Towing eyelet	599 · \\\	تلف شیانه وزی Wireless remote contro
Trailer towing		Trunk light
Traction Control (TRC)	360	Trunk lid light
Trailer towing	258	Trunk light
Transmission		Wattage
Automatic transmission	n264, 269	Turn signal lights
Driving mode select sv	vitch354	Replacing light bulbs
If the shift lever cannot		Turn signal lever
be shifted from P	267, 275	
M mode	272	
Paddle shift switches	271	
S mode	265	

TRC (Traction Control)	360
Trip information	131
Trip meters	125
Trunk	191
Extending a space	494
Jam protection function	193
Luggage security system	192
Power trunk lid	191
Smart entry & start system	155
Trunk closer switch	192
Trunk easy closer	193
Trunk features	465
Trunk grip	192
Trunk lid light	193
Trunk light	193
Trunk opener main switch	192
Trunk opener switch	191
Trunk storage extension	
Wireless remote control	177
Trunk light	
Trunk lid light	193
Trunk light	193
Wattage	664
Turn signal lights	278
Replacing light bulbs	590
Turn signal lever	278

V	W
Vanity lights	Warning buzzers
Vanity lights467	Approach warning319, 335
Wattage664	Brake system605
Vanity mirrors467	Downshifting266, 274
Variable Gear Ratio Steering	Key reminder158
(VGRS)361	No-handed driving warning 349
Function361	Open door608
VDIM (Vehicle Dynamics	Open moon roof243
Integrated Management)361	Pre-crash braking369
Vehicle data recordings10	Seat belt reminder608
Vehicle Dynamics Integrated	Speed warning61
Management (VDIM)	Warning lights122
Vehicle identification number650	ABS606
Vehicle Stability Control	Brake hold operated
(VSC)360	indicator607
VGRS (Variable Gear Ratio	Brake system605, 607
Steering)361	Charging system606
Steering)361 Function361	Electric power steering
VSC	system606
(Vehicle Stability Control)360	Low fuel level608
FarmaSo	Malfunction indicator lamp606
	Master warning light608
	Open door608
	Parking brake indicator607
	Pre-Crash Safety system607
	Seat belt reminder light608
	Slip indicator607
	SRS606
	Tire pressure609

Washer	300
Checking	553
Preparing and checking	
before winter	399
Switch	300
Washing and waxing	510
Weight	648
Welcome light illumination	
control	154
Wheels	570
Replacing	570
Size	660, 662
Window glasses	236
Window lock switch	236
Windows	236
Power windows	236
Rear window defogger	445
Windshield wiper de-icer	446
Windshield wiper de-icer Windshield wipers	لفن شبانه روزی: ۵۸۰ 300
Winter driving tips	399
Wireless remote control ke	y177
Locking/Unlocking	mabus.com
Replacing the battery	

GAS STATION INFORMATION		
Auxiliary catch lever	Trunk opener	Fuel filler door
P. 536	P. 191	P. 307
CLYPIBA056		
Hood lock release lever	Fuel filler door opener	Tire inflation pressure
P. 536	P. 307	P. 660, 662
וטלור צונר טלט		
Fuel tank capacity (Reference)	84 L (22.2 gal., 18.4 lmp. gal.)	
Fuel type • 🔨 \	Premium unleaded gasoline c	only تلفن سب
Cold tire inflation pressure		P. 660, 662
Engine oil capacity (Drain and refill – reference)	With filter 2WD models AWD models Without filter	L (qt., Imp. qt.) 8.6 (9.1, 7.6) 9.0 (9.5, 7.9) 8.4 (8.9, 7.4)
Engine oil type	"Toyota Genuine Motor Oil"	or equivalent P. 653